






AcerPower SE

User's Guide







Copyright 1999 Acer Incorporated
All Rights Reserved. Printed in Taiwan

AcerPower SE User's Guide
Part No.: 49.XXXXX.XXX
Draft Version: May, 1999

Changes may be made periodically to the information in this publication without obligation to notify any person of such revision or changes. Such changes will be incorporated in new editions of this manual or supplementary documents and publications. This company makes no representations or warranties, either expressed or implied, with respect to the contents hereof and specifically disclaims the implied warranties of merchantability or fitness for a particular purpose.

Record the model number, serial number, purchase date, and place of purchase information in the space provided below. The serial number and model number are recorded on the label affixed to your computer. All correspondence concerning your unit should include the serial number, model number, and purchase information.

No part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form or by any means, electronic, mechanical, photocopy, recording, or otherwise, without the prior written permission of Acer Incorporated.



AcerPower SE User's Guide

Model Number : _____

Serial Number : _____

Purchase Date : _____

Place of Purchase : _____

All trademarks, registered trademarks and/or service marks are the properties of their respective owners.






Table of Contents

Notices	v
-------------------	---

Chapter 1 Getting Started 1

Overview	3
Preinstallation	4
Selecting a Site	4
Unpacking Components	4
Features	5
Front Panel	5
Rear Panel	6
Connecting System Components	8
Connecting the Keyboard	8
Connecting the Monitor	9
Connecting the Mouse	9
Connecting the Printer (optional)	10
Connecting Multimedia Components	10
Connecting to the Network (optional)	11
Connecting the Fax/Modem (optional)	11
Connecting USB Devices (optional)	12
Turning On Your Computer	13
Turning Off Your Computer	14
Troubleshooting	15
Error Messages	17
Software Error Messages	17
System Error Messages	17
Correcting Error Conditions	19

Chapter 2 System Board Information 21

Features	23
Board Layout	25
Jumpers and Connectors	28
Floppy Disk / Hard Disk Support	31
Video Function	32
Audio Function	33
USB Support	34
Hardware Monitoring Function	35
Modem Ring-in Function	36
Wake-on LAN	37

iv Table of Contents

Chapter 3 `BIOS Information	39
Entering Setup	42
System Information	44
Product Information	48
Disk Drives	50
Onboard Peripherals	54
Onboard Device Settings	56
Power Management	58
Boot Options	60
Date and Time	63
System Security	64
Setting a Password	66
Changing or Removing the Password	67
Bypassing the Password	68
Advanced Options	69
Memory/Cache Options	70
PnP/PCI Options	72
Load Default Settings	74
Abort Settings Change	75
Exiting Setup	76
 Chapter 4 Upgrading the System	77
Installation Precautions	79
ESD Precautions	79
Preinstallation Instructions	79
Post-installation Instructions	80
Opening the System	81
Removing the Housing Cover	81
Replacing the Housing Cover	82
Installing Additional Memory	84
Installing a DIMM	86
Removing a DIMM	87
Reconfiguring the System	87
Upgrading the CPU	88
Removing the CPU	88
Installing the Upgrade CPU	90
Replacing the Hard Disk	92
Installing and Removing a PCI Card	95
Installing a PCI Card	95
Removing a PCI Card	95
Index	97



Notices

FCC Notice

This device has been tested and found to comply with the limits for a Class B digital device pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This device generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this device does cause harmful interference to radio or television reception, which can be determined by turning the device off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- ☐ Reorient or relocate the receiving antenna
- ☐ Increase the separation between the device and receiver
- ☐ Connect the device into an outlet on a circuit different from that to which the receiver is connected
- ☐ Consult the dealer or an experienced radio/television technician for help

Notice: Shield Cables

All connections to other computing devices must be made using shielded cables to maintain compliance with FCC regulations.

Notice: Peripheral Devices

Only peripherals (input/output devices, terminals, printers, etc.) certified to comply with the Class B limits may be attached to this equipment. Operation with non-certified peripherals is likely to result in interference to radio and TV reception.

Caution

Changes or modifications not expressly approved by the manufacturer could void the user's authority, which is granted by the Federal Communications Commission, to operate this computer.



Use Conditions

This part complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Notice: Canadian Users

This Class B digital apparatus meets all requirements of the Canadian Interference-Causing Equipment Regulations.




Remarque à l'intention des utilisateurs canadiens

Cet appareil numérique de la classe B respecte toutes les exigences du Règlement sur le matériel brouilleur du Canada.

Important Safety Instructions

Read these instructions carefully. Save these instructions for future reference.

1. Follow all warnings and instructions marked on the product.
2. Unplug this product from the wall outlet before cleaning. Do not use liquid cleaners or aerosol cleaners. Use a damp cloth for cleaning.
3. Do not use this product near water.
4. Do not place this product on an unstable cart, stand, or table. The product may fall, causing serious damage to the product.
5. Slots and openings in the cabinet and the back or bottom are provided for ventilation; to ensure reliable operation of the product and to protect it from overheating, these openings must not be blocked or covered. The openings should never be blocked by placing the product on a bed, sofa, rug, or other similar surface. This product should never be placed near or over a radiator or heat register, or in a built-in installation unless proper ventilation is provided.
6. This product should be operated from the type of power indicated on the marking label. If you are not sure of the type of power available, consult your dealer or local power company.
7. Do not allow anything to rest on the power cord. Do not locate this product where persons will walk on the cord.
8. If an extension cord is used with this product, make sure that the total ampere rating of the equipment plugged into the extension





cord does not exceed the extension cord ampere rating. Also, make sure that the total rating of all products plugged into the wall outlet does not exceed the fuse rating.

9. Never push objects of any kind into this product through cabinet slots as they may touch dangerous voltage points or short out parts that could result in a fire or electric shock. Never spill liquid of any kind on the product.
10. Do not attempt to service this product yourself, as opening or removing covers may expose you to dangerous voltage points or other risks. Refer all servicing to qualified service personnel.
11. Unplug this product from the wall outlet and refer servicing to qualified service personnel under the following conditions:
 - a. When the power cord or plug is damaged or frayed
 - b. If liquid has been spilled into the product
 - c. If the product has been exposed to rain or water
 - d. If the product does not operate normally when the operating instructions are followed. Adjust only those controls that are covered by the operating instructions since improper adjustment of other controls may result in damage and will often require extensive work by a qualified technician to restore the product to normal condition.
 - e. If the product has been dropped or the cabinet has been damaged
 - f. If the product exhibits a distinct change in performance, indicating a need for service.
12. Replace the battery with the same type as the product's battery we recommend. Use of another battery may present a risk of fire or explosion. Refer battery replacement to a qualified serviceman.
13. Warning! Batteries may explode if not handled properly. Do not disassemble or dispose of them in fire. Keep them away from children and dispose of used batteries promptly.
14. Use only the proper type of power supply cord set (provided in your accessories box) for this unit. It should be a detachable type: UL listed/CSA certified, type SPT-2, rated 7A 125V minimum, VDE approved or its equivalent. Maximum length is 15 feet (4.6 meters).




Year 2000 Compliance Statement


This product is Year 2000-compliant and carries the “NSTL Hardware Tested Year 2000 Compliant” logo. This product has been tested both by Acer’s internal test labs and NSTL using NSTL’s YMARK2000 certification test. These tests certify that this product will successfully make the year 2000 transition.



For more details, check the Acer Year 2000 Resource Center at <http://www.acer.com.tw/service/y2k/>



Laser Compliance Statement



The CD-ROM drive in this computer is a laser product. The CD-ROM drive’s classification label (shown below) is located on the drive.

CLASS 1 LASER PRODUCT

CAUTION: INVISIBLE LASER RADIATION WHEN OPEN.
AVOID EXPOSURE TO BEAM.

APPAREIL A LASER DE CLASSE 1 PRODUIT

LASERATTENTION: RADIATION DU FAISCEAU LASER
INVISIBLE EN CAS D’OUVERTURE. EVITER TOUTE
EXPOSITION AUX RAYONS.


LUOKAN 1 LASERLAITE LASER KLASSE 1

VORSICHT: UNSICHTBARE LASERSTRAHLUNG, WENN
ABDECKUNG GEÖFFNET NICHT DEM STRAHL AUSSETZEN

PRODUCTO LÁSER DE LA CLASE I

ADVERTENCIA: RADIACIÓN LÁSER INVISIBLE AL SER
ABIERTO. EVITE EXPONERSE A LOS RAYOS.

ADVARSEL: LASERSTRÅLING VEDÅBNING SE IKKE IND I
STRÅLEN.





VARO! LAVATTAESSA OLET ALTTINA LASERSÄTEILYLLE.

VARNING: LASERSTRÅLNING NÄR DENNA DEL ÄR ÖPPNAD
ÄLÄ TUJOTA SÄTEESEENSTIRRA EJ IN I STRÅLEN

VARNING: LASERSTRÅLNING NÄR DENNA DEL ÄR
ÖPPNADSTIRRA EJ IN I STRÅLEN

ADVARSEL: LASERSTRÅLING NÄR DEKSEL ÄPNESSTIRR IKKE
INN I STRÅLEN

Lithium Battery Statement

CAUTION

Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer. Discard used batteries according to the manufacturer's instructions.

ADVARSEL!

Lithiumbatteri - Eksplosionsfare ved fejlagtig håndtering. Udskiftning må kun ske med batteri af samme fabrikat og type. Léver det brugte batteri tilbage til leverandøren.

ADVARSEL

Ekspløsjonsfare ved feilaktig skifte av batteri. Benytt samme batteritype eller en tilsvarende type anbefalt av apparatfabrikanten. Brukte batterier kasseres i henhold til fabrikantens instruksjoner.

VARNING

Explosionsfara vid felaktigt batteribyte. Använd samma batterityp eller en ekvivalent typ som rekommenderas av apparattillverkaren. Kassera använt batteri enligt fabrikantens instruktion.

VAROITUS






Päristo voi räjähtää, jos se on virheellisesti asennettu. Vaihda paristo ainoastaan laitevalmistajan suosittelemaan tyyppiin. Hävitä käytetty paristo valmistajan ohjeiden mukaisesti.




VORSICHT!

Explosionsgefahr bei unsachgemäßen Austausch der Batterie Ersatz nur durch denselben oder einem vom Hersteller empfohlenem ähnlichen Typ. Entsorgung gebrauchter Batterien nach Angaben des Herstellers.




x Notices








Getting Started

Chapter 1





This chapter gives you a general introduction of the system unit, tells you how to select a site, and set up the system. It also includes a simple troubleshooting section to allow you to check your system before you ask for technical support.









Overview

The AcerPower SE is an all-in-one high-performance system that supports the Intel Celeron (with integrated second-level cache). It utilizes the PCI (Peripheral Component Interface) and the AGP (Accelerated Graphics Port) bus designs. Both designs improve system performance, enabling the system to support various multimedia functions and applications.

Aside from the standard I/O (Input/Output) interfaces such as one serial port, one parallel port, and PS/2 keyboard and mouse ports, the system also comes with two USB (Universal Serial Bus) ports, one mono Microphone-in port, one stereo Line-in port, one Line-out port, and one Game/MIDI (Musical Instrument Digital Interface) port. These additional ports are included to enable the system to accommodate additional peripherals.

The system may also come with an onboard AGP video controller, an onboard audio controller, an external fax/modem card and/or a network card. These additional features offer special functions that will enable you to take full advantage of the system. Special features such as hardware monitoring, wake-on LAN, modem ring-in, USB, power management, video and audio functions are discussed in Chapter 2 of this manual.

Furthermore, this system is fully compatible with MS-DOS v6.X, OS/2, SCO UNIX, Windows 98 and Windows NT operating systems.





4 Chapter 1 Getting Started



Preinstallation

The preinstallation process involves the following activities:

- ☐ Selecting a site
- ☐ Unpacking components

Selecting a Site




Consider the following when selecting a site for your computer:

- ☐ Determine the best site for your system. Cable paths should not run near equipment that might cause electromagnetic or radio frequency interference such as radio transmitters, televisions, copy machines, or heating and air-conditioning equipment.
- ☐ Route cables away from personnel and equipment traffic.
- ☐ Avoid dusty areas and extremes of temperature and humidity.

Unpacking Components

Unpack the contents of each box carefully. Save all packing materials in case you need to move or ship the system in the future.

Check that all items are present and in good condition. Contact your dealer immediately if anything is missing or damaged.




Features

The basic configuration consists of a system unit, a keyboard, a CD-ROM drive, a floppy disk drive, a hard disk drive and a mouse.

Front Panel

The figure below shows the system unit front panel.




No.	Component
1	Headphone/Earphone port
2	CD-ROM tray
3	Stop/Eject button
4	Skip/Forward button
5	CD-ROM LED

6 Chapter 1 Getting Started

No.	Component
6	Increase Volume button
7	Decrease Volume button
8	Turbo LED
9	Power LED
10	Hard disk drive LED
11	Power button
12	3.5-inch floppy disk drive eject button
13	3.5-inch floppy disk drive
14	3.5-inch floppy disk drive LED






Rear Panel

The figure below shows the system unit rear panel.





No.	Component
1	Fan
2	System main power switch
3	Voltage selector
4	System power socket
5	USB ports
6	PS/2 mouse port
7	PS/2 keyboard port
8	Serial port 2
9	Parallel port
10	VGA/Monitor port
11	Speaker-out/Line-out port
12	Line-in port
13	Game/MIDI portt
14	Microphone-in port
15	Add-on card brackets



Connecting System Components




Caution: Do not turn on the system main power switch on the rear panel of the system or plug the system in until you finish connecting all system components.

The following sections show how to connect each component to the system:


Connecting the Keyboard

Plug the keyboard cable into the keyboard socket on the rear panel.




Connecting the Monitor

Plug the monitor signal cable into the VGA connector on the rear panel.



Connecting the Mouse


Plug the mouse cable into the mouse connector on the rear panel.



10 Chapter 1 Getting Started

Connecting the Printer (optional)


Check your printer before you connect it to your system. If you have a parallel printer, connect it to the parallel port on the rear panel.



If you have a serial printer or other serial peripheral, connect it to the serial port (COM1). See “Rear Panel” on page 6 for the location of the serial ports.


Connecting Multimedia Components

Your system also supports optional multimedia features. Connect the multimedia components as shown below:




Connecting to the Network (optional)

Your system may come with a LAN (Local Area Network) card for network connection. To connect your system to the network, plug the network cable into the card's network port.



Connecting the Fax/Modem (optional)

Your system may also come with a fax/modem. To activate it, connect the telephone line and handset to the fax/modem ports as shown below:




12 Chapter 1 Getting Started

Connecting USB Devices (optional)

The USB ports on the rear panel enable the system to support additional serial devices without using up your system resources.

To connect a USB device, simply plug the device cable into a USB port on the rear panel.




Note: Most USB devices have a built-in USB port which allows you to daisy-chain other devices.

Turning On Your Computer


After you have connected all peripherals and cables, follow these steps to turn on your computer:

1. Turn on all peripherals connected to the system such as the monitor, printer, fax, speakers, etc.
2. Locate the system main power switch on the back of the system and turn it on.



3. Press the power button located on the front of the system unit.

When the system finishes booting, the computer is now ready for use.





Turning Off Your Computer

1. Turn off all peripherals connected to the system such as the monitor, printer, fax, speakers, etc.
2. Press the power button located on the front of the system unit for at least four seconds. Quickly pressing the button puts the system in Suspend mode only.






Note: You do not need to turn off the system main power switch on the rear panel every time you turn off your computer.

Turn off the system main power switch only:

- if you will not use your system for a long period of time.
- if you need to open your system for any purpose, such as troubleshooting or upgrading.

If the system main power switch is not available, you must unplug the system.



Troubleshooting

If you encounter a hardware problem, we recommend you to review the following suggestions before calling for service:

General failure

- ☐ Are all cables securely plugged?
- ☐ Are all system components and peripherals turned on?
- ☐ Is the system main power switch on?
- ☐ Is the power outlet burned out? You may check this by plugging in and turning on some other piece of equipment.
- ☐ Are any cables damaged? Are they properly routed and coiled? Entwined cables may cause signal interference.

Front panel light doesn't work

- ☐ After turning off the computer, check inside the system unit and make sure that the front panel LED connector for the LED that is not working is correctly plugged. Refer to "Jumpers and Connectors" on page 28 to identify the proper LED connector.

"Garbage" or nothing appears on the screen

- ☐ Is the monitor turned on? Is the screen brightness adjusted properly?



.....
Warning! Never open the monitor case. The CRT monitor retains very high voltage levels even after the power is turned off. Refer all monitor service to qualified service technicians.

Keyboard is dead

- ☐ Is the keyboard cable plugged in? Turn off the system and plug in the keyboard.



.....
Caution: Do not plug or unplug the keyboard while the power is on.

Printer doesn't work

- ☐ Is the printer power turned off?



16 Chapter 1 Getting Started






- ☐ Is the printer cable connected to the correct port (serial or parallel)?
- ☐ Are your application and the printer configured for the same operating values? Be sure there is no conflict with any port on the add-on card. For details, check the documentation that came with your printer.
- ☐ Is the printer out of paper or jammed? Check the printer's status indicator lights.
- ☐ Are the printer cables tangled? To prevent signal interference, neatly fold or coil excess cable length.

Add-on card fails intermittently

- ☐ Do two add-on cards have conflicting addresses? "PnP/PCI Options" on page 72 shows where you can see the addresses in the Setup Utility's Advanced Options. See "Entering Setup" on page 42 for instructions on entering the Advanced Level of the BIOS Utility.

If you receive an error message

- ☐ Read the corrective actions listed in "Error Messages" on page 17.





Error Messages

In the event that you receive an error message, do not continue using the computer. Note the message and take corrective action immediately. This section describes the different types of error messages and suggests corrective measures.

There are two general types of error messages:

- ☐ Software
- ☐ System

Software Error Messages

Software error messages are returned by your operating system or application. These messages typically appear after you boot the operating system or when you run your applications. If you receive this type of message, consult your application or operating system manual for help.

System Error Messages

A system error message indicates a problem with the computer itself. These messages normally appear during the power-on self-test, before the operating system prompt appears.

The table below lists the system error messages.

Error Message	Corrective Action
Memory Error at MMMM:SSSS:0000h (R:xxxxh, W:xxxxh)	Replace the DIMMs.
System Management Memory Bad	Replace the DIMMs.
Keyboard Interface Error	Check the keyboard interface circuit or change the keyboard.
Keyboard Error or Keyboard Not Connected	Reconnect or replace the keyboard.

18 Chapter 1
Getting Started

Error Message	Corrective Action
Pointing Device Error	Reconnect or replace the pointing device.
Pointing Device Interface Error	Check the pointing device interface circuit.
Pointing Device IRQ Conflict	Enter Setup and change the IRQ setting of the PS/2 mouse.
IDE Drive 0 Error IDE Drive 1 Error IDE Drive 2 Error IDE Drive 3 Error	Replace the disk drive or the HDD (hard disk drive) controller. Check the HDD cable connections and IDE settings in Setup.
IDE Drive 0 / 1 / 2 / 3 Auto Detection Failed	Replace the disk drive or the hard disk drive controller. Check the HDD cable connections and IDE settings in Setup.
Floppy Drive A Error Floppy Drive B Error	Check if there is no floppy disk in the drive. If there is, turn off the system and check the cable connections. If the connections are okay and the error message continues to show, replace the floppy drive.
Floppy Disk Controller Error	Check the floppy drive cable and its connections. If the cable is good and properly connected, the floppy disk controller may be the problem. Change the floppy disk controller or disable the onboard controller by installing another add-on card with a controller.
CPU Clock Mismatch	When the user changes the CPU frequency, this message will be shown once. Then the BIOS will adjust the CPU clock automatically.
Serial Port Conflict	Change the onboard serial port address in Setup or change the add-on card serial port address.

Error Message	Corrective Action
Parallel Port Conflict	Change the onboard parallel port address in Setup or the parallel port address of the add-on card.
Real-time Clock error	Check the RTC circuit or replace the battery.
CMOS Battery Bad	Replace the onboard lithium battery.
CMOS Checksum Error	Run Setup again and reconfigure the system.
Onboard XXX... Conflicts	Try to reassign or disable onboard device resources.
PCI Device Error	Check the PCI card. Replace it if bad.
System Resource Conflict	Run Setup to reconfigure the system.
IRQ Setting Error	Run Setup to reconfigure the system.
Expansion ROM Address Allocation Fail	Change the I/O expansion ROM address.

Correcting Error Conditions

As a general rule, the "Press F1 to continue" error message is caused by a configuration problem which can be easily corrected. An equipment malfunction is more likely to cause a fatal error, i.e., an error that causes complete system failure.

Here are some corrective measures for error conditions:

1. Run Setup. You must know the correct configuration values for your system before you enter Setup, which is why you should write these values down when the system is correctly configured. An incorrect Setup configuration is a major cause of power-on error messages, especially for a new system.
2. Remove the system cover according to the directions in the system housing installation guide. Check that the system board and any expansion boards are set correctly.



20 Chapter 1 Getting Started



3. Check that all connectors and boards are secure. Consult the system housing installation guide for assistance.

If you have purchased a new hard disk drive and your computer cannot detect it or access it after installing it, it may be because your disk is not physically formatted. Physically format the disk using the FDISK and FORMAT commands.






Caution: These commands are performed in DOS environment. We recommend that you familiarize yourself with the DOS commands first before you format your hard disk.



If you follow the corrective steps above and still receive an error message, the cause may be an equipment malfunction.

If you are sure that your configuration values are correct and your battery is in good condition, the problem may lie in a damaged or defective chip. Contact an authorized service center for assistance.




Note: If you do not know how to contact an authorized service center, call your distributor.





System Board Information




Chapter 2





This system board is uniquely-designed to support not only the common features found in today's high-performance system boards, but the multimedia functions as well.

This chapter gives a detailed discussion of the board's components and features.



Features

This high-performance system board comes with the following components and features:

Components

- ☐ Intel Celeron processor with 128-KB second-level cache running at up to 366 MHz
- ☐ Two double in-line memory module (DIMM) sockets that accept 8-, 16-, 32-, 64-, and 128-MB Synchronous Dynamic Random Access Memory (SDRAM) modules, allowing memory upgrade of up to 256 MB
- ☐ Peripheral Component Interface (PCI) bus Integrated Device Electronics (IDE) controller
- ☐ 3-D Super AGP video accelerator with 8-MB shared-frame buffer, embedded in the North Bridge controller
- ☐ Audio controller
- ☐ One Wake-on LAN (WOL) connector
- ☐ One Modem ring-in connector
- ☐ Two PCI enhanced IDE interfaces that support up to four IDE devices
- ☐ External ports
 - ☐ PS/2 keyboard and mouse ports
 - ☐ One serial port
 - ☐ One parallel port that supports Standard Parallel Port (SPP)/Extended Capabilities Port (ECP)/Enhanced Parallel Port (EPP) modes
 - ☐ Two Universal Serial Bus (USB) ports
- ☐ Three PCI slots






24 Chapter 2 System Board Information




Features

- ☐ Plug-and-Play
- ☐ Desktop Management Interface (DMI) support
- ☐ Advanced Configuration and Power Interface (ACPI)-compliant BIOS
- ☐ Software Shutdown support for Windows 98
- ☐ Power Management
- ☐ USB support
- ☐ Hardware Monitoring




Board Layout

Your system board should look just like the following figure:



The following table lists the components that you will find on the system board:




No.	Component
1	USB ports
2	CPU temperature sensor connector
3	CPU socket
4	DIMM sockets
5	Turbo LED connector
6	Battery
7	Reset button connector
8	Power LED connector



26 Chapter 2
System Board Information








No.	Component
9	ATX power supply connector
10	HDD LED connector
11	Floppy disk drive connector
12	IDE 1 connector
13	IDE 2 connector
14	Intrusion alarm connector
15	Super I/O controller
16	System BIOS chip
17	Power button connector
18	South bridge controller
19	Wake-on LAN connector
20	Modem ring-in connector
21	PCI slots
22	Voice modem connector
23	Audio controller
24	CD-in connector
25	Microphone-in connector
26	Line-in connector
27	Line-out connector
28	Game/MIDI port
29	VGA port
30	Parallel port






No.	Component
31	COM 2 port
32	PS/2 keyboard port
33	PS/2 mouse port
34	COM 1 connector
35	Speaker connector
36	PC speaker connector
37	3-pin CPU fan connector
38	2-pin CPU fan connector
39	North bridge controller



Jumpers and Connectors

Refer to the following figure for the location of the jumpers and connectors on the system board:



The following table lists the onboard jumpers, their respective functions and possible settings:

Jumper	Function and Settings
JP2	CPU/DRAM Frequency 1-2, 4-5 100/100 MHz 2-3, 5-6 66/100 MHz (default)
JP6	Password Check 1-2 Check password 2-3 Bypass password (default)

The following table lists the onboard connectors and their respective functions:




Connector	Function
CN2	USB
CN3	Upper port: mouse; Lower port: keyboard
CN4	COM 1
CN5	Upper: parallel/printer; Lower left: COM 2; Lower right: VGA
CN6	ATX power
CN7	Speaker
CN8	Hard disk drive (HDD) light emitting diode (LED)
CN9	PC speaker
CN10	Upper: game/MIDI; Lower left: line-out ; Lower center: line-in, Lower right: microphone-in
CN11	IDE 2
CN12	IDE 1
CN13	Floppy disk drive (FDD)
CN17	CPU temperature sensor
CN18	Intrusion alarm
CN19	Voice modem
CN20	Modem ring-in
CN21	CD-in
CN22	Wake-on LAN (WOL)
CN23	Power button



30 Chapter 2
System Board Information



Connector	Function
CN24	Reset button
CN25	Turbo LED
DIMM 1, DIMM 2	Memory module sockets
FN1	3-pin CPU fan
FN2	2-pin CPU fan
JP5	Power LED








Floppy Disk / Hard Disk Support

The board comes with an enhanced PCI IDE controller that supports PIO mode 4 and Ultra DMA (Direct Memory Access) mode data transfers. Two PCI IDE interfaces are mounted on board to enable the system to support a maximum of four IDE hard disks, or any other IDE devices. See “Jumpers and Connectors” on page 28 for the location of the IDE interfaces.

Connect the cables according to the IDE hard disk configuration listed in the table below. Follow the instructions in the housing installation manual on how to install a hard disk in the system.

IDE Connector	Master	Slave
IDE 1 (CN12)	Hard disk 0	Hard disk 1
IDE 2 (CN11)	Hard disk 2/IDE CD-ROM	Hard disk 3








32 Chapter 2
System Board Information

Video Function

The system board comes with a 3-D super AGP video accelerator embedded in the North bridge controller. The AGP bus architecture is considered to be the best solution for 3-D applications because it offers greater bandwidth, which is capable of speeding up the VGA bus to meet the requirements of 3-D applications.








Audio Function

For audio solution, the board comes with a PCI-based audio controller and the following ports (CN10):

- ☐ Mono microphone port
- ☐ Stereo line-in port
- ☐ Stereo line-out port
- ☐ Game/MIDI port

These connectors enable the system to accommodate external audio devices. For instructions on how to connect the external audio devices, see “Connecting Multimedia Components” on page 10.







USB Support

USB is a new serial bus design that is capable of cascading low and medium-speed peripherals (less than 12 Mbps) such as a keyboard, mouse, joystick, scanner, printer and modem/ISDN. With USB, complex cable connections at the back panel of your PC can be eliminated.

The board comes with two USB ports (CN2). See “Jumpers and Connectors” on page 28 for the location of the ports.









Hardware Monitoring Function

The Hardware Monitoring function allows you to check the system resources, either locally or in a computer network, by using software such as Acer ADM (Advanced Desktop Management). Acer ADM is a desktop management program that offers SMART (System Monitoring Analysis and Reporting Technology) for checking local or network connected systems. In addition, it also enables the PC hardware and applications to be OS (operating system) independent.




To enable the Hardware Monitoring function, you need to install Acer ADM. Contact your dealer for information on the availability of the software. Refer to the software documentation for more details on the Hardware Monitoring function.





Modem Ring-in Function

The Modem Ring-in function enables the system to resume from suspend mode by monitoring the fax/modem (or any device of similar type) activities. Any signal or activity detected from the Modem ring-in connector automatically returns the system to normal operation. Refer to “Jumpers and Connectors” on page 28 for the location of the Modem ring-in connector (CN20) on the system board.








Wake-on LAN



The Wake-on LAN (WOL) feature is a special feature that allows the system to be activated by a network connection via the onboard WOL connector (CN22). Aside from WOL, common network functions such as remote access, file sharing, etc. are also supported.




Refer to “Jumpers and Connectors” on page 28 for the location of the WOL connector (CN22) on the system board.






38 Chapter 2
System Board Information








BIOS Information

Chapter 3





This chapter contains detailed discussion about the BIOS utility. You will need this information for reconfiguring your system or for resetting your system back to its original settings in case you have reconfigured it improperly.







The BIOS Utility is a hardware configuration program built into your system's Basic Input/Output System (BIOS).

Since most systems are already properly configured and optimized, there is no need to run this utility. However, if you encounter configuration problems and get the "Run Setup" message, you will need to run this utility.

Before you run Setup, make sure that you have saved all open files. The system reboots immediately after you exit Setup.



.....
Note: If you repeatedly receive Run Setup messages, the battery may be bad. In this case, the system cannot retain configuration values in CMOS. Ask a qualified technician for assistance.





Entering Setup

To enter Setup, press the key combination **Ctrl-Alt-Esc**.



Important! You must press **Ctrl-Alt-Esc** simultaneously while the system is booting. This key combination does not work during any other time.


The Setup Utility main menu then appears:

Setup Utility
<ul style="list-style-type: none">• System Information• Product Information• Disk Drives• Onboard Peripherals• Power Management• Boot Options• Date and Time• System Security
Load Default Settings Abort Settings Change
↑↓ = Move Highlight Bar, ←→ = Select, Esc = Exit

The system supports two BIOS Utility levels: Basic and Advanced. The above screen is the BIOS Utility Basic Level screen. It allows you to view and change only the basic configuration of your system.

If you are an advanced user, you may want to check the detailed configuration of your system. Detailed system configurations are contained in the Advanced Level. To view the Advanced Level, press the **F8** key.

The following screen shows the Setup Utility Advanced Level main menu:




Note: The F8 key works only when you are in the main menu. This means that you can activate the Advanced Level only when you are in the main menu. Also, items marked by an (*) are only visible in the Advanced Level.

The command line at the bottom of the menu tells you how to move within a screen and from one screen to another.

- ☐ To select an option, move the highlight bar by pressing ↓ or ↑ then press **Enter**.
- ☐ Press **PgDn** to move to the next page or **PgUp** to return to the previous page.
- ☐ To change a parameter setting, press ← or → until the desired setting is found.
- ☐ Press **Esc** to return to the main menu. If you are already in the main menu, press **Esc** again to exit Setup.

The parameters on the screens show default values. These values may not be the same as those in your system.

The grayed items on the screens have fixed settings and are not user-configurable.



44 Chapter 3 BIOS Information



System Information

The following screen appears if you select System Information from the main menu:

System Information		Page 1/2
Processor.....	Celeron™	
Processor Speed.....	366 MHz	
Internal Cache Size.....	32 KB, Enabled	
External Cache Size.....	128KB, Enabled	
Floppy Drive A.....	1.44 MB, 3.5-inch	
Floppy Drive B.....	None	
IDE Primary Channel Master.....	Hard Disk, 6180 MB	
IDE Primary Channel Slave.....	None	
IDE Secondary Channel Master.....	None	
IDE Secondary Channel Slave.....	None	
Total Memory.....	64 MB	
1st Bank.....	SDRAM, 32 MB	
2nd Bank.....	SDRAM, 32 MB	
PgDn/PgUp = Move Screen, Esc = Back to Main Menu		


The following screen shows page 2 of the System Information menu:

System Information		Page 2/2
Serial Port 1.....	3F8h, IRQ 4	
Serial Port 2.....	2F8h, IRQ 3	
Parallel Port.....	378h, IRQ 7	
PS/2 Mouse.....	Installed	
PgDn/PgUp = Move Screen, Esc = Back to Main Menu		

These pages show the current basic configuration of your system.

The following table describes the parameters found in the System Information pages:





Parameter	Description	Format
Processor	Specifies the type of processor currently installed in your system.	
Processor Speed	Specifies the speed of the processor currently installed in your system.	Speed in MHz
Internal Cache Size	Specifies the first-level or the internal memory (i.e., the memory integrated into the CPU) size, and whether it is enabled or disabled.	Cache size in KB
External Cache Size	Specifies the second-level cache memory size currently supported by the system.	Cache size in KB
Floppy Drive A	Shows the floppy drive A type.	Capacity, dimension
Floppy Drive B	Shows the floppy drive B type.	Capacity, dimension
IDE Primary Channel Master	Specifies the current configuration of the IDE device connected to the master port of the primary IDE channel.	Drive type, capacity
IDE Primary Channel Slave	Specifies the current configuration of the IDE device connected to the slave port of the primary IDE channel.	Drive type, capacity



46 Chapter 3
BIOS Information




Parameter	Description	Format
IDE Secondary Channel Master	Specifies the current configuration of the IDE device connected to the master port of the secondary IDE channel.	Drive type, capacity
IDE Secondary Channel Slave	Specifies the current configuration of the IDE device connected to the slave port of the secondary IDE channel.	Drive type, capacity
Total Memory	Specifies the total amount of onboard memory. The memory size is automatically detected by BIOS during the POST. If you install additional memory, the system automatically adjusts this parameter to display the new memory size.	Memory size in MB
1st Bank	Indicates the type of DRAM installed in the DIMM 1 socket. The None setting indicates that there is no DRAM installed.	DIMM type, capacity in MB
2nd Bank	Indicates the type of DRAM installed in the DIMM 2 socket. The None setting indicates that there is no DRAM installed.	DIMM type, capacity in MB
Serial Port 1	Shows the serial port 1 address and IRQ settings.	Address, IRQ
Serial Port 2	Shows the serial port 2 address and IRQ settings.	Address, IRQ
Parallel Port	Shows the parallel port address and IRQ settings.	Address, IRQ





Parameter	Description	Format
PS/2 Mouse	Indicates if there is a mouse connected to your system. This is automatically detected by BIOS.	Displays Installed if there is a mouse detected; otherwise, it displays None.



Product Information

The screen below appears if you select Product Information from the main menu:

Product Information	
Product Name.....XXXXXXXXXX
System S/N.....XXXXXXXXXX
Main Board ID.....XXXXXXXXXX
Main Board S/N.....XXXXXXXXXX
System BIOS Version.....VX.XX
DMI BIOS Version.....X.XX.X

Esc = Back to Main Menu F1 = Help

The Product Information menu contains general data about the system, such as the product name, serial number, BIOS version, etc. This information is necessary for troubleshooting (may be required when asking for technical support).

The following table describes the parameters found in this menu:

Parameter	Description
Product Name	Displays the model name of your system
System S/N	Displays your system's serial number
Main Board ID	Displays the system board's identification number
Main Board S/N	Displays your system board's serial number
System BIOS Version	Specifies the version of your BIOS utility



Parameter	Description
DMI BIOS version	Specifies the version of the DMI BIOS utility installed in your system. The Desktop Management Interface (DMI) BIOS allows you to check your system hardware components without actually opening your system. Hardware checking is done via software during start up.

Disk Drives

Select Disk Drives from the main menu to configure the drives installed in your system.

The following screen shows the Disk Drives menu:

Disk Drives	
Floppy Drive A.....	[xx-MB, x.xx-inch]
Floppy Drive B.....	[None]
LS-120 drive as.....	[Normal]
<ul style="list-style-type: none"> • IDE Primary Channel Master • IDE Primary Channel Slave • IDE Secondary Channel Master • IDE Secondary Channel Slave 	
↑↓ = Move Highlight Bar F1 = Help Esc = Exit →← = Change Setting	


The following table describes the parameters found in this menu. Settings in **boldface** are the default and suggested settings.

Parameter	Description	Options
Floppy Drive A / B	Allows you to configure your floppy drive	None 360 KB, 5.25-inch 1.2 MB, 5.25-inch 720 KB, 3.5-inch 1.44 MB, 3.5-inch 2.88 MB, 3.5-inch
LS-120 drive as	Allows you to enable the LS-120 device installed in your system and to specify the function of the device. The setting affects how BIOS will detect the device.	Normal Drive A Drive B Hard Disk
IDE Primary Channel Master	Lets you configure the hard disk drive connected to the master port of IDE channel 1.	

Parameter	Description	Options
IDE Primary Channel Slave	Lets you configure the hard disk drive connected to the slave port of IDE channel 1.	
IDE Secondary Channel Master	Lets you configure the hard disk drive connected to the master port of IDE channel 2.	
IDE Secondary Channel Slave	Lets you configure the hard disk drive connected to the slave port of IDE channel 2.	

The following screen appears if you select any of the IDE Drive parameters:

IDE Primary/Secondary Channel Master/Slave	
Type.....	[Auto]
Cylinder.....	[xxxx]
Head.....	[xxxx]
Sector.....	[xxxx]
Size.....	[XXXX] MB
Hard Disk Size > 504 MB.....[Auto]	
*Hard Disk Block Mode.....	[Auto]
*Advanced PIO Mode.....	[Auto]
*Hard Disk 32-bit Access.....	[Enabled]
*DMA Transfer Mode.....	[Auto]
.	
↑↓ = Move Highlight Bar	F1 = Help
Esc = Exit	→← = Change Setting






52 Chapter 3

BIOS Information



The following table describes the parameters found in this menu. Settings in **boldface** are the default and suggested settings.

Parameter	Description	Options
Type	Lets you specify the type of hard disk installed in your system. If you want BIOS to automatically configure your hard disk, select Auto . If you know your hard disk type, you can enter the setting manually. Setting this parameter also sets the Cylinder, Head, Sector, and Size parameters.	Auto , None, or User. The User setting allows you to enter your settings manually if you know your hard disk type. The Auto setting also sets the Cylinder, Head, Sector, and Size parameters.
Cylinder	Specifies your hard disk's number of cylinders, and is automatically set depending on your Type parameter setting.	
Head	Specifies your hard disk's number of heads, and is automatically set depending on your Type parameter setting.	
Sector	Specifies your hard disk's number of sectors, and is automatically set depending on your Type parameter setting.	
Size	Specifies the size of your hard disk, in MB, and is automatically set depending on your type parameter setting.	
Hard Disk Size > 504 MB	Enables your system to support hard disks with capacities more than 504 MB.	Auto or Disabled



Parameter	Description	Options
Hard Disk Block Mode	Enhances your hard disk performance by allowing data transfer in blocks (multiple sectors) at a rate of 256 bytes per cycle. This parameter appears only in the Advanced Level.	Auto or Disabled
Advanced PIO Mode	Improves your hard disk performance by allowing faster data recovery and read/write timing; thus, it reduces the hard disk's activity time. This parameter appears only in the Advanced Level.	Auto or Mode 0 to 4
Hard Disk 32-bit Access	Improves your hard disk performance by allowing the use of the 32-bit hard disk access. This parameter appears only in the Advanced Level.	Enabled or Disabled
DMA Transfer Mode	Lets you enable the Ultra DMA and Multi-DMA modes to enhance your hard disk performance. This parameter appears only in the Advanced Level.	Auto , Multi Mode 0 to 2, or Ultra Mode 0 to 2

Onboard Peripherals


The Onboard Peripherals menu allows you to configure the onboard devices. Selecting this option from the main menu displays the following screen:

Onboard Peripherals	
Serial Port 1.....	[Enabled]
Base Address.....	[3F8h]
IRQ.....	[4]
Serial Port 2.....	[Enabled]
Base Address.....	[2F8h]
IRQ.....	[3]
Parallel Port.....	[Enabled]
Base Address.....	[378h]
IRQ.....	[7]
Operation Mode.....	[Bi-directional]
ECP DMA Channel.....	[-]
• Onboard Device Settings	
↑↓ = Move Highlight Bar F1 = Help	
Esc = Exit →← = Change Setting	

The following table describes the parameters found in this menu. Settings in **boldface** are the default and suggested settings.

Parameter	Description	Options
Serial Port 1 / 2	Let you enable or disable the serial ports.	Enabled or Disabled
Base Address	Lets you set a logical base address for each serial port. This parameter is configurable only if the Serial Port parameter is enabled.	3F8h (for serial port 1), 2F8h (for serial port 2), 2E8h, 3E8h
IRQ	Lets you assign an interrupt for each serial port. This parameter is configurable only if the Serial Port parameter is enabled.	4 or 11 (for serial port 1), 3 or 10 (for serial port 2)

Parameter	Description	Options
Parallel Port	Lets you enable or disable the parallel port.	Enabled or Disabled
Base Address	Lets you set a logical base address for the parallel port. This parameter is configurable only if the Parallel Port parameter is enabled.	3BCh, 378h , 278h
IRQ	Lets you assign an interrupt for the parallel port. This parameter is configurable only if the Parallel Port parameter is enabled.	5 or 7
Operation Mode	Lets you set your parallel port's operation mode. This parameter is configurable only if the Parallel Port parameter is enabled.	Standard Parallel Port (SPP), Bidirectional , Enhanced Parallel Port (EPP), Extended Capabilities Port (ECP)
ECP DMA Channel	Allows you to assign a DMA channel for the ECP parallel port function. This parameter is configurable only if you select the Extended Capabilities Port (ECP) as the operation mode.	1 or 3
Onboard Device Settings	Allows you to configure the device controllers available on board. Selecting this option displays the Onboard Device Settings sub-menu.	



Onboard Device Settings

The following screen shows the Onboard Device Settings sub-menu:

Onboard Device Settings	
Floppy Disk Controller.....	[Enabled]
IDE Controller.....	[Both]
PS/2 Mouse Controller.....	[Enabled]
USB Host Controller.....	[Enabled]
USB Legacy Mode.....	[Disabled]
Onboard Audio Chip.....	[Enabled]
↑↓ = Move Highlight Bar F1 = Help	
Esc = Exit →← = Change Setting	

The following table describes the parameters found in this sub-menu. Settings in **boldface** are the default and suggested settings.

Parameter	Description	Options
Floppy Disk Controller	Lets you enable or disable the onboard floppy disk controller.	Enabled or Disabled
IDE Controller	Lets you enable or disable the onboard primary, secondary or both IDE interfaces.	Primary, Both , or Disabled
PS/2 Mouse Controller	Lets you enable or disable the onboard PS/2 mouse controller.	Enabled or Disabled
USB Host Controller	Lets you enable or disable the onboard USB host controller.	Enabled or Disabled



Parameter	Description	Options
USB Legacy Mode	Lets you activate or deactivate the USB keyboard connected to your system. When activated, the USB keyboard functions in a DOS environment.	Enabled or Disabled
Onboard Audio Chip	Lets you activate or deactivate the audio controller on board.	Enabled or Disabled

Power Management

The Power Management menu lets you configure the system power-management feature.

The following screen shows the Power Management parameters and their default settings:

Power Management	
Power Management Mode.....	[Enabled]
IDE Hard Disk Standby Timer.....	[Off] Minute(s)
System Sleep Timer.....	[Off] Minute(s)
Sleep Mode.....	[-----]
Power Switch < 4 Sec.....	[Power Off]
System Wake-Up Event	
Modem Ring Indicator.....	[Enabled]
↑↓ = Move Highlight Bar F1 = Help	
Esc = Exit →← = Change Setting	

The following table describes the parameters found in this menu. Settings in **boldface** are the default and suggested settings.

Parameter	Description	Options
Power Management Mode	Allows you to reduce the system's power consumption. When enabled, the IDE hard disk and system timers become configurable.	Enabled or Disabled
IDE Hard Disk Standby Timer	Allows the hard disk to enter Standby mode after inactivity of 1 to 15 minutes, depending on your setting.	1 to 15 minutes, or Off

Parameter	Description	Options
System Sleep Timer	Automatically puts the system to power-saving mode after a specified period of inactivity. Any keyboard or mouse action, or any activity detected from the IRQ channels resumes system operation.	2, 5, 10, 15, 20, 30, 40, 50...120 minutes, or Off
Sleep Mode	Lets you specify the power-saving mode that the system will enter after a specified period of inactivity. This parameter is configurable only if the System Sleep Timer is enabled.	Standby or Suspend
Power Switch < 4 sec.	Lets you specify whether to automatically turn off the machine or put the system to Suspend mode when the power switch is pressed for less than 4 seconds.	Power Off or Suspend
System Wake-up Event	Lets you specify the activity that will resume the system to normal operation.	
Modem Ring Indicator	Wakes the system from Sleep mode once any fax/modem activity is detected.	Enabled or Disabled



Boot Options

This option allows you to specify your preferred settings for bootup.

The following screen appears if you select Boot Options from the main menu:

Boot Options	
Boot Sequence 1st [Floppy Disk] 2nd [Hard Disk] 3rd [IDE CD-ROM]	
First Hard Disk Drive.....	[IDE]
Primary Display Adapter.....	[Auto]
Fast Boot.....	[Auto]
Silent Boot.....	[Enabled]
Num Lock After Boot.....	[Enabled]
Memory Test.....	[Disabled]
*Configuration Table.....	[Enabled]
*Update BIOS with Boot Block.....	[Disabled]
↑↓ = Move Highlight Bar F1 = Help Esc = Exit →← = Change Setting	

The following table describes the parameters found in this menu. Settings in **boldface** are the default and suggested settings.

Parameter	Description	Options
Boot Sequence	Allows you to specify the boot search sequence.	Floppy Disk, Hard Disk, IDECD-ROM
First Hard Disk Drive	Specifies whether the BIOS utility will boot from an IDE hard disk or a SCSI hard disk drive.	IDE or SCSI
Primary Display Adapter	Lets you activate the onboard video controller as your primary display adapter, or automatically disable it once BIOS detects that there is a video card installed in your system.	Onboard or Auto




Parameter	Description	Options
Fast Boot	Allows you to define your system's booting process, whether to skip some POST routines or proceed with the normal booting process.	Auto or Disabled
Silent Boot	When enabled, BIOS is in graphical mode and displays only an identification logo during POST and while booting. Then, the screen displays the operating system prompt (as in DOS) or logo (as in Windows 95). If any error occurs while booting, the system automatically switches to the text mode. You may also switch to the text mode while booting by pressing F9 after you hear a beep that indicates the activation of the keyboard.	Enabled or Disabled
Num Lock After Boot	Allows you to activate or deactivate the Num Lock function upon booting.	Enabled or Disabled
Memory Test	Lets you specify whether you want BIOS to perform or bypass the RAM test during POST.	Enabled or Disabled



62 Chapter 3
BIOS Information



Parameter	Description	Options
Configuration Table	Allows you to enable or disable the display of the configuration table after POST but before booting. The configuration table gives a summary of the hardware devices and settings that BIOS detected during POST. This parameter appears only when you are in the Advanced Level.	Enabled or Disabled
Update BIOS with Boot Block	When enabled, it allows you to replace the existing BIOS in the Flash ROM by simply inserting the floppy disk containing the new BIOS into the floppy drive then resetting the system. After reset, the system will automatically read the BIOS file contained in the floppy disk (i.e., the first file in the disk) and replace the BIOS in the Flash ROM. If the update is successful, the system will automatically disable this parameter then shut down. This parameter appears only when you are in the Advanced Level.	Enabled or Disabled






Date and Time

The following screen appears if you select the Date and Time option from the main menu:

Date and Time	
Date.....	[WWW MMM DD, YYYY]
Time.....	[HH:MM:SS]
↑↓ = Move Highlight Bar Esc = Exit	F1 = Help →← = Change Setting

The following table describes the parameters found in this menu:

Parameter	Description	Options
Date	Lets you set the date following the weekday-month-day-year format.	Weekday: Sun, Mon, Tue, Wed, Thu, Fri, Sat Month: Jan, Feb...Dec Day: 1 to 31 Year: 1980 to 2079
Time	Lets you set the time following the hour-minute-second format.	Hour: 0 to 23 Minute: 0 to 59 Second: 0 to 59




System Security


The Setup program has a number of security features to prevent unauthorized access to the system and its data.

The following screen appears if you select System Security from the main menu:

System Security	
Setup Password.....	[None]
Power-on Password.....	[None]
Operation Mode.....	[Normal]
Disk Drive Control	
Floppy Drive.....	[Normal]
Hard Disk Drive.....	[Normal]
.	
↑↓ = Move Highlight Bar F1 = Help	
Esc = Exit →← = Change Setting	



The following table describes the parameters found in this menu. Settings in **boldface** are the default and suggested settings.



Parameter	Description	Options
Setup Password	Prevents unauthorized access to the BIOS utility.	None or Present. The Present setting allows you to set a Setup password. For instructions on how to set a Setup password, refer to "Setting a Password" on page 66.

Parameter	Description	Options
Power-on Password	Secures your system against unauthorized use. Once you set this password, you have to type it whenever you boot the system.	None or Present. The Present settings allows you to set a Power-on password. For instructions on how to set a Setup password, refer to "Setting a Password" on page 66.
Operation Mode	Lets you enable or disable the password prompt display. When set to Normal, the password prompt appears before system boot. When set to Keyboard Lock, the password prompt does not appear; however, your system will not respond to any keyboard or mouse input until you enter the correct password.	Normal or Keyboard Lock
Disk Drive Control	Allows you to protect your system's floppy drive and hard disk data from being modified (possible under DOS mode only).	
Floppy Drive	Protects your floppy drive data from being modified.	Normal , Write Protect All Sectors, Write Protect Boot Sectors
Hard Disk Drive	Protects your hard disk data from being modified.	Normal , Write Protect All Sectors, Write Protect Boot Sectors

Setting a Password

1. Make sure that **JP6** is set to **2-3** (bypass password).



.....
You cannot enter the BIOS utility if a Setup password does not exist and JP6 is set to 1-2 (password check enabled). By default, JP6 is set to 2-3 (bypass password).

2. Enter the BIOS utility and select System Security .
3. Highlight the Setup Password parameter to set a Setup password, or Power-on Password to set a Power-on password. Then press **←** or **→**. The following screen appears:

Setup Password	
Enter your new Setup Password twice. Setup Password may be up to 7 characters long.	
Enter Password.....	[xxxxxxxx]
Enter Password again.....	[xxxxxxxx]
Set or Change Password	
↑↓ = Move Highlight Bar F1 = Help	
Esc = Exit →← = Change Setting	

4. Type a password. The password may consist of up to seven characters. Then press **Enter**.



.....
***Note:** Be very careful when typing your password because the characters do not appear on the screen.*

5. Retype the password then press **Enter**.
6. After setting the password, highlight the Set or Change Password option.
7. Press **Esc** to return to the System Security screen.
8. Press **Esc** to return to the main menu.

9. Press **Esc** to exit the BIOS utility. A dialog box appears asking if you want to save the CMOS data.
10. Select **Yes** to save the changes and reboot the system.
11. After rebooting, turn off the system then open the housing.
12. Set **JP6** to **1-2** to enable the password function.

If you have set a Setup password, the next time you want to enter the BIOS utility, you must key-in your Setup password.

If you have set a Power-on password, you will be prompted to enter that password every time you boot your system.

Changing or Removing the Password

Should you want to **change one of your passwords**, do the following:

1. Enter the BIOS utility and select System Security.
2. Highlight the Setup Password parameter (for Setup password) or the Power-on Password parameter (for Power-on password). Then press **←** or **→**. The Password menu appears.
3. From the Password menu, highlight the Set or Change Password option.
4. Enter a new password.
5. Press **Esc** to return to the System Security screen.
6. Press **Esc** to return to the main menu.
7. Press **Esc** to exit the BIOS utility. A dialog box appears asking if you want to save the CMOS data.
8. Select **Yes** to save the changes.

To remove the password, simply select the Setup Password parameter (for Setup password) or the Power-on Password parameter (for Power-on password) from the System Security menu and set it to **None**.





Bypassing the Password

If you forget your password, you can bypass the password security feature by hardware. Follow these steps to bypass the password:

1. Turn off and unplug the system.
2. Open the system housing and set **JP6** to **2-3** to bypass the password function.
3. Turn on the system and enter the BIOS utility. This time, the system does not require you to type in a password.

You can either change the existing password or remove it by selecting **NONE**. Refer to “Changing or Removing the Password” on page 67 for the procedure.






Advanced Options




Note: The Advanced Options selection is available only in the Advanced Level.


The Advanced Options menu allows you to configure the system memory and PCI device settings.

The following screen shows the Advanced Options parameters:



Caution: Do not change any settings in the Advanced Options menu if you are not a qualified technician to avoid damaging the system.





Memory/Cache Options

Selecting Memory/Cache Options from the Advanced Options menu displays the following screen:

Memory/Cache Options	
Internal Cache (CPU Cache).....	[Enabled]
External Cache.....	[Enabled]
Cache Scheme.....	Write-back
Memory at 15MB-16MB Reserved for.....[System]	
C8000 - DFFFFh Shadow.....	[Disabled]

↑↓ = Move Highlight Bar	F1 = Help
Esc = Exit	→← = Change Setting

This menu lets you configure the system memory.

The following table describes the parameters found in this sub-menu. Settings in **boldface** are the default and suggested settings.

Parameter	Description	Options
Internal Cache (CPU Cache)	Lets you enable or disable the primary cache memory, i.e., the CPU memory.	Enabled or Disabled
External Cache	Lets you enable or disable the secondary cache memory.	Enabled or Disabled
Cache Scheme	This parameter is non-configurable and is always set to Write-back. The Write-back mode updates the cache but not the memory (write-back mode) when there is a write instruction.	Write-back

Parameter	Description	Options
Memory at 15MB-16MB Reserved for	To prevent memory address conflicts between the system and expansion boards, reserve this memory range for the use of either the system or an expansion board. Some VGA cards have required settings for this feature. Check your VGA card manual before setting this parameter.	System or Add-on card
C8000 - DFFFFh Shadow	Allows you to shadow an expansion card to ROM. For some legacy ISA LAN cards, you might need to disable shadowing for proper operation. In such case, we recommend that you set this parameter to Disabled.	Enabled or Disabled

PnP/PCI Options

The PnP/PCI Options allows you to specify the settings for your PCI devices. Selecting this option displays the following screen:

PnP/PCI Configuration				
PCI IRQ Setting.....	[Auto]			
	INTA	INTB	INTC	INTD
PCI Slot 1.....	[--]	[--]	[--]	[--]
PCI Slot 2.....	[--]	[--]	[--]	[--]
PCI Slot 3.....	[--]	[--]	[--]	[--]
PCI IRQ Sharing.....	[Yes]			
VGA Palette Snoop.....	[Disabled]			
Plug and Play OS.....	[Yes]			
Reset Resource Assignments.....	[No]			
↑↓ = Move Highlight Bar		F1 = Help		
Esc = Exit		→← = Change Setting		

The following table describes the parameters found in this sub-menu. Settings in **boldface** are the default and suggested settings.

Parameter	Description	Options
PCI IRQ Setting	Allows you to automatically or manually configure the Plug-and-Play (PnP) devices installed in your system. Refer to your device manual for technical information about the PCI card.	Auto or Manual
PCI Slot 1 / 2 / 3	Allow you to manually assign an interrupt for each PCI device installed in your system. When the PCI IRQ Settings is set to Auto, BIOS automatically assigns the available IRQs to the PCI devices.	
PCI IRQ Sharing	Allows you to assign the same IRQ to two different devices.	Yes or No

Parameter	Description	Options
VGA Palette Snoop	Enables the palette snooping feature if you installed more than one VGA card in the system, allowing the control palette register (CPR) to manage and update the VGA RAM DAC (Digital Analog Converter, a color data storage) of each VGA card installed in the system. The snooping process lets the CPR send a signal to all the VGA cards so that they can update their individual RAM DACs. The signal goes through the cards continuously until all RAM DAC data has been updated. This allows the display of multiple images on the screen. Some VGA cards have required settings for this feature. Check your VGA card manual before setting this parameter.	Enabled or Disabled
Plug and Play OS	Lets you specify whether BIOS will initialize only PnP boot devices such as SCSI cards, or all PnP boot and non-boot devices such as sound cards.	Yes or No
Reset Resource Assignments	When enabled, avoids IRQ conflict when installing non-PnP and PnP ISA cards. This clears all resource assignments and allows BIOS to reassign resources to all installed PnP devices the next time the system boots.	Yes or No After clearing the resource data, it is recommended that you reset the parameter to its default, i.e., No .





Load Default Settings

You need to reload the BIOS default settings every time you make changes to your system hardware configuration (such as memory size, CPU type, hard disk type, etc.); otherwise, BIOS will keep the previous CMOS settings. Selecting this option displays the following dialog box:

Do you want to load default settings?	
[Yes]	[No]

Choosing **Yes** enables BIOS to automatically detect the hardware changes that you have made in your system. This option also allows you to restore the default settings.

Choosing **No** returns you to the main menu without loading the default settings.








Abort Settings Change


Selecting the Abort Settings Change option from the main menu displays the following dialog box:

Do you want to abort settings change?	
[Yes]	[No]

Choosing Yes discards all the changes that you have made and reverts the parameters to their previously saved settings.

Choosing No returns you to the main menu. BIOS retains all changes that you have made.





Exiting Setup

To exit the BIOS utility, simply press **Esc**. The following dialog box appears:

Do you really want to exit SETUP?



[Yes] [No]




Select **Yes** to exit Setup. Select **No** to return to the main menu. If you have made changes in the parameter settings, the following dialog box appears:

Settings have been changed.
Do you want to save to CMOS settings?

[Yes] [No]


Select **Yes** to save your changes before you exit Setup. Select **No** to discard all changes and exit Setup.







Upgrading the System

Chapter 4





This chapter tells you how to remove and replace the system housing, and to install optional components to upgrade the system. It gives brief and clear instructions accompanied by mechanical illustrations showing how to perform each described procedure.





Installation Precautions

Before you install any system component, we recommend that you read the following sections. These sections contain important ESD precautions, pre- and post-installation instructions.

ESD Precautions

Electrostatic discharge (ESD) can damage your processor, disk drives, expansion boards, and other components. Always observe the following precautions before you install a system component.

1. Do not remove a component from its protective packaging until you are ready to install it.
2. Wear a wrist grounding strap and attach it to a metal part of the system unit before handling components. If a wrist strap is not available, maintain contact with the system unit throughout any procedure requiring ESD protection.

Preinstallation Instructions

Always observe the following before you install a system component:

1. Turn off the system power and all the peripherals connected to the unit before opening it.
2. Open the system according to the instructions in the housing installation manual.
3. Follow the ESD precautions on page 79 before handling a system component.
4. Remove any expansion boards or peripherals that block access to the DIMM sockets or CPU connector.
5. See the following sections for specific instructions on the component you wish to install.




Warning! Not turning off the system properly before you start installing the components may damage your system.

Do not attempt the procedures described in the following sections unless you are a qualified service technician.

Post-installation Instructions

Observe the following after installing a system component:

1. See to it that the components are installed according to the step-by-step instructions in their respective sections.
2. Make sure you have set all the required jumpers. Refer to “Jumpers and Connectors” on page 28 or to the label pasted inside the system for the correct jumper settings.



3. Replace any expansion boards or peripherals that you removed earlier.
4. Replace the system cover.
5. Connect the necessary cables and turn on the system.

Opening the System




Caution: Before you proceed, make sure that you have turned off the system and all peripherals connected to it. Read the preinstallation instructions on page 79.

This section tells you how to open the housing cover when you need to install additional components inside the system unit.


Removing the Housing Cover

1. Turn off the system power and unplug all cables.
2. Place the system unit on a flat, steady surface.
3. Remove the four screws from the rear panel. Set the screws aside. You will need them when replacing the housing cover.




82 Chapter 4 Upgrading the System

4. Push the housing cover slightly backward, then pull it upward to remove it from the chassis.







Replacing the Housing Cover


1. Replace the housing cover.





2. Secure the housing cover with the necessary screws.








Installing Additional Memory

The system memory is upgradeable to a maximum of 256 MB via two 168-pin DIMM sockets on board. These DIMM sockets accept PC-100 compliant DIMMs with 8-, 16-, 32-, 64-, and 128-MB capacities. See “Board Layout” on page 25 for the location of the DIMM sockets. For instructions on how to install DIMMs, refer to “Installing a DIMM” on page 86.


The following table lists the possible memory configurations:

DIMM 1	DIMM 2	Total Memory
8 MB	None	8 MB
16 MB	None	16 MB
32 MB	None	32 MB
64 MB	None	64 MB
128 MB	None	128 MB
None	8 MB	8 MB
None	16 MB	16 MB
None	32 MB	32 MB
None	64 MB	64 MB
None	128 MB	128 MB
8 MB	8 MB	16 MB
8 MB	16 MB	24 MB
8 MB	32 MB	40 MB
8 MB	64 MB	72 MB
8 MB	128 MB	136 MB
16 MB	8 MB	24 MB






DIMM 1	DIMM 2	Total Memory
16 MB	16 MB	32 MB
16 MB	32 MB	48 MB
16 MB	64 MB	80 MB
16 MB	128 MB	144 MB
32 MB	8 MB	40 MB
32 MB	16 MB	48 MB
32 MB	32 MB	64 MB
32 MB	64 MB	96 MB
32 MB	128 MB	160 MB
64 MB	8 MB	72 MB
64 MB	16 MB	80 MB
64 MB	32 MB	96 MB
64 MB	64 MB	128 MB
64 MB	128 MB	192 MB
128 MB	8 MB	136 MB
128 MB	16 MB	144 MB
128 MB	32 MB	160 MB
128 MB	64 MB	192 MB
128 MB	128 MB	256 MB



Installing a DIMM

Installing a DIMM


1. Open the clips on the socket.
2. Align the DIMM with the socket.
3. Press the DIMM into the socket until the clips lock into the DIMM.



Note: The DIMM socket is slotted to ensure proper installation. If you insert a DIMM but it does not fit easily into the socket, you may have inserted it incorrectly. Turn the DIMM around and try to insert it again.

Removing a DIMM

1. Press the holding clips on both sides of the socket outward to release the DIMM.
2. Gently pull the DIMM out of the socket.



Reconfiguring the System

The system automatically detects the amount of memory installed. Run Setup to view the new value for total system memory and make a note of it.

Upgrading the CPU

Removing the CPU




Note: Observe the ESD precautions on page 79 when installing or removing a system component.

Before you can replace or upgrade your processor, you need to remove the previously installed processor on the system board.


Follow these steps to remove the CPU:

1. On the system board, locate the CPU mounted on the socket.
2. Detach the fan/heatsink cable connector.



3. Remove the fan/heatsink from the CPU.
4. Pull up the socket lever. The CPU pins will be automatically released from the socket holes.

5. Pull out the CPU from the socket.



Installing the Upgrade CPU




Note: Observe the ESD precautions on page 79 when installing or removing a system component.


Before you proceed, make sure that there is no CPU installed in the CPU socket.

Follow these steps to install the upgrade CPU:


1. Pull up the socket lever.
2. Insert the CPU, making sure that pin 1 (indicated by a notched corner of the CPU) connects to hole 1 of the socket.
3. Pull down the socket lever to lock the CPU into the socket.



4. Attach the heatsink and fan to the CPU.



5. Plug the fan/heatsink cable to the fan connector marked FN1 (for 3-pin connector) or FN2 (for 2-pin connector). See “Jumpers and Connectors” on page 28 for the location of the connectors on the system board.




Warning! The heatsink becomes very hot when the system is on. Never touch the heatsink with any metal or with your hands.


Replacing the Hard Disk

Follow these steps to replace the hard disk drive:

1. Disconnect all cables connected to the hard disk and 3.5-inch floppy disk drives.




2. Remove the 3.5-inch drive frame from the housing by pressing the tab on top and pivoting the frame outward.




3. Remove the four screws that hold the hard disk to the drive frame.

4. Pull out the hard disk drive.




5. Install a new 3.5-inch hard disk drive and secure it with the four screws that you have removed previously.




6. Reinstall the frame into the housing as in the following figure:
 - a. Align the frame with the notch.

94 Chapter 4
Upgrading the System

- b. Pivot the frame toward the housing until the tab clicks into place.



7. Connect the disk drive cables and power cables.




Make sure that the other ends of the floppy disk drive cables are connected to their corresponding connectors on the system board.

Installing and Removing a PCI Card

Installing a PCI Card

1. Locate an empty PCI slot on the system board.
2. Remove the bracket on the housing opposite the selected empty PCI slot.
3. Remove the PCI card from its protective packaging.
4. Align then insert the PCI card into the slot. Make sure that the card is properly seated.
5. Secure the card to the housing with a screw.

When you turn on the system, BIOS automatically detects and assigns resources to the PCI devices.









Removing a PCI Card

To remove a PCI card, simply reverse the instructions listed under the "Installing a PCI Card" section.



96 Chapter 4
Upgrading the System



Index

Symbols

. 43

A

abort settings change 75

ACPI 24

Advanced level 42

Advanced Options 69

 PnP/PCI 72

AGP 3

audio function 33

 controller 33

 ports 33

B

Basic level 42

BIOS utility 41–76

board layout 25

Boot Options 60

 boot sequence 60

 configuration table 62

 fast boot 61

 first hard disk drive 60

 memory test 61

 Num Lock after boot 61

 primary display adapter 60

 silent boot 61

 update BIOS with boot block 62

C

C8000-DFFFh Shadow 71

computer

 performance 23

connecting components 8

 fax 11

 keyboard 8

 modem 11

 monitor 9

 mouse 9

 network 11

 printer 10

connectors 28, 29

CPU upgrade 88

 installing 90

 removing 88

D

Date and Time 63

default values 43

Desktop Management Interface 24

DIMM 23

DIMM installation 86

DIMM removal 87

Disk Drives

 sector 52

Disk Drives 50

 advanced PIO mode 53

 cylinder 52

 DMA transfer mode 53

 floppy drives A/B 50

 Hard disk 32-bit access 53

 Hard disk block mode 53

 Hard disk size > 504 MB 52

 head 52

 IDE primary channel master 50

 IDE primary channel slave 51

 IDE secondary channel master 51

 IDE secondary channel slave 51

 LS-120 drive as 50

 size 52

 type 52

DMI 24

E

entering Setup 42

error messages 17

 correcting 19

 hardware 17

 software 17

 system 17

ESD precautions 79

exit Setup 76

expansion slots 23

F

F8 43

FDD/hard disk support 31

features 5

 front panel 5

 rear panel 6

H

Hardware Monitoring 35

Hardware monitoring 24

I

- installation precautions 79
 - post-installation 80
 - preinstallation 79
- installing and removing add-on cards
 - installing a PCI card 95

J

- jumper settings 28
- jumpers 28

K

- key 43

L

- Load default settings 74

M

- main menu 42
- Memory at 15MB - 16MB reserved for 71
- Memory Cache Options
 - cache scheme 70
 - external cache 70
 - internal cache 70

MIDI 3

- modem ring-in 36

O

- Onboard Device Settings 55
 - floppy disk controller 56
 - IDE controller 56
 - onboard audio chip 57
 - PS/2 mouse controller 56
 - USB host controller 56
 - USB legacy mode 57

Onboard Peripherals 54

- base address 54, 55
- ECP DMA channel 55
- IRQ 54, 55
- operation mode 55
- parallel port 55
- serial port 1/2 54

- opening the system 81
 - removing cover 81
 - replacing cover 82

overview 3**P**

- Parallel Port 23
- Password
 - bypassing 68

- changing 67
- removing 67
- setting 66

PCI 3**Power Management 58**

- IDE hard disk timer 58
- modem ring indicator 59
- power management mode 58
- power switch > 4 seconds 59
- Sleep mode 59
- system sleep timer 59
- system wake-up event 59

power management 24**power on computer 13****preinstallation 4****Product Information 48**

- DMI BIOS version 49
- main board ID 48
- product name 48
- system BIOS version 48
- system serial number 48

R

- replacing HDD 92

S**SDRAM 23****Software Shutdown 24****System Information 44**

- 1st bank 46
- 2nd bank 46
- external cache size 45
- floppy drive A 45
- floppy drive B 45
- IDE primary channel master 45
- IDE primary channel slave 45
- IDE secondary channel master 46
- IDE secondary slave 46
- internal cache size 45
- parallel port 46
- processor 45
- processor speed 45
- PS/2 mouse 47
- serial port 1 46
- serial port 2 46
- total memory 46
- system introduction 3
- system reconfiguration 87



System Security 64
 disk drive control 65
 floppy drive 65
 hard disk drive 65
 operation mode 65
 Power-on password 65
 Setup password 64

T

troubleshooting 15
turning off computer 14
turning on computer 13

U

USB 3, 24, 34

V

video function 32
 AGP 32
 memory 32
 shared-frame buffer 32

W

Wake-on LAN 37
WOL 37

