

Contents

3 INTRODUCTION

- 4 Package Contents

5 GETTING TO KNOW YOUR CAMERA

- 5 Front View
- 6 Rear View
- 7 Mode Dial
- 8 LCD Monitor Information

10 PREPARING THE CAMERA

- 10 Installing the Batteries
- 11 Using the AC Adapter (Optional Accessory)
- 12 Inserting and Removing an SD Memory Card (Optional Accessory)

13 GETTING STARTED

- 13 Turning the Power On/Off
- 13 Choosing the Screen Language
- 14 Setting the Date and Time
- 15 Formatting an SD Memory Card or Internal Memory
- 16 Using the LCD Monitor

17 PHOTOGRAPHY MODE

- 17 Shooting Images
- 18 Setting Image Resolution and Quality
- 19 Using the Zoom Function
- 20 Using the Flash
- 21 Setting Focus

22 Capture Mode

- 22 Burst
- 23 Self-Timer
- 24 Adjusting the Exposure (EV Compensation)
- 25 Setting White Balance

26 USING THE MODE DIAL

27 PLAYBACK MODE - THE BASICS

- 27 Viewing Images
- 28 Magnifying Images
- 29 Thumbnail Display

30 MOVIE MODE

- 30 Recording Movie Clips
- 31 Playing Back Movie Clips

32 PLAYBACK MODE - ADVANCED FEATURES

- 32 Playing Back Still Images/Movie Clips on TV
- 33 Deleting Images/Movie Clips
- 34 Connecting to a PictBridge-Compatible Printer

38 TRANSFERRING FILES FROM YOUR DIGITAL CAMERA TO COMPUTER

- 38 Step 1: Install the USB driver
- 39 Step 2: Connect the digital camera to your computer
- 40 Step 3: Download images or movie clips

41 EDITING SOFTWARE INSTALLATION

- 41 Installing NTI Photo Suite (Optional)

42 USING THE DIGITAL CAMERA AS A PC CAMERA

- 42 Step 1: Install the PC camera driver
- 43 Step 2: Connect the digital camera to your computer
- 43 Step 3: Run your application software (i.e. Windows NetMeeting)

44 MENU OPTIONS

- 44 Camera Menu
- 49 Movie Menu
- 50 Playback Menu
- 53 Setup Menu

57 SPECIFICATIONS

INTRODUCTION

Thank you for purchasing the new digital still camera!

Equipped with a 6.36 Mega pixels CCD sensor, your camera delivers high quality, 2816 x 2112 resolution images. Other features provided by the camera include the following:

- **6.36 Mega pixels**

A high-resolution CCD sensor provides 6.36 mega pixels for high quality of images.

- **Auto flash**

An auto flash sensor automatically detects the shooting (lighting) conditions and determines whether the flash should be used.

- **2.36" TFT color image LCD monitor**

- **Optical zoom: 1x~3x**

- **Digital zoom: 1x~4x**

- **Approx. 8MB internal (built-in) memory**

Images can be captured without using an SD memory card.

- **Support for SD memory card for memory expansion**

You may wish to expand the memory capacity (up to 1GB capacity) by using an additional SD memory card.

- **USB connection**

Still images or movie clips that you have recorded can be downloaded to your computer using the USB cable (A USB driver is required for Win 98 and Win98SE).

- **DPOF functionality**

DPOF can be used to print your images on a DPOF compatible printer by simply inserting the SD memory card.

- **PictBridge support**

You can connect the camera directly to a printer that supports PictBridge and perform image selection and printing using the camera monitor screen and controls.

- **Provided editing software: NTI Photo Suite**

You can enhance and retouch your images on your computer by using the provided editing software.

Package Contents

Carefully unpack your kit box and ensure that you have the following items. In the event that any item is missing or if you find any mismatch or damage, promptly contact your dealer.

Common Product Components:

Digital camera
User's manual
Camera strap
USB cable
2 AA batteries(Alkaline or Ni-MH recommended)
Warranty card

Common (Optional) Accessories:


SD memory card
Battery charger
AC power adapter
Software CD-ROM
Camera pouch
AV cable



-
- Accessories and components may vary by retailer.

GETTING TO KNOW YOUR CAMERA

Front View



1. Shutter release button

2. Mode dial

3. Power switch

4. Flash

5. Self-timer LED


6. PC / AV terminal

7. DC input terminal


8. Lens


9. Microphone


Rear View




1. LED indicator


2.  Zoom in (telephoto)
button


 Zoom out (wide-angle)
button

3.  Playback button


4.  Menu button


5.  Delete button

6.  Self-timer button


7.  Focus button

8. Strap holder

9.  Exposure compensation
button

10.  Flash button

11. OK button

 Display button


12. Battery / card cover








13. Tripod socket

14. LCD monitor

Mode Dial

You can select from seven shooting modes and setup mode according to shooting conditions to achieve the desired effect.



	Mode	Description
1.	P Program	Select this mode to permit the shutter speed and aperture to be set manually.
2.	 Portrait	Select this mode to make people stand out with the background out-of-focus.
3.	 Landscape	Select this mode to take photographs of distant scenery or landscapes.
4.	 Sports	Select this mode to shoot fast moving objects.
5.	 Night	Select this mode to take photographs of people against a dusk or night-time background.
6.	 Setup	Select this mode to adjust the camera settings.
7.	 Video	Select this mode to record video clips.
8.	 Auto	Select this mode to adjust point-and-shoot action.





LCD Monitor Information

■ Camera Mode







1. Mode indication

- [**P**] Program Mode
- [] Portrait Mode
- [] Landscape Mode
- [] Sports Mode
- [] Night Mode
- [] Setup Mode
- [] Movie Mode
- [**A**] Auto Mode

2. Flash mode

- [] Auto
- [] Red eye
- [] Flash on
- [] Flash off

3. Capture mode


- [] Single
- [] Burst
- [] AEB
- [] 2 sec. Self-timer
- [] 10 sec. self-timer
- [] 10+2 sec. Self-timer

4. Focus mode

- [**AF**] Standard
- [] Macro
- [] Infinity






5. Possible number of shots


6. Memory status

[] : Built-in memory
(without card)

[] : SD memory card

7. Battery and AC adapter

- [] Full battery power
- [] Medium battery power
- [] Low battery power
- [] No battery power
- [] AC adapter







8. Recorded pixels

- [**6M**] 2816 x 2112
- [**4M**] 2272 x 1704
- [**2M**] 1600 x 1200
- [**0.3M**] 640 x 480

9. Image quality

- [******] Fine
- [*** ***] Normal
- [*****] Economy

10. White balance

- Auto
- [] Daylight
- [] Cloudy
- [] Tungsten
- [] Fluorescent

11. ISO sensitivity

- [**ISO Auto**] Auto
- [**ISO 64**] 64
- [**ISO 100**] 100
- [**ISO 200**] 200


12. EV compensation

13. Zoom bar

14. Focus area


■ Movie Mode

1. Movie mode
2. Flash mode
3. Recordable movie time available
4. Memory status
5. Battery power and AC adapter indicator
6. Focus area
7. Zoom bar




■ Image Playback

1. Playback mode
2. Number of image
3. Memory status
4. Battery power and AC adapter indicator
5. Index number of total number
6. DPOF indicator
7. Protect indicator
8. Date
9. Time
10. EV compensation
11. ISO sensitivity
12. White balance
13. Image quality
14. Recorded pixels



■ Movie Playback

1. Playback mode
2. Movie mode
3. Number of movie
4. Memory status
5. Battery power and AC adapter indicator
6. Index number of total number
7. Elapsed time
8. Date
9. Time
10. Play/Pause indicator




PREPARING THE CAMERA

Installing the Batteries

You can use 2 AA size batteries (alkaline or Ni-MH rechargeable) to power the camera. Make sure that the power of the digital camera is off before inserting or removing the batteries.

1. Make sure the camera is turned off.
2. Open the battery cover.
3. Insert the batteries in the correct orientation as shown in the illustration.
4. Close the battery cover.
 - To remove the batteries, turn the camera off before removing batteries and hold the camera with the battery cover facing upward, then open the battery cover.




-
- Be careful not to drop the batteries when opening or closing the battery cover.
 - Due to the characteristics of AA alkaline battery, camera performance may deteriorate. AA alkaline battery is not recommended except in emergencies and checking the camera's functionality.

Using the AC Adapter (Optional Accessory)

Use of the AC adapter is recommended if you intend to use the LCD monitor for a long time or connect the camera to a PC.

1. Make sure your camera is off.
2. Connect one end of the AC adapter to the camera DC input terminal labeled "DC IN 3V".
3. Connect the other end to a power outlet.




- Make sure to use only the AC adapter specified for the camera. Damage caused by the use of an incorrect adapter is not covered under the warranty.
- To prevent unexpected auto power off resulting from no battery power left during the process of transferring your images to the computer, use the AC adapter as a power supply.
- The AC adapter can only be used to power the camera. Batteries cannot be charged inside the camera.


Inserting and Removing an SD Memory Card (Optional Accessory)

The digital camera comes with 8MB of internal memory, allowing you to store captured still images or video clips in the digital camera. Moreover, you can also expand the memory capacity by using an optional SD (Secure Digital) memory card so that you can store more files.

1. Make sure your camera is turned off before inserting or removing a memory card.
2. Open the battery/SD memory card cover.
3. Insert an SD memory card in the correct orientation as shown in the illustration.
4. Close the battery/SD memory card cover.
 - To remove the SD memory card, make sure the camera is turned off. Press lightly on the edge of the memory card and it will eject.




- Be sure to format an SD memory card with this digital camera before using it. Refer to section in the manual titled **“Formatting an SD Memory Card or Internal Memory”** for further details.
- To prevent valuable data from being accidentally erased from an SD card, you can slide the write protect tab (on the side of the SD memory card) to “LOCK”.
- To save, edit, or erase data on an SD memory card, you must unlock the card.



GETTING STARTED

Turning the Power On/Off


- Press the power switch until the digital camera turns on.
- To turn the power off, press the power switch again.



Choosing the Screen Language

Follow the steps below to choose the desired language.

1. Rotate the mode dial to $\overset{\text{SET}}{\text{UP}}$ and turn your camera on by pressing the power switch.




2. [Setup] is displayed.
3. Use the four-way controller to select [Language], then press the OK button.
4. Use the four-way controller to select the language you want.
5. Press the OK button to confirm.



Setting the Date and Time

Follow the steps below to set the date display style, current date and time.

1. Rotate the mode dial to **SET UP** and turn your camera on by pressing the power switch.
2. [Setup] is displayed.
3. Use the four-way controller to select [Date & Time] and switch the date types, then press the OK button.
4. Press the four-way controller to select Day, Month, Year and Time fields.
 - The time is displayed in 24-hours format.
5. Press the OK button after all fields are set.




- The date illustration shown is for the purpose of explanation and may differ from the actual setting of your camera.

Formatting an SD Memory Card or Internal Memory

The term “Formatting” means preparing an “SD memory card” to record images; this process is also called “initialization”. This utility formats an SD memory card or the internal memory and erases all stored images and data.





1. Rotate the mode dial to $\overset{\text{SET}}{\text{UP}}$ and turn your camera on by pressing the power switch.
 - [Setup] is displayed.
2. Use the four-way controller to select [Format], then press the OK button.
3. Use the four-way controller to select [Yes], then press the OK button to confirm.




- When you format an SD memory card, be aware that all data on the SD memory card will be erased. Protected images are also erased.
- To format the internal memory, do not insert an SD memory card into the camera. Otherwise, you will format the SD memory card.
- An SD memory card having any problem cannot be properly formatted.

Using the LCD Monitor

Your camera is equipped with a 2.36" full color TFT LCD monitor to help you compose images, replay recorded images/movie clips or adjust menu settings. The mode icons, text and numbers displayed on the monitor may vary according to the current settings.






1. Rotate the mode dial to **A**, **P**, , , , or .
2. Press the power switch to turn on the power.
3. Compose your scene on the LCD monitor.
4. Press the shutter release button.




- The LCD monitor darkens in strong sunlight or bright light. This is not a malfunction.
- To prevent your images from being blurred while pressing the shutter release button, always hold it carefully. This is especially important when you are shooting under low lighting conditions, since your camera may decelerate the shutter speed to ensure your images are properly exposed.

PHOTOGRAPHY MODE

Shooting Images

1. Rotate the mode dial to **A**, **P**, , , , , or  and turn your camera on by pressing the power switch.
2. Mode-dial Help information will be displayed on the LCD monitor. This is a brief guide to the selected mode which disappears in a few seconds.
3. Compose the image on the LCD monitor screen so that the main subject is within the focus frame.
4. Press the shutter release button down halfway to focus the image.
 - When you press the shutter release button down halfway, the camera's Auto Focus feature automatically focuses the image. The focus frame turns green if the subject is in focus. Proper exposure is determined and locked at the same time.
5. Press the shutter release button the rest of the way down to capture the image.



- The actual captured image appears to be larger than the one displayed by the LCD monitor screen after the image has been captured.
- Pressing the **OK/|O|** button switches the LCD monitor display mode. Each time you press the **OK/|O|** button, the display changes in the following order: Normal Display → Information Display → No Icons → LCD Off.
- To enable/disable Mode-dial Help function, set the [Option-Mode-dial Help] to [On]/[Off] in the **SET UP** mode.



Setting Image Resolution and Quality

As you get to know the digital camera, you can set the image resolution (number of vertical and horizontal pixels) and image quality (compression ratio) based on the types of images you want to shoot. These settings affect the number of images that can be stored in the internal memory, or on an SD memory card.

Higher resolution and higher quality images provide finer detail but cause the images' file size to be larger.



To change image resolution or image quality, perform these steps below:


1. Rotate the mode dial to **A**, **P**, **Ⓜ**, **▲**, **Ⓢ**, or **☾** and turn your camera on by pressing the power switch.
2. Press the **[M]** button.
 - [Capture] is displayed.
 - In the **A** mode, [Auto] is displayed.
3. Use the four-way controller to select [Image Size], then press the OK button.
4. Use the four-way controller to select the desired setting, then press the OK button to confirm.
5. Follow the step 3 and 4 above to set the [Quality].




- The possible number of shots and recording time depend on the storage size, resolution and quality settings and the subject of the image to be captured.







Using the Zoom Function

This camera is equipped with 3x optical zoom. The lens moves during the optical zoom photography, allowing you to capture telephoto and wide-angle shots. By using the optical zoom function; images appear closer by pressing the  button, or smaller away by pressing the  button.


The zoom bar indicates the current level of magnification. When the digital zoom is within 3x magnification, the zoom bar is within the optical zoom range. When the digital zoom function is set to **On**, you can further enlarge the subjects with the 4x digital zoom by continuously pressing the  button. It is activated after your camera reaches its maximum optical zoom factor (3x) and the zoom bar is within the digital zoom area. You can enlarge the subject to a maximum magnification equivalent to 12 times. A useful feature as it is, however, the more the image is enlarged, the more pixelated the image will appear.






To capture a zoomed image, perform the following steps:

1. Rotate the mode dial to **A**, **P**, , , or  and turn your camera on by pressing the power switch.
2. Adjust the magnification ratio by using the  /  button.
 - To exit the zoom photography, press and hold the  button.
 - The status of digital magnification is displayed on the LCD monitor.






3. Compose your scene and press the shutter release button.



- To enable digital zoom feature, set the [Function- Digital Zoom] to [On] in the **A**, **P**, , , or  mode.





Using the Flash

The flash is designed to function automatically when lighting conditions warrant the use of flash. You can take an image using a desired flash mode to suit your circumstances.

1. Rotate the mode dial to **A**, **P**, , , , or .
2. Press the power switch to turn on the power.
3. Press the four-way controller (). The flash mode changes each time the button is pressed.
4. Press the OK button to confirm the setting.
5. Compose your scene and press the shutter release button.



The camera has four flash modes: Auto, Red-eye, Flash on and Flash off. The table below will help you to choose the appropriate flash mode:

Flash mode	Description
 Auto	The flash fires automatically according to the photographic conditions.
 Red-eye	Use this mode to reduce the red-eye phenomenon when you want to take natural-looking photographs of people and animals in low-light conditions. When taking photographs, the red-eye phenomenon can be reduced by asking the subject (person) to look at the digital camera or get as close to the digital camera as possible.
 Flash on	The flash will always fire regardless of the surrounding brightness.
 Flash off	The flash will not discharge, regardless of the brightness. Use this mode when taking pictures using indoor lighting, for stages and indoor competitions, and when the subject is too far away for the flash to be effective.

Setting Focus

Images can be captured with the focus determined automatically using auto focus. You may over-ride the auto focus and specify [🌻] macro or [▲] infinity.

1. Rotate the mode dial to **A**, **P**, **🌻**, **▲**, **🌻**, or **☾**.
2. Press the power switch to turn on the power.
3. Press the four-way controller (🌻). The focus mode changes each time the button is pressed.
4. Press the OK button to confirm the setting.
5. Compose your scene and press the shutter release button.



The camera has three focus modes: Standard, Macro and Infinity. The table below will help you choose the appropriate focus mode:

Focus mode	Description
AF Standard	Select Standard-focus setting for most occasions when you want the camera to automatically determine the focus setting. When using Standard-focus setting, any object at a range of focus is 50 cm or greater can be in focus.
🌻 Macro	Select Macro-focus setting to capture close-up images. When the lens is zoomed to its widest position you may focus objects as close as 5 cm. When the lens is zoomed to its telephoto position (3x zoom) you may focus objects as close as 30 cm.
▲ Infinity	Select Infinity-focus setting when you want to capture images of subject at a distance of infinity. The flash mode will be set to Flash Off automatically.








Capture Mode

Burst

Burst mode is used for continuous shooting. 3 pictures are taken continuously once the shutter release button is pressed. Secure the camera to a tripod or place it on a stable surface.

Auto Bracket

In Auto Bracket (AEB) mode, the camera automatically changes the exposure within a set range to take three shots after you press the shutter release button once. Auto Bracket settings can be combined with exposure compensation settings to extend the adjustment range.







1. Rotate the mode dial to **A**, **P**, , , , or .
2. Press the power switch to turn on the power.
3. Press the four-way controller () and select [Burst] or [AEB].
4. Press the OK button to confirm the setting. The  (Burst) or  (AEB) indicator is displayed on the monitor screen.
5. Press the shutter release button halfway to lock the focus.
6. Press the shutter release button to capture a sequence of images.
7. In Burst mode, the flash mode will be set to **Flash Off** automatically.



- In Burst and Auto Bracket mode, the flash mode will be set to **Flash Off** automatically.




Self-Timer

The self-timer can be used in situations such as group shots. When using this option, you should either mount the camera on a tripod (recommended) or rest it on a flat, level surface.

1. Secure the camera to a tripod or place it on a stable surface.
2. Rotate the mode dial to **A**, **P**, , , , or .
3. Press the power switch to turn on the power.
4. Press the four-way controller () and select your desired self-timer mode.
5. Press the OK button to confirm the setting.
6. Compose your scene and press the shutter release button.
 - The self-timer function is activated.
 - The photograph is then taken after the preset time.
 - To cancel the self-timer at any time, press the four-way controller () or press the shutter release button halfway.



The table below will help you choose the appropriate self-timer mode:






Self-timer mode	Description
 2 sec. Self-timer	The image is captured about 2 seconds after the shutter is pressed. This mode is useful for preventing camera shake.
 10 sec. Self-timer	The image is captured about 10 seconds after the shutter is pressed. This mode is suitable for the shots in which the photographer has to be included.
 10+2 sec. Self-timer	The first image is captured about 10 seconds after the shutter release button is pressed, and then the second image is captured 2 seconds later. This mode is convenient when capturing group images in succession. Flash does not fire in this mode.



- After one shot is taken, the self-timer mode is turned off.
- If you wish to take another image using the self-timer, repeat these steps.

Adjusting the Exposure (EV Compensation)







You can manually adjust the exposure determined by the digital camera. Use this mode when the proper exposure cannot be obtained, for example, when the contrast (difference between bright and dark areas) between the subject and the background is extremely high. The EV compensation value can be set in the range from -2.0EV to +2.0EV.




1. Rotate the mode dial to **P**, , , , or .
2. Press the power switch to turn on the power.
3. Press the four-way controller () and set the range of EV compensation value from -2.0EV to +2.0EV.
4. Press the OK button to confirm the setting.



Setting White Balance

This feature lets you make adjustments to compensate for different lighting types according to your shooting conditions.

1. Rotate the mode dial to **P**, , , , or .
2. Press the power switch to turn on the power.
3. Press the  button. [Capture] is displayed.
4. Use the four-way controller to select [W. Balance], then press the OK button.
5. Use the four-way controller to select the desired white balance setting, then press the OK button to confirm.
6. To cancel the setting, press the  button and exit the menu.



USING THE MODE DIAL

The digital camera provides 6 types of scene modes to satisfy different shooting conditions of your subject.

A Auto Mode: This is the simplest way which allows you to take still pictures without having to set special functions or manual adjustments. The camera sets the optimal focusing and exposure.

P Program Mode: The camera automatically sets the shutter speed and aperture for taking still images. You can adjust other functions, such as flash mode or continuous shooting mode.



Portrait Mode: Select this mode to make people stand out with the background out-of-focus.

Landscape Mode: This mode allows you to take photographs of distant scenery or landscapes.

Sports Mode: This mode allows you to shoot fast moving objects.

Night Mode: This mode allows you to take photographs of people against a dusk or night-time background.

1. Rotate the mode dial to the desired mode and turn your camera on by pressing the power switch.
2. Mode-dial Help information will be displayed on the LCD monitor. This is a brief guide to the chosen mode which disappears in a few seconds. If you wish to refer to this information again, press the OK button.
3. Compose your subject within the focus frame.
4. Press the shutter release button to capture the image.









- To enable/disable Mode-dial Help function, set the [Option-Mode-dial Help] to [On]/[Off] in the SET UP mode.


PLAYBACK MODE - THE BASICS

Viewing Images

You can display the still images one by one.





1. Rotate the mode dial to **A**, **P**, , , ,  or  and turn your camera on by pressing the power switch.
2. Press the  button.
 - The last recorded image appears on the LCD monitor screen.
 - Basic information is shown by indicators on the LCD monitor screen.
To see full information display, press the **OK/□** button.
3. Use the four-way controller to select the desired images.



-
- For protected images/movie clips,  mark will be displayed.
 - If there is no image stored in the internal memory or on the SD memory card, [No image] message will appear on the LCD monitor screen.
 - You cannot enter the Playback mode from the Setup mode.

Magnifying Images

While reviewing your images, you may enlarge a selected portion of an image. This magnification allows you to view fine details. The zoom factor displayed on the screen shows the current magnification ratio.







1. Press the  button.
 - The last recorded image appears on the LCD monitor screen.
 - Press the four-way controller to view the previous or next image.
2. Adjust the zoom ratio by using the  button.
 - To enlarge the selected image, press the  button.
 - To return to the normal image, press the  button.
 - The magnification factor is displayed on the LCD monitor screen.
3. To view different portions of the images, press the four-way controller to adjust the display area.



-
- The magnification factors range from 1.5X to 4X (within 6 stages: 1.5X, 2.0X, 2.5X, 3.0X, 3.5X and 4.0X).

Thumbnail Display

This function allows you to view 9 thumbnail images on the LCD monitor screen simultaneously so you may search for a particular image.


1. Press the  button.
 - The last recorded image appears on the LCD monitor screen.
2. Press the  button once.
 - Nine thumbnail images are displayed simultaneously.
 - For recorded movie clips, the  movie mode icon will be displayed.
 - For protected images/movie clips,  mark will be displayed.
3. Use the four-way controller to move the cursor to select the image to be displayed at regular size.
4. Press the OK or  /  button to display the selected image on full screen.





MOVIE MODE

Recording Movie Clips

This mode allows you to record movie clips with sound via built-in microphone.


1. Rotate the mode dial to  (Movie Mode) and turn your camera on by pressing the power switch.
2. Mode-dial Help information will be displayed on the LCD monitor. This is a brief guide which disappears in a few seconds. If you wish to refer to this information again, press the OK button.
3. Compose your subject within the focus frame
4. Press the shutter release button to start recording.
5. To stop recording, press the shutter release button again.



- The optical zoom function (3X) can be activated before you start recording the movie clips
- The digital zoom function can be activated before and during the recording.
- Pressing the OK/[OK] button switches the LCD monitor screen display mode. Each time you press the OK/[OK] button, the display changes in the following order: Normal Display → No Icons → LCD Off.
- To enable/disable Mode-dial Help function, set the [Option-Mode-dial Help] to [On]/[Off] in all modes.

Playing Back Movie Clips

You can play back the recorded movie clips on the LCD monitor screen. However, the sound recorded with movie clips can only be played back on a TV or on a computer.

1. Press the  button.
2. Use the four-way controller to go through the images until the movie clip you want to play back is displayed.
3. Press the OK button to start playing back the movie clips.
 - To pause or resume movie playback, press the OK button again.




- The index number, date and time indicators displayed on the LCD monitor screen will disappear after a few seconds.
- The zoom function cannot be activated when playing back movie clips.
- To playback the movie clips on the computer, we recommend you to use Windows Media Player 9.0 or later (WMP 9.0 or later). You can download WMP version from the website at www.microsoft.com.

PLAYBACK MODE - ADVANCED FEATURES

Playing Back Still Images/Movie Clips on TV

You can also playback your images on a TV screen. Before connecting to any device, make sure to select NTSC/PAL system to match the video output system of the video equipment you are going to connect to the digital camera, then turn off all devices to be connected.





























1. Connect one end of the AV cable to the AV terminal of the digital camera.
2. Connect the other end to the AV input socket of the TV set.
3. Turn the TV and digital camera on.
4. Playback the images/movie clips.
 - The method of operation is the same as playing back still images and movie clips on the digital camera.




-
- The sound recorded with movie clips can only be played back on a TV or on a computer.

Deleting Images/Movie Clips

Use this function to delete one or all images/movie clips stored in SD memory card or the internal memory. Please note that the deleted images or movie clips cannot be recovered. Exercise caution before deleting a file.

1. Rotate the mode dial to **A**, **P**, , , , , , , , , , , , , , , , , , , , , , , , , , ,
2. Press the  button.
 - The last recorded image/movie clip appears on the LCD monitor screen.
3. Use the four-way controller to select the image/movie clip you want to delete.
4. Press  the button to delete.
5. Use the four-way controller to select [This Image] or [All Images] by your preference, then press the OK button.
6. When the delete message appears, use the four-way controller to select [Yes], then press the OK button to confirm the deletion.
 - If you wish to cancel the deletion, select [No].



- Protected images cannot be deleted with the delete function.


Connecting to a PictBridge-Compatible Printer

Even if you do not have a computer, you can connect the camera directly to a printer that supports PictBridge to perform image selection and printing using the camera screen and controls. DPOF support also lets you specify which images you want to print and how many copies of each should be printed.

Connecting the camera to the printer

1. Rotate the mode dial to $\overset{\text{SET}}{\text{UP}}$ and turn your camera on by pressing the power switch.
2. Press the four-way controller to select the [Option] menu, then use the four-way controller to select [USB Mode]. Press the OK button.
3. Use the four-way controller to select [PictBridge], then press the OK button.
4. Connect your camera and the printer via a supplied USB cable.

- The message "One moment" will appear on the on the LCD monitor screen.



- On Windows 98/98SE/ME/2000, if the camera is connected to your computer and you unintentionally set the camera's USB connection to PictBridge, the "Install Driver" message will appear. Ignore this message and click "Cancel".



Printing images


When the camera is properly connected to a PictBridge-compatible printer, the [Printing Mode Select] screen is displayed on the LCD monitor screen. Use the four-way controller to select the print mode.

In [Print] Mode:

Lets you print the specified image with PictBridge.

1. Use the four-way controller to select the [Print] mode, then press the OK button.
2. Use the four-way controller to select the image you want to print, then press the four-way controller to set more detailed settings.
3. Use the four-way controller to select by your preference, then press the OK button.
[Quantity]: Specifies the number of prints. You can select the number up to 10.
[Date]: If you select [With], images are printed with the date.
[File Name]: If you select [With], images are printed with the file name.



4. After Print Setting is set, the print icon  is marked on the displayed image. You can still use the four-way controller to change the image by your preference, then press the OK button to print.

5. Use the four-way controller to access the paper selection setting, then press the OK button to confirm.



[Size]: You may select the desired item depending on the type of printer being used.

[Borderless]: You may select the desired item depending on the type of printer being used.

6. This starts printing and displays the message "Transferring" on the LCD monitor screen. The message will disappear after the printing is finished. Then the screen returns to [Printing Mode Select].

■ To cancel printing:


Pressing the OK button during print data transfer displays the screen for selecting whether to [Continue] or [Cancel] printing.



In [Print All] Mode:

Lets you print all images with PictBridge.


1. If you wish to print all the images stored in the camera, you may choose [Print All] in [Printing Mode Select].
2. To set Print Settings, follow steps 2 to 6 in [Print] Mode.



In [Print With DPOF] Mode:

This function only lets you print the specified image based on the previous DPOF settings.

1. If you wish to print images with DPOF setting, you may choose [Print With DPOF] in [Printing Mode Select].
2. To set Print Settings, follow steps 2 to 6 in [Print] Mode.



-
- When connecting a printer which is not compatible with DPOF, [Print With DPOF] cannot be selected.

TRANSFERRING FILES FROM YOUR DIGITAL CAMERA TO COMPUTER

After using USB cable to establish a USB connection between the camera and your computer, you can use your computer to share recorded images or video clips with your family or friends via e-mail or post them on the Web. In order to do this, you must install the USB driver onto your computer first. Note that before you begin to install the software, you need to check your system according to the table as shown below.

	System Requirements (Windows)	System Requirements (Macintosh)
CPU	Pentium III 600 MHz processor or higher	PowerPC G3/G4
Operating System	Windows 98SE/Me/NT/2000/XP	OS 9.0 or higher
RAM	32MB (64MB RAM recommended)	32MB (64MB RAM recommended)
Hard Disk Space	128MB hard disk space	128MB hard disk space
Required Devices	A CD-ROM drive An available USB port	An available USB port
Display	Color Monitor (800x600, 24-bit or higher recommended)	Color Monitor (800x600, 24-bit or higher recommended)

Step I: Install the USB driver

■ Installation on Windows 98 & 98SE

The USB driver on the supplied CD-ROM is exclusively for Windows 98 and 98SE. Windows 2000/ME/XP users need not install the USB driver.




1. Insert the enclosed CD-ROM into your CD-ROM drive.
2. When the welcome screen appears, click “**Install USB/PC-Cam driver**”. Follow the on-screen instructions to complete the installation.
3. After the USB driver has been installed, restart your computer

■ Installation on MAC OS 9.0

For Mac OS 9.0 or higher, the computer will automatically recognize the digital camera and load its own USB drivers.

Step 2: Connect the digital camera to your computer

1. Rotate the mode dial to **SET UP** and turn your camera on by pressing the power switch.
2. Press the four-way controller to select the [Option] menu, then use the four-way controller to select [USB Mode].
3. Press the OK button.
4. Use the four-way controller to select [PC], then press the OK button.
5. Turn off your camera.
6. Connect your camera and the computer via the supplied USB cable.
7. Turn your camera on by pressing the power switch.
8. There will be a new "Removable Disk" icon detected in "My Computer", which contains your recorded images or movie clips. (For Mac users, double-click [untitled] or [unlabeled] disk drive icon on our desktop.)



Step 3: Download images or movie clips

When the digital camera is turned on and connected to your computer, it is considered to be a disk drive, just like a floppy disk or CD. You can download (transfer) images by copying them from the “Removable disk” (“untitled” or “unlabeled” disk on a Macintosh) to your computer hard drive.

■ Windows

Open the “removable disk” and double click on the DCIM / DSCIM folder to open it to find more folders. Your images are inside these folder(s). Select the desired still images or video clips and then choose “Copy” from the “Edit” menu. Open the destination location (folder) and choose “Paste” from the “Edit” menu. You may also drag and drop image files from the digital camera to a desired location.

■ Macintosh

Open the “untitled” disk icon, and the destination location on your hard disk. Drag and drop from the digital camera to the desired destination.



- Memory card users may prefer to use a memory card reader (highly recommended).
- Video playback application is not included with the package. Make sure that video playback application has been installed in your computer.

EDITING SOFTWARE INSTALLATION

Installing NTI Photo Suite (Optional)

PC users will find that NTI Photo Suite is a very user-friendly image-editing program. With NTI Photo Suite, you can retouch, compose, and organize your images. It includes a variety of templates, such as photo frames, birthday cards, calendars and more. Get your images ready and explore this amazing program.

■ To install NTI Photo Suite:

1. Insert the CD-ROM that came with the camera into your CD-ROM drive. The welcome screen appears.
2. Click "INSTALL NTI PHOTO SUITE". Follow the on screen instructions to complete the installation.



-
- To use NTI Photo Suite to edit and retouch your recorded images, please refer to the on-line help.
 - For Windows 2000/XP users, please make sure to install and use the NTI Photo Suite in "Administrator" mode.
 - NTI Photo Suite is not supported on the Mac. iPhoto or iPhoto2 is recommended.

USING THE DIGITAL CAMERA AS A PC CAMERA

Your digital camera can act as a PC camera, which allows you to videoconference with business associates, or have a real-time conversation with friends or family. To use the digital camera for videoconferencing, your computer system must include the items as below:

- Microphone
- Sound card
- Speakers or headphones
- Network or Internet connection



-
- Video conferencing (or video editing) software is not included with the digital camera.
 - This mode is not supported for Mac.


Step 1: Install the PC camera driver

The PC-camera driver included in the CD-ROM is exclusively for Windows. The PC camera function is not supported for Mac platforms.

1. Insert the enclosed CD-ROM into your CD-ROM drive.
2. When the welcome screen appears, click “ **Install USB/PC-Cam driver** ”. Follow the on-screen instructions to complete the installation.
3. After the driver installation is completed, restart your computer.

Step 2: Connect the digital camera to your computer

1. Rotate the mode dial to **SET UP** and turn your camera on by pressing the power switch.
2. Press the four-way controller to select the [Option] menu, then use the four-way controller to select [USB Mode].
3. Press the OK button.
4. Use the four-way controller to select [PC CAM.], then press the OK button.
5. Connect your camera and the computer via the supplied USB cable.
6. Position the digital camera steadily on top of your computer monitor or use a tripod.



Step 3: Run your application software (i.e. Windows NetMeeting)

To use Windows NetMeeting for videoconferencing:

1. Go to **Start → Programs → Accessories → Communications → NetMeeting** to launch the NetMeeting program.
2. Click the Start Video button to view live video.
3. Click the Place Call button.
4. Type the e-mail address or the network address of the computer that you are calling.
5. Click Call. The person that you are calling must also have Windows NetMeeting running and be willing to accept your call to start the videoconference.













- The video resolution for videoconferencing applications is generally 320 x 240.
- For more information about the operation of videoconference application software, refer to its respective help documentation.
- Use of AC adapter is recommended while the camera is used as a PC camera.

MENU OPTIONS







Camera Menu

This menu is for the basic settings to be used when capturing still images.









1. Rotate the mode dial to **A**, **P**, , , , or  and turn your camera on.
2. Press the  button, then use the four-way controller to select the [Capture] / [Function] / [Image] menu.
 - In **A** Mode, press the  button to access the [Auto] menu directly.
3. Use the four-way controller to select the option item, then press the OK button.
4. Press the four-way controller to select the desired setting, then press the OK button.








■ In the **A** Mode

Item	Functional Description
Image Size 	Sets the size of the image that will be captured. Refer to the section in this manual titled "Setting Image Resolution and Quality" for further details.  2816x2112  2272x1704  1600x1200  640x480
Quality 	Sets the quality (compression rate) at which the image is captured. Refer to the section in this manual titled "Setting Image Resolution and Quality" for further details. ★ Fine ★★ Normal ★★★ Economy














- In the **P**, , , , or  Mode.
- **[Capture] settings**

Item	Functional Description
Image Size 	Refer to the section in this manual titled “ Setting Image Resolution and Quality ” for further details.
Quality 	Refer to the section in this manual titled “ Setting Image Resolution and Quality ” for further details.
W.Balance  WB	Sets the white balance when shooting under a variety of lighting conditions and permits photographs to be taken that approach the conditions that are seen by the human eye. Auto  Daylight  Cloudy  Tungsten  Fluorescent
ISO 	Sets the sensitivity for taking pictures. When the sensitivity is raised (and the ISO figure is increased), photography will become possible even in dark locations, but the more pixelated (grainier) the image will appear. Auto / 64 / 100 / 200

■ [Function] settings


Item	Functional Description
<p data-bbox="125 198 208 219">Metering</p> 	<p data-bbox="283 198 881 245">You can select the metering mode that sets which part of the subject to measure to determine the exposure.</p> <ul style="list-style-type: none"><li data-bbox="298 252 881 299"> Center-weighted: Averages the light metered from the entire frame, but gives greater weight to the subject matter at the center.<li data-bbox="298 306 881 353"> Spot: The exposure is determined by the small area in the center of the screen only.
<p data-bbox="125 366 244 387">Digital Zoom</p> 	<p data-bbox="283 366 881 435">This sets whether or not to use digital zoom at the time of shooting. Refer to the section in this manual titled “Using the Zoom Function” for further details.</p>
<p data-bbox="125 463 232 483">Quick View</p> 	<p data-bbox="283 463 832 508">Set to display a photographed image on LCD monitor screen immediately after you have taken the shot.</p>




■ [Image] settings











Item	Functional Description
Color 	Sets the color of the image that will be captured.  Full Color  Black & White  Sepia
Sharpness 	Sets the level of image sharpness.  High  Medium  Low
Saturation 	To capture an image, your camera offers you three different degrees of color to match with your preference. Your images will demonstrate different impression by selecting different degrees of color. This is called "Saturation".  High  Medium  Low
Date Imprint 	The date of recording can be printed directly on the still images. This function must be activated before the image is captured. The date appears on the right bottom of the captured picture. When images are shot with date imprint feature, the date cannot be removed later.

Movie Menu


This menu is for the basic settings to be used when recording movie clips.






1. Rotate the mode dial to  and turn your camera on.
2. Press the  button.
3. Press the four-way controller to select the option item. Then press the OK button
4. Press the four-way controller to select the desired setting, then press the OK button.
5. To exit the movie menu, press the  button.

Item	Functional Description
Color 	Refer to the Camera Menu's option item (the P ,  ,  ,  , or  Mode) for further details.
Digital Zoom 	Refer to the Camera Menu's option item (the P ,  ,  ,  , or  Mode) for further details.




Playback Menu

In the  menu, set the settings used for playback.









1. Press the  button.
 - The last recorded image appears on the LCD monitor screen.
2. Press the  button, then use the four-way controller to select the [Function] / [Properties] menu.
3. Use the four-way controller to select the option item, then press the OK button.
4. Press the four-way controller to select the desired setting, then press the OK button.
5. To exit the playback menu, press the  button.

■ [Function] settings

Item	Functional Description
Slide Show 	You can play back recorded images in order with a selected interval time. This function is useful for checking your images or for presentations, etc. 3 Sec. / 5 Sec. / 10 Sec.
Protect 	Set the data to read-only to prevent images from being erased by mistake.
DPOF 	Allows you to select the desired pictures to be printed and set the number of prints and whether or not to imprint the data in DPOF format. You can print images easily just by inserting the SD memory card to a DPOF-compatible printer or taking it to a print shop.



■ [Properties] settings

Item	Functional Description
Resize 	Changes the size of a recorded image. Resizing replaces the original image with the changed image. Only resizing to a smaller size is available.  2272x1704  1600x1200  640x480
Quality Change 	Changes the quality (compression rate) of a recorded image. Compresses images and overwrites an old size images with a newly compressed image. Only quality changing to a lower quality level is available. ★★ Normal ★ Economy
Copy to Card 	Allows you to copy your files from the digital camera's internal memory to an SD memory card. You can only do this if you have an SD memory card installed and some files in internal memory.





Setup Menu

This feature allows you to set up the default settings by preference for using your camera.






1. Rotate the mode dial to **SET UP** mode and turn your camera on.
2. Press the four-way controller to select the [Setup] / [Option] / [System] menu.
3. Use the four-way controller to select the desired option item, then press the OK button.
- 4) To exit the setup menu, rotate the mode dial to another mode.






■ [Setup] settings

Item	Functional Description
Format 	Erases all images and reformats the SD memory card loaded in your camera. Protected images are also erased. SD memory card cannot be formatted if it is write-protected. Refer to the section in this manual titled “ Formatting an SD Memory Card or Internal Memory ” for further details.
Beeper 	This sets whether or not to mute the startup sound, and the camera sound each time you press a camera button. Louder / Soft / Off
Date & Time 	This sets the date and the time. Refer to the section in this manual titled “ Setting the Date and Time ” for further details. d/m/y m/d/y y/m/d
Language 	Sets the language that is displayed on the LCD monitor screen. Refer to the section in this manual titled “ Choosing the Screen Language ” for further details. English/ Français / Deutsch / Español / Italiano / 繁體中文 / 简体中文

■ [Option] settings

Item	Functional Description
USB Mode 	Selects to choose one of the following modes for further settings. PC / PictBridge / PC CAM
TV 	Sets video output of the camera for matching the video output system of the equipment that you are going to connect to the camera. PAL / NTSC
LCD Brightness 	This sets the brightness of the LCD monitor screen. The adjustment range is from -5 to +5.
Auto Shut Down 	If no operation is performed for a specific period of time, the power to the camera is automatically turned off. This feature is useful to reduce battery wear. 2 Min. / 3 Min. / 5 Min. / Off
Mode-dial Help 	This enables/disables the Mode-dial Help function. When this function is activated, a brief mode guide appears on the LCD monitor as you rotate the mode dial to different modes.

■ [System] settings

Item	Functional Description
Reset Number. 	Sets whether or not to reset the file number when you take photographs. This creates a new folder. The captured images are recorded to the newly created folder from number 0001. If you want to reset the file number, be sure that no images are recorded in the internal memory or the SD memory card.
Set to Default 	Returns all basic settings to the digital camera's default settings. The time setting will not be reset.
Version 	This displays the current firmware version of the camera.

SPECIFICATIONS

Item	Description
Image Sensor	CCD
Effective pixels	6.36 Mega pixels
Image size	Still image: 2816x 2112, 2272 x 1704, 1600 x 1200, 640 x 480 Movie clip: 320 x 240
Image quality	Still image: Fine / Normal / Economy Movie image: QVGA
Recording media	Approx. 8 MB internal memory SD memory card (Optional, up to 1 GB)
File format	JPEG (Exif 2.2), DCF, Motion JPEG (AVI)
Lens	F-no.: Wide: 2.8 / Tele: 4.8 Focal length: 5.5mm~16.5mm (equivalent to 34~102mm)
Focus range	Normal :40cm ~ infinity Macro :W: 5cm ~ 40cm T: 35cm ~ 40cm
Flash effective range	Wide: Approx. 0.6 m - Approx.2.4 m (at the standard output sensitivity of 200) Tele: Approx. 0.6 m - Approx. 1.8 m (at the standard output sensitivity of 200)
LCD monitor	2.36" color TFT-LCD Approx. 110K pixels display
Self-timer	10 sec self-timer, 2 sec self-timer, 10+2 sec self-timer
Exposure compensation	-2.0EV~ +2.0EV (in 1/3 EV increments)
White balance	Auto, Daylight, Cloudy, Tungsten, Fluorescent
ISO	Auto, 64, 100, 200
Interface	DC input terminal, PC/AV terminal
Power	2 x AA (alkaline or Ni-MH rechargeable) batteries AC-DC Adapter (3V/2.5A) (Optional)
Dimension	Approx. 88.5 x 60 x 28 mm (3.6 x 2.4 x 1.1 in)
Weight	Approx. 130g (without batteries and SD memory card)

* Recording capacity shows approximate number of shots recorded during CIPA-compliant testing. Actual performance may vary according to operating conditions.

* Design and specifications are subject to change without notice.