


SMART RAID



USER'S MANUAL



Copyright © 1998, 1999 Distributed Processing Technology Corporation

All Rights Reserved – Printed in U.S.A.

Storage Manager is a trademark of Distributed Processing Technology Corporation.

SmartCache, SmartRAID, RAIDstation and DPT are registered trademarks of Distributed Processing Technology Corporation.

Microsoft, MS-DOS, Windows NT, Windows, and the Windows logo are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.

NetWare is a trademark of Novell Corporation.

OpenServer, UnixWare and SCO are trademarks of The Santa Cruz Operation. **YES, IT RUNS WITH UNIXWARE** mark – developer tested only. SCO makes no warranties with respect to this product.

I₂O is a registered trademark of Intel Corporation.

All other trademarks are property of their respective owners.

FCC Statement

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: If the SX4055F Fibre Channel Expansion Module is used, the DPT controller will not meet Class B limits. A DPT controller with an SX4055F module does comply with the limits for a Class A digital device.

VCCI Statement

This is a Class B product based on the standard of the Voluntary Control Council for Interference from Information Technology Equipment (VCCI). If this is used near a radio or television receiver in a domestic environment, it may cause radio interference. Install and use the equipment according to the instruction manual.

Distributed Processing Technology

Limited Product Warranty

PROOF OF PURCHASE MAY BE REQUIRED. YOU MAY REGISTER YOUR PURCHASE BY RETURNING THE ENCLOSED WARRANTY CARD WITHIN 30 DAYS OF PURCHASE.

Distributed Processing Technology Corporation ("DPT") warrants to the purchaser of this product that it will be free from defects in material and workmanship for the period as set forth below:

PRODUCT TYPE	WARRANTY <i>(Years from date of purchase)</i>
Hard disks	5 years
RAID/SCSI Controllers	3 years
Cache, Memory, SCSI Expansion and RAID /Caching Modules	3 years
Storage Array Cabinets (Tower and Rackmount)	3 years
Battery Module	1 year

FIRMWARE IS NOT COVERED BY ANY WARRANTY. SOFTWARE IS PROVIDED "AS IS". DPT DOES NOT WARRANT THAT THE SOFTWARE WILL MEET YOUR REQUIREMENTS OR THAT ITS USE WILL BE ERROR-FREE OR UNINTERRUPTED. DPT does warrant that the diskette(s) on which the program is furnished will be free from defects in materials and workmanship under normal use for a period of 90 days from the date of purchase.

If Distributor or Distributor's customer notifies DPT of a defect in the product within the applicable warranty period, DPT shall, at its sole option, either (i) repair the defective product (ii) replace the defective product or (iii) refund the purchase price paid by the Distributor. Replacement parts or products may be new or reconditioned. Product which fails to function upon proper installation shall be deemed dead on arrival ("DOA"), subject to verification by DPT. DOA product shall be replaced by DPT provided that DPT has been notified of the DOA within forty-five (45) days of the date of purchase by Distributor or Distributor's customer. Product returned for any warranty service will not be accepted by DPT unless (i) a return material authorization (RMA) number has been received from DPT along with instructions for returning the product prior to the return, (ii) returned product is in its original or equivalent packaging (to ensure product is not damaged in shipment) and (iii) the product has been returned to DPT within 15 days of issuance of the RMA number. DPT will not be responsible for damage to product during the return shipment to DPT. DPT reserves the right to (i) charge a \$20 re-box fee or (ii) reject any returned product not shipped in the original or equivalent packaging. Freight charges associated with improperly packed product rejected by DPT will be the responsibility of the customer. At its option, DPT may require proof of purchase. Distributor or Distributor's customer shall be responsible for all costs of shipping products for warranty service unless the product is DOA, in which event DPT shall be responsible for the cost of return shipment to the customer. If DPT determines that the product is not defective within the terms of the warranty, customer shall pay the cost of repair at DPT's then prevailing rate. This limited warranty is contingent upon proper use of the product and does not cover product which has been modified, or subjected to unusual physical or electrical stress, unauthorized service, or failure to perform preventative maintenance. Replaced parts or products become the property of DPT.

DPT MAKES NO OTHER EXPRESS OR IMPLIED WARRANTY INCLUDING THE WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. IN NO EVENT WILL DPT BE LIABLE TO YOU FOR ANY DAMAGES, INCLUDING LOST PROFITS, LOSS OF DATA OR OTHER INCIDENTAL OR CONSEQUENTIAL DAMAGES. DPT's LIABILITY FOR BREACH OF WARRANTY IS LIMITED EXCLUSIVELY TO REPAIR OR REPLACEMENT OF PRODUCTS.

Some states do not allow the exclusion of implied warranties or limitations of liability for incidental or consequential damages, so the above exclusions may not apply to you. This warranty gives you specific legal rights. You may have other rights, which vary from state to state.

Distributed Processing Technology
140 Candace Drive
Maitland, Florida • 32751 • USA
Phone (407) 830-5522 • Fax (407) 260-5366
World Wide Web: <http://www.dpt.com>

Distributed Processing Technology

End-User Software License Agreement

You may (i) use the software on a single machine; (ii) make only one copy of the software into any machine-readable or printed form for backup purposes; (iii) merge the software into other software for your use on the single machine (provided that any portion of the software merged into other software will continue to be subject to the terms and conditions of this license); (iv) transfer the software and this license to another party if the other party agrees to accept the terms and conditions of this license; and (v) not make copies of any written materials. If you transfer the software you must either transfer all copies of the software and accompanying materials to the same party or destroy any copies not transferred. You may not attempt to defeat any protection method implemented by DPT to prevent unauthorized use of the software, and you may not modify, adapt, translate, reverse engineer, decompile or disassemble either software or written materials nor create derivative works based upon the software or written materials. This license is effective until terminated by you by destroying the software together with all copies. This license shall terminate automatically if you fail to comply with any term or condition of this license. This agreement is governed by the laws of the State of Florida.

U.S. Government Restricted Rights: The software and any manuals are provided with restricted rights. If the software and manuals are acquired under the terms of a DOD Contract, use, duplication or disclosure by the Government is subject to restrictions as set forth in subparagraph (c)(I)(ii) of the Rights in Technical Data and Computer Software Clause at 252.227-7013. If acquired under the terms of a civilian agency contract, use, reproduction or disclosure is subject to 52.227-19(a) through (d).

Release Notes

To review release notes and documentation errata associated with the SmartRAID V products, select Help–View README Information in Storage Manager or view the README file in the DPT install directory for the latest information.

Check the DPT web site for availability of an updated version of this manual (*SmartRAID V User's Manual*) in Adobe Acrobat PDF format. The current *SmartRAID V Quick Install Guide* is also available for download from the DPT web site in PDF format. The Quick Install Guide contains text in English, French, German, Italian, Polish and Spanish.

Technical Support

Our technical support staff is available Monday – Friday between 6 am and 6 pm Eastern time. Between 6 pm and 8 pm, you can leave a callback message. You can contact us by fax or e-mail 24 hours a day.

Telephone: 407-830-5522 (Press 6 and follow the prompts.)

Fax: 407-830-4793

Internet: <http://www.dpt.com/techsup/supporthelp.html>

DPT offers priority Technical Support as a fee-based option. If you choose this option your call is given priority over all other support calls.

900-555-4378 at the rate of \$1.35 per minute

407-830-5522 Press 6 and select the Priority Technical Support option. The rate is \$30 for the first hour and \$1.00 per minute after the first hour.

Product information and the latest versions of DPT drivers and utilities can be obtained at no charge from the DPT FTP site (<ftp.dpt.com>) or from the Technical Support section of our World Wide Web site 24 hours a day.

Table of Contents

FCC Statement	iii
VCCI Statement	iii
Limited Product Warranty	iv
End-User Software License Agreement	v
Release Notes	vi
Technical Support	vi
<i>Read This First!</i>	1-1
About the Documentation	1-2
User's Manual	1-2
Storage Manager Help System	1-3
Installation Roadmap	1-3
What's In the Box?	1-5
System Requirements	1-5
Safety Information	1-6
Working with Electricity	1-7
Preventing Electrostatic Discharge	1-8
<i>About Your New Controller</i>	2-1
Introduction	2-2
Product List	2-3
Product Feature Overview	2-4
SmartRAID V Millennium Features	2-5
SmartRAID V Decade and Century Features	2-7
SX405x Bus Expansion Module Features	2-8
RA4050 RAID Accelerator Features	2-9
BB4050 Battery Module Features	2-10
SmartRAID V Controller LEDs	2-11
LED Display During Power-Up	2-11
LED Display During Controller Idle	2-11
LED Display During Controller Active	2-12
Cache Status LEDs	2-12
BB4050 LED Indicators	2-13
Audible Alarm	2-13
<i>Configuration and Installation</i>	3-1
Installation Overview	3-2
Configuration	3-3
Narrow and Wide SCSI	3-3
Configuring Cables	3-3
Configuring SCSI Termination	3-4

Configuring Device IDs	3-6
SCSI	3-6
Fibre Channel	3-6
Installation	3-7
Installing the RA4050 RAID Accelerator	3-8
Installing an SX405x Bus Expansion Module	3-9
Installing SIMMs	3-11
Installing DIMMs	3-13
Installing the BB4050 Battery Backup Module	3-14
Installing the Controller	3-15
Determining the Booting Controller	3-16
Controller IRQ and Address	3-16
NVRAM Reset	3-17
Using Microsoft Cluster Server	3-18
System Requirements	3-19
How SmartRAID V Works with MSCS	3-20
Storage Manager on ROM	4-1
Overview	4-2
Keyboard Reference	4-3
Menu Reference	4-4
Icon Reference	4-4
Screen Layout	4-5
The Menu Bar	4-5
The Left Pane – Tree View	4-6
The Right Pane – Information View	4-6
Running SMOR	4-8
Information/Configuration Windows	4-9
DPT I2O BIOS Settings	4-9
Controller Information Windows	4-11
Controller Information Tab	4-11
HBA Configuration Tab	4-13
Device Information	4-15
Array and Array Group Information	4-17
Setting the Configuration	4-19
Array Operations	4-20
Creating an Array	4-20
Creating a Parity Group	4-22
Deleting an Array	4-23
Hot Spares	4-23
Rebuilding a Failed Array	4-24
Formatting a Drive	4-24
Managing Controller Firmware	4-25
Upgrading Firmware	4-25

Saving Controller Firmware to a Disk Image	4-27
Creating a Firmware Disk Image	4-28
Restoring Firmware from a Disk Image	4-28
Software Installation	5-1
Windows NT 4.0	5-2
Installing a New System	5-3
Upgrading an Existing System	5-5
Adding to an Existing System	5-5
Adding to an Existing System (Microsoft OSM)	5-6
Windows 95/98	5-7
Installing Windows 98 (Full Install Version)	5-7
Installing Windows 95 (OEM SR2 – Version 950b)	5-9
Installing Windows 95 (Retail Upgrade – Version 950a)	5-11
Adding SmartRAID V to an Existing Windows 95/98 Configuration	5-11
Upgrading to Windows 98 from Windows 95 (Upgrade Version)	5-12
Installing Storage Manager for Windows	5-13
SCO UNIX	5-14
Installing SCO UNIX 3.2V4.2 or OpenServer 5	5-14
Adding to an Existing SCO UNIX 3.2V4.2 or OpenServer 5 System	5-15
SCO UnixWare 7	5-15
Novell NetWare	5-17
NetWare 4.11 – Boot Controller	5-18
NetWare 4.11 – Secondary Controller	5-19
NetWare 4.2 – Boot Controller	5-20
NetWare 4.2 – Secondary Controller	5-21
NetWare 5.0 – Boot Controller	5-22
NetWare 5.0 – Secondary Controller	5-23
Installing Remote Communication Support	5-24
Red Hat Linux	5-24
Red Hat Linux 5.2 and 6.0	5-25
Red Hat Linux 6.1	5-25
Installing Storage Manager for Linux	5-26
Storage Manager	6-1
Introduction	6-2
System Requirements	6-2
Running Storage Manager	6-3
Using Storage Manager Locally	6-3

SmartRAID V User's Manual

Using Storage Manager Remotely	6-3
Storage Manager on ROM	6-4
Physical Configuration View	6-4
Logical Configuration View	6-6
Logical Device Address	6-7
Status	6-8
Information Windows	6-10
Host Bus Adapter Information Window	6-10
Battery Backup Configuration	6-11
HBA Configuration	6-13
Flash Configuration	6-15
Controller Caching for Windows NT	6-16
Device Information Window	6-17
Caching Configuration	6-18
Array Groups	6-19
Creating an Array Group	6-22
Naming an Array Group	6-24
Dynamic Array Expansion	6-24
Requirements and Restrictions	6-25
Expanding an Array Group	6-26
Reconfiguring Windows NT After Array Expansion	6-27
Deleting an Array Group	6-28
Saving the Subsystem Configuration	6-28
Events	6-29
Event Logging	6-30
Event Notification	6-31
Pager Event Messaging	6-33
Broadcasters	6-34
Broadcaster for NetWare	6-34
Installing the Broadcaster	6-34
Stopping/Restarting the Broadcaster	6-34
Viewing Events	6-34
Broadcaster for SCO UNIX Systems	6-35
Installing the Broadcaster	6-35
Stopping/Restarting the Broadcaster	6-35
Viewing Events	6-35
Broadcaster for Windows NT	6-36
Installing the Broadcaster	6-36
Stopping/Restarting the Broadcaster	6-36
Viewing Events	6-36
Formatting Drives	6-38
Drive Failures	6-39
Audible Alarm	6-39
Rebuilding a Degraded Array	6-40

Hot Spares	6-41
Verify	6-42
Background Task Priority	6-43
I/O Statistics	6-44
Controller I/O Statistics	6-44
Device I/O Statistics	6-45
Remote Communication	6-48
Communicating Across a Network	6-49
Installation and Configuration	6-49
Editing the Configuration File	6-50
Setting up the Server	6-51
Connecting Servers and Workstations	6-52
Connecting to Remote Systems	6-53
Making a Manual Connection	6-54
Using the Phonebook	6-55
Using a Custom Connection	6-56
Theory of Operation	7-1
Intelligent RAID Controllers	7-2
Intelligent I/O	7-3
Benefits	7-3
I2O and Intelligent RAID Controllers	7-4
Pipelined Parallel Processing (P3)	7-5
Disk Caching	7-6
Software and Hardware Caching	7-7
Elevator Sorting	7-8
Caching	7-9
Write-back and Write-through Algorithm	7-9
Flush Strategy	7-10
Predictive Caching Algorithms	7-10
Virtual Cache	7-10
Read Ahead	7-10
Pre-Fetch	7-11
Predictive Caching in Multi-user Systems	7-11
Caching Host Reads	7-12
Optimizing Operating System Cache Size	7-12
Optimizing Controller Cache Size	7-12
RAID	7-13
Disk Striping	7-13
Definition of RAID Levels	7-14
Dual-Level RAID	7-18
Creating Data Redundancy	7-19
Handling I/O Errors	7-20
Degraded Mode	7-21
Rebuilding a Failed Hard Drive	7-21

SmartRAID V Architecture	7-22
ASPI Protocol	7-22
I2O Messaging Protocol	7-22
Command Processing	7-23
Command Overlapping	7-23
Command Queuing	7-24
Auto Request Sense	7-24
Byte/Word Alignment	7-24
Scatter/Gather	7-24
PCI Data Transfer and Bus Mastering	7-25
On-Board Microprocessor	7-26
SCSI Interface	7-26
SCSI Device IDs	7-26
Logical Unit Numbers (LUN)	7-27
Bridge Controllers	7-27
Commands and Messages	7-27
Disconnect/Reconnect	7-27
Transfer Padding and Residue Reporting	7-28
Single-Ended and Differential SCSI	7-28
Multi-Mode SCSI	7-29
Wide SCSI	7-29
SCSI Transfer Rate	7-29
Cabling Single-Ended SCSI	7-30
Cabling Ultra2 (LVD) SCSI	7-32
SCSI Termination	7-33
TERMPWR	7-34
Fibre Channel Arbitrated Loop (FC-AL)	7-35
DPT I2O BIOS	7-36
Assembly Drawings	A-1
PM3755F	A-2
PM3755U2B	A-3
PM3754U2	A-4
PM1554U2, PM2554U2 and PM2654U2	A-5
SX4054U2-1 Bus Expansion Module	A-6
SX4054U2-2 Bus Expansion Module	A-7
SX4055U2-1 Bus Expansion Module	A-8
SX4055U2-2 Bus Expansion Module	A-9
SX4055F FC-AL Bus Expansion Module	A-10
RA4050 RAID Accelerator	A-11
BB4050 Battery Module	A-12
Troubleshooting	B-1

Specifications	C-1
DC Power Requirements	C-2
Environmental Specifications	C-3
Memory	C-3
Capacities	C-3
SIMMs	C-3
DIMMs	C-4
Battery	C-4
SNMP	D-1
Introduction	D-2
Simple Network Management Protocol	D-2
Management Information Base	D-2
Management Console	D-3
DPT MIB Information	D-3
What's Included	D-6
System Requirements	D-6
Hardware Support	D-6
Management Consoles	D-6
Operating System Support	D-7
Installation of DPT SNMP Software	D-7
Installing DPT SNMP Support	D-7
Installing SNMP for Microsoft Windows 95	D-8
Installing SNMP for Microsoft Windows 98	D-8
Operation	D-9
SNMP Software Overview	D-9
DPT SNMP Sub-Agent	D-10
DPT SNMP Trap Broadcaster Module	D-11
Glossary	G-1
Index	I-1

CHAPTER 1:

Read This First!

Before you begin installing your new DPT controller, please take the time to read this chapter. This chapter is an important guide to the rest of the documentation and provides a summary of the installation process.

The term *RAID controller* used throughout this document applies to all SmartRAID V products.

SmartRAID V Documentation

A chapter-by-chapter tour of the documentation set. This includes the User's Manual you are reading, a Quick Install Guide and the Storage Manager Help Files.

Installation Roadmap

The SmartRAID V installation process at a glance, with cross-references to specific chapters in this manual.

What's in the Box

A list of parts and accessories you received with your new controller.

System Requirements

What type of host system you need to successfully install and use a DPT SmartRAID V controller.

Safety Information

Notices regarding electrical safety and electrostatic discharge protection.

About the Documentation

The complete documentation set for the SmartRAID V product line consists of three parts:

- The *User's Manual* (this book), which contains information that helps you to configure and install your SmartRAID V product and using the Storage Manager software. This document also contains information about using the DPT storage subsystem utility – Storage Manager on ROM; background information about the peripheral bus, SCSI, RAID, and caching; system specifications; troubleshooting tips; a glossary of terms; and other topics of interest to SmartRAID V users.
- The *Quick Install Guide*, a brief version of installation steps designed for the experienced user. This document contains instructions in English, French, German, Italian, Polish and Spanish.
- The *Storage Manager Help System*, which contains information about using the Storage Manager software, using SCSI devices and creating disk arrays.

NOTE *An updated version of this manual (in Adobe Acrobat PDF format) may be available for download on the DPT web site (www.dpt.com). SmartRAID V Quick Install Guides are also available for download from the DPT web site.*

User's Manual

The *User's Manual* contains seven chapters and 4 appendices.

Chapter 1, Read This First – This chapter provides an overview of the rest of the documentation, and a roadmap of the installation process.

Chapter 2, About Your New SmartRAID V Controller – This chapter describes the features of the various SmartRAID V controllers, and the add-on modules that you can use with your controller.

Chapter 3, Configuration and Installation – This chapter provides instructions about setting up device IDs and termination, assembling the main board, plug-in modules and SIMM or DIMM memory modules, selecting the proper cables, and installing the controller into your PC.

Chapter 4, Storage Manager on ROM – This chapter provides instructions for using the Storage Manager on ROM (SMOR) utility. SMOR is a DPT storage management utility that is part of the controller ROM and is available during boot. You can use SMOR to configure your controller and create disk arrays before installing an operating system on your computer.

Chapter 5, Software Installation – This chapter provides instructions for installing DPT drivers and Storage Manager for all supported operating systems. After the hardware is configured and the disk arrays created, you can install the operating system, SmartRAID V drivers and the full, OS-specific version of Storage Manager.

Chapter 6, Storage Manager – This chapter provides information about using DPT's Storage Manager software. Storage Manager is a utility that lets you access the full feature set of your SmartRAID V controller and manage your storage subsystem.

Chapter 7, Theory of Operations – This chapter provides an overview of the technology used in the SmartRAID V series of controllers: caching, RAID, DPT controller architecture, I₂O, PCI, SCSI, Fibre Channel and other related topics.

Appendix A, Assembly Drawings – This appendix provides outline drawings of the SmartRAID V circuit boards. These drawings assist you in locating the various components on the boards.

Appendix B, Troubleshooting – This appendix is a list of common problems and suggested solutions.

Appendix C, Specifications – This appendix provides electrical and environmental specifications for the SmartRAID V product line.

Appendix D, SNMP – This appendix describes the DPT implementation of the Simple Network Management Protocol feature for SmartRAID V hardware.


Glossary – The Glossary provides definitions of terms and acronyms used throughout the documentation.

Storage Manager Help System

The Storage Manager online help information contains both topical and pop-up helps for Storage Manager, DPT products and RAID concepts.

Installation Roadmap

The figure on the following page provides an overview of the installation process, and refers to specific chapters in the documentation that provide information about each step.



What's In the Box?

All SmartRAID V controller kits include a controller, utility diskettes (containing drivers and the Storage Manager software for supported operating systems), and documentation. The documentation set consists of this *User's Manual*, a *Quick Install Guide*, and the Storage Manager online help system.

NOTE *SmartRAID V Ultra2 SCSI controllers include the following additional items:*

- *One internal Ultra/Ultra2 4-device Wide SCSI cable.*
- *A multimode, Ultra2 terminator (installed on the end of the included cable).*

System Requirements

The DPT Storage Manager software and device drivers require approximately 2MB of disk space. See Chapter 5, "Software Installation" for information about supported operating systems.

All SmartRAID V controllers are PCI 2.2 compliant and are designed to operate in host systems that comply with revision 2.2 of the PCI specification.

SmartRAID V Decade and Century controllers are multifunction PCI devices. The host system must be able to properly configure multifunction PCI devices, where one of the devices is a bridge.

SmartRAID V Millennium controllers include a PCI bridge. The host system must be able to properly configure PCI bridges and any devices located behind the bridge.

Refer to the file READ.ME in the DPT install directory for more information about computer systems and motherboards that DPT has tested for compatibility with SmartRAID V controllers. You can also select Help-View README Information in Storage Manager to see this information.

Safety Information

Throughout this manual are various notices that indicate procedures or practices that can result in loss of data, damage to equipment or personal injury. Be sure to read the following sections for additional information regarding electrical shock hazards and preventing damage from electrostatic discharge.

The following symbol will accompany IMPORTANT and CAUTION notices that can result in damage to equipment or loss of data.



These notices can be identified as shown by the following examples:

NOTE *This type of notice is used to emphasize important information or procedures that should be followed but if ignored would not result in permanent damage to equipment or software.*

IMPORTANT

This type of notice is used to emphasize a procedure that, if not followed, can cause malfunction of the equipment or software or result in loss of data.




This type of notice is used to indicate hazards or unsafe practices which could result in personal injury or product-property damage.

Working with Electricity

Any device that uses electricity must be treated with caution. Follow these guidelines to ensure general safety.

- Keep the chassis area clear and dust-free during and after installation.
- Do not perform any action that creates a potential hazard to people or makes the equipment unsafe.
- Before working on the system, unplug the power cord.
- Disconnect all power before doing the following:
 - Installing or removing a chassis
 - Working near power supplies
- Do not work alone when potentially hazardous conditions exist.
- Never assume that power has been disconnected from a circuit. Always check.
- Look carefully for possible hazards in your work area, such as moist floors, ungrounded power extension cables, or missing safety grounds.

Notices in this manual with the following symbol indicate a potential electric shock hazard to personnel or equipment.



Preventing Electrostatic Discharge



Electrostatic discharge (ESD) can damage electronic components and equipment. ESD occurs when electronic components are improperly handled and can result in complete or intermittent failures. Always follow ESD-prevention procedures when removing and replacing components.

Use the following guidelines to prevent ESD damage:

- Always use an ESD wrist or ankle strap and ensure that it makes skin contact.
- Connect the equipment end of the strap to an unpainted metal chassis surface.
- If no wrist strap is available, ground yourself by touching the metal chassis.
- When installing a component, use any available ejector levers or captive installation screws to properly seat the bus connectors in the backplane or card slot. These devices prevent accidental removal, provide proper grounding for the system, and help to ensure that bus connectors are properly seated.
- When removing a component, use any available ejector levers or captive installation screws to release the bus connectors from the backplane or card slot.
- Handle adapter cards by available handles or edges only. Avoid touching the printed circuit boards or connectors.
- Place a removed component board-side-up on an antistatic surface or in an approved antistatic container.
- If you plan to return the component to DPT, immediately place it in a static shielding container.
- Avoid contact between printed circuit boards and clothing. The wrist strap only protects components from ESD voltages on the body; ESD voltages on clothing can still cause damage.

CHAPTER 2:

About Your New Controller

This chapter presents the features of DPT SmartRAID V SCSI and Fibre Channel controllers, along with the Bus Expansion, RAID Accelerator and Battery Backup modules.

Feature Overview

A look at the features common to SmartRAID V hardware.

Millennium

Specific features of our high performance RAID controller.

Decade and Century

What makes our low cost RAID controllers so powerful, and how you can upgrade them to meet your growing needs.

SX405x and RA4050 Expansion Modules

SX405x modules add additional SCSI or Fibre Channel busses. An RA4050 module upgrades your Decade or Century controller to hardware RAID and a maximum 64MB of cache.

BB4050 Battery Module

The BB4050 provides up to 72 hours of battery backup safety for your data cache when using a PM3755U2B controller.

LEDs and Audible Alarm

Information about LED indicators and the audible alarm feature.

Introduction

DPT SmartRAID V products incorporate the latest intelligent controller technology to deliver optimum performance for desktop systems, file servers or multi-user host systems.

NOTE *ECC-protected cache is available when you use DPT SM4050 or DM4050/DM4060 memory modules.*

PM3755U2 controllers require DPT DM4050 or DM4060 memory modules. Non-DPT DIMM modules are not supported.

Millennium controllers support RAID 0, 1, 5 and multilevel RAID (0+1 and 0+5). Millennium controllers support a maximum of 256MB of onboard cache.

- **Century controllers** support RAID 0 and RAID 1. You can upgrade to hardware RAID 5 support and up to 64MB of onboard cache by adding an RA4050 RAID Accelerator module.

Century PM2654U2 controllers support RAID 0, RAID 1 and RAID 5 with a pre-installed RA4050 RAID Accelerator. You can have a maximum of 64MB of cache on the RA4050 module.

- **Decade controllers** support RAID 0, 1 and 5 and include 4MB of onboard cache.

You can upgrade a Decade controller by adding an RA4050 RAID Accelerator module to support hardware XOR for RAID 5 and a maximum of 64MB of onboard cache.

- **SX405x Bus Expansion Modules** add extra SCSI channels or a Fibre Channel port to SmartRAID V controllers. You can use a Fibre Channel expansion module to provide both SCSI and Fibre Channel connections on a SmartRAID V SCSI controller.
- The **RA4050 RAID Accelerator** provides up to 64 MB of cache and adds hardware RAID 5 capability to a Century controller or adds hardware XOR and up to 64MB of cache to a Decade controller.
- The **BB4050 Battery Module** provides battery backup for the onboard cache on a Millennium PM3755U2B controller.

Product List

The following SmartRAID V products and accessories are documented in this manual:

Model	Description
PM3755F	64-bit PCI to Fibre Channel RAID Controller
PM3755U2B	64-bit PCI to Ultra2 Wide SCSI RAID Controller (w/battery backup capability)
PM3754U2	32-bit PCI to Ultra2 Wide SCSI RAID Controller
PM2654U2-R ¹	32-bit PCI to Ultra2 Wide SCSI RAID Controller
PM2554U2	32-bit PCI to Ultra2 Wide SCSI RAID Controller
PM1554U2	32-bit PCI to Ultra2 Wide SCSI RAID Controller
SX4055F	64-bit Fibre Channel Single Bus Expansion Module
SX4055U2-1	64-bit Ultra2 Wide SCSI Single Bus Expansion Module
SX4055U2-2	64-bit Ultra2 Wide SCSI Dual Bus Expansion Module
RA4050	RAID Accelerator Module
BB4050	Battery Backup Module
SM4050-16	16MB ECC SIMM
SM4050-64	64MB ECC SIMM
DM4050-16 ²	16MB ECC DIMM
DM4050-64 ²	64MB ECC DIMM
DM4060-16 ²	16MB ECC DIMM
DM4060-64 ²	64MB ECC DIMM

-
1. PM2654U2 controllers are shipped with an RA4050 RAID Accelerator preinstalled.
 2. PM3755U2B controllers use DIMMs for cache memory.

Product Feature Overview

All SmartRAID V controllers include:

- Support for I₂O OSMs provided by major operating system vendors; DPT provides drivers for some operating systems. See Chapter 5, “Software Installation” for a list of drivers supplied by DPT.
- Certifications for major operating systems, including Novell NetWare and Windows NT.
- Support for a variety of SCSI and Fibre Channel devices, including hard disk, tape, CD-Recordable, CD-ROM, Magneto-Optical drives, jukeboxes and scanners.
- Local and remote configuration, array status and I/O monitoring using DPT Storage Manager software.
- Operating system independent configuration and RAID creation using the Storage Manager on ROM (SMOR) utility.
- Support for SCSI-1, SCSI-2 and SCSI-3 with active termination.
- ASPI protocol support for third-party applications and utilities.
- Flash ROM for easy upgrades of controller firmware, I₂O BIOS and SMOR.
- Event logging and broadcasting, including messaging for alphanumeric pagers.
- Dynamic Array Expansion, which lets you increase your storage capacity under Windows NT by adding one or more drives to a RAID 0 or RAID 5 array while your system remains online. See Dynamic Array Expansion in Chapter 6, “Storage Manager” for information on using this feature.
- Predictive caching which analyzes disk read requests made by the host to determine whether they are part of a pattern. If a pattern is detected, the controller uses the pattern to predict which data the host is likely to request in the near future, then reads this data into the cache.
- Intelligent Hot Spare. A hot spare drive automatically replaces a failed drive. When multiple hot spares are available on a controller, the intelligent hot spare algorithm picks the best one based on capacity and bus location. RAID 1 and RAID 5 arrays are rebuilt automatically using the new drive.

SmartRAID V Millennium Features

SmartRAID V Millennium products are high-performance RAID controllers for host computers with a PCI expansion bus.

Key features of the Millennium include:

- High-performance RISC processor (80 MIPS)
- Hardware RAID 0, 1, and 5
- Support for striping multiple arrays as a single logical drive (RAID 0+1 and RAID 0+5)
- Hardware XOR
- Up to 256MB of cache per controller
- 32-bit PCI and 64-bit PCI bus models

Conforms to revision 2.2 of the PCI specification. PCI clock speeds up to 33 MHz are supported.

- One Ultra2 SCSI (PM375xU2) or Fibre Channel (PM3755F) bus
- Intelligent Hot Spare capability
- ECC protection for the data cache (using DPT ECC-capable memory modules)
- Real-time monitoring of controller temperature and voltage
- Optional battery backup capability for DM4050/DM4060 controller cache

The following Millennium controllers are available:

	PM3754U2	PM3755F
Type	Ultra2 Wide	Fibre Channel
Host Bus	32-bit PCI	64-bit PCI
Host/Internal Transfer Rate	132 MB/sec	264 MB/sec
I/O Transfer Rate¹	80 MB/sec	100 MB/sec
	PM3755U2B	
Type	Ultra2 Wide	
Host Bus	64-bit PCI	
Host/Internal Transfer Rate	264 MB/sec	
I/O Transfer Rate¹	80 MB/sec	
Battery Backup	72 hours ²	

1. Maximum per channel burst rate

2. Using a single 16MB DIMM

You can use an SX405x Bus Expansion Module to expand a Millennium controller with one or two additional SCSI channels or with one Fibre Channel Arbitrated Loop (FC-AL) port. Millennium Fibre Channel controllers can be expanded with one additional FC-AL port. By using an SX4055F Bus Expansion Module, Fibre Channel and SCSI buses can coexist on the same SCSI controller (PM375xU2 models only). SX405x Bus Expansion Modules are daughter cards that attach to the SmartRAID V controller and do not require an additional card slot in the host system.

The PM3755U2B controller can be upgraded to include a battery-backed cache by adding a BB4050 battery module.

- For controlling DPT RAIDstation storage cabinets or other manufacturers' cabinets, Millennium SCSI controllers provide a Very High Density Cable Interconnect (VHDCI) 0.8 mm external connector.
- To simultaneously control SCSI devices mounted in the host system, Millennium SCSI controllers provide an internal, high-density 68-pin connector.
- The Millennium Fibre Channel controller provides a single High Speed Serial Data Connector (HSSDC) for external connections. Dual loop redundancy is available by adding an SX4055F Expansion Module.

The memory sockets on a Millennium controller accept up to 256MB of cache for maximum performance. For maximum data protection, use the DPT ECC SIMMs or DIMMs listed below:

Model	Description
SM4050-16	16 MB ECC SIMM
SM4050-64	64 MB ECC SIMM
DM4050-16	16 MB ECC DIMM
DM4050-64	64 MB ECC DIMM
DM4060-16	16 MB ECC DIMM
DM4060-64	64 MB ECC DIMM

NOTE *The PM3755U2B controller only accepts DM4050 or DM4060 modules. Do not use non-DPT DIMMs for this controller.*

The PM3754U2 controller can use either standard 32- or 36-bit¹ single-sided, low-profile 60ns (or faster) EDO SIMMs. However, standard EDO SIMMs do not provide ECC data protection. The PM3754U2 data cache is protected by ECC only when DPT SM4050 memory modules are installed. The green ECC Enabled LED is lit when DPT memory is installed. Refer to Appendix A, "Assembly Drawings" for the location of this LED.

¹The parity bit is not used on 36-bit EDO SIMMs. However, the SIMMs will function in the controller as non-parity memory.

SmartRAID V Decade and Century Features

SmartRAID V Decade and Century controllers are designed to provide high performance solutions for workstations and servers in environments where cost is a factor.

The following Decade and Century controllers are available:

	PM1554U2 / PM2554U2 / PM2654U2
Type	Ultra2 Wide
Host Bus	32-bit PCI
Host/Internal Transfer Rate	132 MB/sec
I/O Transfer Rate ¹	80 MB/sec

1. Maximum transfer rate per channel

The Decade (PM1554U2) controller features include:

- Onboard I/O processor (31 MIPs)
- Hardware RAID 0, 1, 5, 0+1 and 0+5
- Firmware XOR
- 4MB of onboard cache RAM
- Intelligent Hot Spare capability
- Conforms to revision 2.2 of the PCI specification

NOTE *If an RA4050 module is attached to a PM1554U2 controller, the controller's onboard cache is disabled and only the cache on the RA4050 cache is used (64MB maximum). The RA4050 also adds hardware XOR capability which enhances RAID 5 performance.*

Century controller features include:

- Onboard I/O processor
 - PM2554U2 (31 MIPs)
 - PM2654U2-R (40 MIPs)
- Hardware RAID 0, 1 and 0+1
- RAID 5 and 0+5 when using an RA4050 RAID Accelerator
- Up to 64MB of cache when using an RA4050 RAID Accelerator
- Intelligent Hot Spare capability
- Conforms to revision 2.2 of the PCI specification.

The Century controller provides a single Ultra2 SCSI channel and supports up to two additional channels with an SX405x Bus Expansion Module. The SX405x is available in three models, providing either one or two additional SCSI channels or one Fibre Channel Arbitrated Loop (FC-AL) port. By using an SX4055F Bus Expansion Module both Ultra2 SCSI and Fibre Channel can coexist on the same controller.

Both the RA4050 RAID Accelerator and the SX405x Bus Expansion Module are daughter cards that attach to the controller and do not require an additional card slot in the host system. PM2654U2 controllers are shipped with RA4050 and/or SX405x expansion modules already installed.

SX405x Bus Expansion Module Features

SX405x Bus Expansion Modules provide additional channels for SmartRAID V controllers. The SX4055F Bus Expansion Module, can be used to add a FC-AL port to a SmartRAID V Ultra2 SCSI controller or a second Fibre Channel bus to a SmartRAID V Fibre Channel controller.

NOTE *SX405xU2 modules are not compatible with SmartRAID Fibre Channel controllers. The SX4055U2 Bus Expansion Module is not compatible with SmartRAID V controllers that have a 32-bit connector.*

The following DPT Bus Expansion Modules are available:

	SX4054U2-1 (-2)	SX4055U2-1 (-2)	SX4055F
Type	Ultra2 Wide	Ultra2 Wide	Fibre Channel
Channels	Single (Dual)	Single (Dual)	Single
I/O Transfer Rate¹	80 MB/sec	80 MB/sec	100 MB/sec
Width	32-bit	64-bit	64-bit
Internal PCI Transfer Rate	132 MB/sec	264 MB/sec	264 MB/sec

1. Maximum burst rate per channel

SX405x modules attach to the SmartRAID V controller and do not require an additional slot in the host system:

- A single channel SX405xU2-1 Ultra2 SCSI Bus Expansion Module adds one SCSI channel and provides one external Very High Density Cable Interconnect (VHDCI) 0.8 mm connection and one internal high-density 68 pin-connection.
- A dual channel SX405xU2-2 Ultra2 SCSI Bus Expansion Module adds two SCSI channels and provides two external VHDCI 0.8 mm connections and two internal high-density 68-pin connections.
- A Fibre Channel SX4055F Bus Expansion Module adds a single FC-AL bus with a High Speed Serial Data Connector (HSSDC). Using this module with a Fibre Channel controller provides dual-loop redundancy.

RA4050 RAID Accelerator Features

The RA4050 RAID Accelerator module adds up to 64 MB of cache hardware RAID 5 and 0+5 to a Century controller or additional cache and hardware XOR to a Decade controller. The RA4050 connects to the end of the controller and does not require an additional slot in the host system.

The RA4050 hardware cache can provide a substantial performance improvement in systems with heavy disk I/O load, such as CAD workstations, and in network servers running operating systems such as Windows NT, Novell NetWare or UNIX.

The RA4050 supports up to 64 MB of cache using four SIMM sockets. Each socket accepts either a 16MB or 64MB standard 32- or 36-bit² single-sided, low-profile 60ns (or faster) EDO SIMM, or one of the DPT ECC SIMMs listed below:

Model	Description
SM4050-16	16 MB ECC SIMM
SM4050-64	64 MB ECC SIMM

DPT SM4050 SIMMs are recommended for systems where data integrity is critical. Although, standard EDO memory modules can be used to provide RAM for the cache, SM4050 SIMMs protect the cache with ECC capability. The green ECC Enabled LED is lit when DPT memory is installed. Refer to Appendix A, “Assembly Drawings” for the location of this LED.

²The parity bit is not used on 36-bit EDO SIMMs, however, the SIMMs will function in the controller as non-parity memory.

BB4050 Battery Module Features

The BB4050 Battery Module adds battery backup for the data cache on a SmartRAID V PM3755U2B controller using DPT DM4050 or DM4060 memory modules.

The following features of the BB4050 provide additional data security for high-reliability servers:

- Nickel Metal Hydride battery pack provides a backup time of 72 hours (using a single 16MB memory module). Actual backup time depends on the amount of cache used and is calculated by the controller firmware.
- On board intelligence for power crossover and charge management.
- The battery status and backup capacity can be monitored using Storage Manager.
- Fast recharge (five hours).
- Battery life of 300 charge/discharge cycles.
- A user initiated discharge/recharge cycle is available to prevent loss of battery capacity through *voltage depression* by performing periodic deep-discharging and recharging of the battery.
- Operating temperature range of 10°C to 40°C.



Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer. Dispose of used batteries according to the manufacturer's instructions.

SmartRAID V Controller LEDs

SmartRAID V controllers provide nine LEDs that let you visually monitor controller activity. Several different controller states are indicated by the LED as outlined in the following sections. Two additional LEDs indicate the status of the cache memory on the controller. See Appendix A, “Assembly Drawings” for the location of the LEDs on your controller.

LED Display During Power-Up

During its power-up sequence, the controller passes through the following states in sequence, as indicated by the LEDs:

Memory Mapped I/O	LEDs 6 and 7 and LEDs 5 and 8 flash alternately while the controller waits for the host computer to initialize the address translation unit (ATU) on the PCI bus.
Bridge	LEDs 5 and 7 and LEDs 6 and 8 flash alternately while the controller waits for the host computer to initialize its PCI-to-PCI bridge.
Fast Idle	The controller enters a fast idle pattern while waiting for the I ₂ O initialization commands after the address translation unit (ATU) and PCI bridge have been enabled.

NOTE *The ATU, PCI bridge and cache module (if installed) must be configured and enabled before the I₂O initialization can be completed. If any one of these components are not configured or become disabled during the Fast Idle phase, the pattern will return to the respective wait pattern for the affected component.*

LED Display During Controller Idle

When no commands are in progress and all bus activity has ceased, the controller enters the Idle state. This is indicated by a rotating pattern in LEDs 1 through 8.

LED Display During Controller Active

When the power-up sequence is complete, viewing the LEDs can help you determine the operating status of the controller. These LED patterns are also useful for troubleshooting. Refer to Appendix B, “Troubleshooting” for more information on interpreting LED patterns.

LED	Function
1	<i>Heartbeat</i> . Indicates that controller interrupts are enabled and that the controller is alive. During controller activity, this LED flashes four times a second.
2	Indicates the occurrence of a non-maskable interrupt (NMI) to the I/O processor on the controller.
3	Indicates the controller’s internal operating system is in its idle loop.
4	Indicates that the controller’s internal operating system is processing an interrupt.
5	Reserved for future use.
6	Indicates that the cache controller is using DMA to perform a data transfer.
7	Indicates the controller is generating parity information for a RAID 5 array (hardware XOR).
8	Indicates that there is a command on the SCSI or Fibre bus.
IRQ	Lit only when the controller activates an interrupt on the host PCI bus.

Cache Status LEDs

Two LEDs on the SmartRAID V controller indicate the status of the onboard cache RAM. Refer to Appendix A, “Assembly Drawings” for the location of the LEDs on your controller.

- The green ECC Enabled LED is lit when all installed SIMMs or DIMMs are DPT ECC memory modules. This indicates that the controller data cache is ECC protected.
- The red ECC Error LED, is lit when a correctable or non-correctable error has been detected in one of the ECC SIMMs or DIMMs. The LED will stay lit, even after the error has been corrected, until the controller is powered-down. Cache failure information is recorded in the controller error log and can be viewed using the Event Log window in Storage Manager.

BB4050 LED Indicators

The BB4050 module has two LED indicators labeled CHARGE and TRICKLE. These LEDs indicate the following conditions:

Status	TRICKLE LED	CHARGE LED
Initial Powerup ¹	Momentary flash	On
Fast Charge	Off	On
Trickle Charging	On	Off
Charge inhibit	Off	Off
Discharge	Flashing	On
Battery not installed	On	On

1. If battery voltage and the ambient temperature are acceptable, the Trickle LED will not remain lit.

Use the Battery Configuration dialog in Storage Manager to view the current status of the BB4050 module.

Audible Alarm

DPT controllers with caching capability (Millennium models or Decade/Century models using an RA4050 module) have an audible alarm. The failure of a drive which is a member of an array attached to the controller causes the audible alarm to sound. The alarm stops automatically (after the initial system scan) when you start Storage Manager or SMOR.

CHAPTER 3:

Configuration and Installation

Your new DPT SmartRAID V controller is the center of a complete system consisting of the controller, disk drives and other peripherals, and the connecting cables. This chapter discusses configuring these components.

This chapter includes information on using SmartRAID V controllers in a Microsoft Cluster Server (MSCS) configuration.

Configure Devices

Prepare your *SCSI* peripherals for use by setting their *SCSI* IDs and termination. *Fibre Channel* disks and peripherals will configure themselves automatically during boot.

Attach Modules

Assemble the various parts of your DPT controller, which can include the base controller, a RAID Accelerator, Bus Expansion Module and one or more memory modules. The PM3755U2B controller can also use the battery backup module.

Install in your System

Mount the assembled controller in your computer system.

Configure the Software

Use our SMOR utility to set your system parameters, install the operating system and you are ready to use your system.

Microsoft Cluster Server

How to use a SmartRAID V controller in a Microsoft Cluster Server configuration.

Installation Overview

The process of installing a SmartRAID V controller consists of the following steps:

1. If you are using a RAIDstation storage cabinet, configure it as described in the *RAIDstation User's Manual*.
2. Configure device IDs, cables and termination for SCSI devices in the host system. Fibre Channel controllers and devices will automatically configure themselves during boot.
3. If you are using a RAID Accelerator, adding a Bus Expansion Module, expanding your cache memory or using a battery module, plug the appropriate modules onto the controller.

NOTE

SmartRAID V Millennium controllers or Century and Decade controllers with an RA4050 module must have cache installed.

DPT recommends that SmartRAID V controllers have at least 16MB of cache installed.

4. Install the controller and storage devices in the appropriate enclosures. Attach all cables between the controller and the storage devices.
5. Run Storage Manager on ROM (SMOR) by pressing **Ctrl+D** during system boot to configure the controller's SCSI termination and verify proper hardware configuration. You can also use SMOR to configure your storage subsystem and disk arrays. (Refer to Chapter 4, "Storage Manager on ROM".)
6. If you are setting up the computer system for the first time, install the operating system on one of the controller's disk drives or arrays. During this process, you should also install any driver updates for your DPT controller. Refer to Chapter 5, "Software Installation" for specific instructions.
7. Install any required operating system drivers and Storage Manager. Refer to Chapter 5, "Software Installation" for additional information.

Storage Manager for Microsoft Windows is on the DPT Windows NT, Windows 95/98 diskette. Storage Manager for SCO UNIX (Motif version) is on the SCO UNIX diskette.

Configuration

DPT Fibre Channel controllers and attached Fibre Channel devices are plug-and-play and will configure themselves automatically during boot.

SCSI devices in the system must be configured prior to use. This configuration includes enabling SCSI termination for the devices and setting the SCSI IDs for each device.

Narrow and Wide SCSI

The SCSI devices you will be installing can be either Narrow (8-bit) or Wide (16-bit) SCSI devices. Wide SCSI disk drives allow data to be transferred at twice the rate of older 8-bit devices. However, some SCSI devices such as tape and CD-ROM drives still use an 8-bit interface. This is not a problem because the Wide SCSI bus is backward compatible with Narrow SCSI devices, allowing both types of SCSI devices to be used on the same controller.

NOTE *You can mix Narrow and Wide devices on a single 16-bit SCSI cable. However, any Narrow devices must be attached to the bus ahead of any Wide devices. This ensures that the 16-bit signals are correctly terminated.*

Configuring Cables

SmartRAID V SCSI controllers contain a single Wide SCSI bus with one internal and one external SCSI connector. Each SmartRAID V SCSI controller kit contains a Wide, 68-conductor SCSI cable. This cable is for connections internal to the computer cabinet only.

SmartRAID V Fibre Channel controllers contain one Fibre Channel port with a single Fibre Channel connector. The SmartRAID V Fibre Channel controller requires a High Speed Serial Data Connector (HSSDC) cable. If you do not have an HSSDC cable, this cable is available from DPT or a cable supplier of your choice.

NOTE *Internal and external, Narrow and Wide SCSI cables, Fibre Channel cables, connector adapters and terminators can be purchased directly from DPT (you can use our online web store at www.dpt.com) or from a supplier of your choice.*

Configuring SCSI Termination

The devices on each physical end of a SCSI cable must be terminated. Depending upon how you configure your system, you will either terminate two SCSI devices, or the SCSI controller and one peripheral SCSI device.

NOTE *The SCSI cable supplied with your DPT controller has a factory-installed active terminator on the end of the cable.*


If you are using multiple SCSI busses on a single controller, each separate bus must be terminated.

SCSI termination for SmartRAID V controllers is configured through the SMOR utility or from the Configure Host Bus Adapter window in Storage Manager. The controller has four possible termination settings:


- | | |
|------------------|--|
| Auto | The default setting. This can be used for all cabling conditions except where a Narrow (8-bit) cable is attached to the controller. For this case use High Only. |
| Disabled | Turns off controller termination unconditionally. |
| Enabled | Turns on controller termination unconditionally. |
| High Only | Terminates only the additional signals that are used on Wide SCSI devices. This allows Wide and Narrow cables to be simultaneously attached to the controller. |

By using a 68-pin to 50-pin SCSI cable adapter, an 8-bit SCSI device can be attached to a Wide SCSI cable along with Wide SCSI devices. However, the device at the end of the cable must be a Wide SCSI device so that all SCSI signals are terminated. For internal and external cables where one cable is an 8-bit (Narrow) SCSI cable, set the controller termination to **High Only**.


The following illustrations show various SCSI cabling examples. Terminate your SCSI devices as shown in the examples, ensuring that only the devices at the ends of the cables are terminated.




SmartRAID V
Termination = **Auto**



SmartRAID V
Termination = **High Only**



SmartRAID V
Termination = **Auto**



SmartRAID V
Termination = **High Only**

T = Terminated

Configuring Device IDs

The SCSI specification allows up to 7 SCSI devices (and a controller) to be connected to a single 8-bit SCSI bus. A Wide SCSI bus can support up to 15 devices (and a controller). Up to 126 devices can be attached to a single Fibre Channel loop.

SCSI

All SCSI devices, including the controller, must be assigned a unique SCSI ID. SCSI IDs, which are typically set using jumpers or switches on peripheral devices, can be assigned any number from 0 to 7 for 8-bit SCSI devices or 0 to 15 for Wide SCSI devices. For more information on SCSI IDs, see Chapter 7, “Theory of Operation.”

Set the SCSI ID of each SCSI device attached to the controller to a unique ID number between 0 and 6. The SmartRAID V controller is set to ID 7 by default (most SCSI controllers use ID 7.) Wide SCSI devices can also use SCSI IDs 8 through 15. SCSI IDs can be duplicated on the same controller if the devices using the same ID are not attached to the same bus.

If necessary, the SmartRAID controller ID can be changed to any ID 0 – 7 by using SMOR or from the Configure Host Bus Adapter window in Storage Manager.

NOTE *Changing the controller ID is not recommended. You should leave the SmartRAID V controller at SCSI ID 7.*

Fibre Channel

DPT Fibre Channel controllers and their attached Fibre Channel devices are configured automatically during boot. Device IDs are assigned within the range 0 – 126 and cannot be changed manually.

Installation

NOTE *SmartRAID V Millennium controllers and Century or Decade controllers with an RA4050 module should have at least 16MB of cache installed.*

Several optional modules are available to upgrade the performance of your SmartRAID V controller:

- **RA4050 RAID Accelerator** – adds RAID 5, hardware XOR and cache memory capacity to the Decade and Century controllers.
- **SX4054U2 Bus Expansion Module** – adds SCSI channels to a SmartRAID V Decade or Century controller.
- **SX4055U2 Bus Expansion Module** – adds SCSI channels to a 64-bit SmartRAID V controller.
- **SX4055F Bus Expansion Module** – adds one Fibre Channel port to a SmartRAID V controller.
- **SM4050-16 (-64) ECC SIMM** – adds 16 or 64 MB of cache memory to SmartRAID V Millennium non-battery backup controllers or to SmartRAID V controllers using the RA4050 RAID Accelerator.
- **DM4050-16 (-64) or DM4060-16 (-64) ECC DIMM** – adds 16 or 64 MB of cache memory to SmartRAID V PM3755U2B controllers.
- **BB4050** – adds battery-backed cache capability to a PM3755U2B controller. The battery-backed cache must be DPT DM4050 or DM4060 memory modules. Non-DPT DIMMs are not compatible with the BB4050.

Installing the RA4050 RAID Accelerator


SmartRAID V Century controllers can be upgraded to support RAID 5, 0+5 and data caching by installing the RA4050 RAID Accelerator module.

A Decade (PM1554U2) controller has built-in RAID 5 and 0+5 support without an RA4050 module. Adding an RA4050 module to a Decade controller provides up to 64MB of cache and hardware XOR performance for RAID 5 operation.

NOTE *Century or Decade controllers with an RA4050 module must have at least one memory module installed on the RA4050.*

To install the RA4050 module:

1. Install the SIMMs in the SIMM sockets of the module. Refer to the section, “Installing SIMMs” in this chapter.
2. Attach the RA4050 module to the controller as shown in the diagram below. The plastic docking guides should lock into place. To remove the module, squeeze the plastic docking guides together and separate the module from the controller.



3. To confirm that the RA4050 and SIMMs have been properly installed, start SMOR and select the controller. The Information window should indicate the RA4050 is attached and display the amount of cache memory.

Installing an SX405x Bus Expansion Module

SmartRAID V controllers accept the following Bus Expansion Modules:

Model	Description
SX4054U2-1	Single Ultra2 SCSI Bus, 32-bit Expansion Module. Adds one SCSI bus with one internal and one external connector.
SX4054U2-2	Dual Ultra2 SCSI Bus, 32-bit Expansion Module. Adds two SCSI buses with two internal and two external connectors.
SX4055U2-1	Single Ultra2 SCSI Bus, 64-bit Expansion Module. Adds one SCSI bus with one internal and one external connector.
SX4055U2-2	Dual Ultra2 SCSI Bus, 64-bit Expansion Module. Adds two SCSI buses with two internal and two external connectors.
SX4055F	Single Fibre Channel-Arbitrated Loop, 64-bit Expansion Module. Adds one external Fibre Channel port (HSSDC).

SX4054 Bus Expansion Modules are intended for use with Decade or Century controllers. For a 64-bit Millennium controller, use an SX4055x Bus Expansion Module.

Up to 15 devices may be attached to each SCSI bus. Up to 125 devices can be attached to the SX4055F Fibre Channel Bus Expansion Module.


Additional information about Ultra2 SCSI and Fibre Channel can be found in Chapter 7, "Theory of Operations."

NOTE *If the SX4054/SX4055 has been properly installed, it will be listed by SMOR when the controller is selected. See Chapter 4, "Storage Manager on ROM" for additional information.*


To install an SX4054/SX4055 module:

1. Remove the module mounting bracket from the end of the module. Keep the bracket screws.
2. Attach the module to the controller, connecting P5 on the SX405x to J7 on the controller. Refer to Appendix A, "Assembly Drawings" for connector locations.

NOTE *SX4055 modules have two connectors (J7 and J8) that must align correctly when installing the expansion module on a Millennium 64-bit controller.*



3. Install the new module mounting bracket (with additional holes for the added external connectors) and secure with the screws from Step 1 above.



4. Install the card in an available PCI slot and attach the mounting bracket to the slot opening in the host system.

Installing SIMMs

SmartRAID V PM3754U2 and PM3755F Millennium controllers support up to 256MB of cache using four onboard SIMM sockets. One to four memory modules of the same type and capacity can be installed.

SmartRAID V Decade and Century controllers can use up to 64MB of cache provided by the SIMM sockets on an RA4050 module. One to four SIMMs of the same type and capacity can be installed.

IMPORTANT

All installed SIMMs must be the same type and capacity.

Do not mix SM4050 ECC SIMMs and non-DPT SIMMs.

Do not use DPT SmartCorrect SM4000 SIMMs.

NOTE

PM1554U2 controllers have 4MB of onboard cache.

RA4050 maximum cache memory can be a single 64MB SIMM, or four 16MB SIMMs. You can use less than 64MB of memory; however, you must install at least one 16MB SIMM.


ECC protected cache requires DPT SM4050 SIMMs. The ECC Enabled LED on the controller is lit when DPT SIMMs are installed.

To install SIMM modules:

1. Install the SIMMs in the sockets as shown starting with socket 1. Refer to Appendix A, “Assembly Drawings” for socket locations. Be sure the SIMM is fully seated and locked in the socket.

Although standard 32- or 36-bit 16MB or 64MB low-profile single-sided 60ns EDO SIMMs can be used, DPT recommends that you use DPT SM4050-16 or -64 ECC SIMMs for maximum data integrity.

2. To confirm that the SIMMs have been properly installed, use SMOR to view the amount of cache memory reported when the SmartRAID V controller is selected.



Installing DIMMs

IMPORTANT

All installed DIMMs must be the same type and capacity.

At least one DIMM must be installed.


Use only DPT DM4050 or DM4060 DIMMs.

Do not use DPT SmartCorrect DM4000 DIMMs.

The SmartRAID V Millennium model PM3755U2B has four onboard DIMM sockets for cache memory. The green ECC Enabled LED on the controller is lit when ECC-capable DIMMs are installed.

To install DIMM modules:

1. Install the DIMMs in the sockets as shown starting with socket 1. Refer to Appendix A, “Assembly Drawings” for socket locations.
2. To confirm that the DIMMs are properly installed, start SMOR and select the SmartRAID V controller to display the amount of cache memory reported.



Installing the BB4050 Battery Backup Module


The BB4050 Battery Backup Module is used only on a PM3755U2B Millennium controller.

To install the BB4050 Module:

1. Before installing the BB4050 module, be sure the battery pack electrical connector is plugged in the socket on the BB4050 board.
2. Align the Battery Backup Module and the Millennium controller as shown in the illustration.
3. Install the three fasteners through the appropriate holes in the Millennium controller and into the matching posts in the Battery Module. Tighten the fasteners.

IMPORTANT

Do not overtighten the fasteners; it can damage the circuit board.



Installing the Controller

1. Connect the computer's disk activity LED cable to connector P6 on the controller. See Appendix A, "Assembly Drawings" for the location of this connector.

Pins 1 and 3 of P6 are connected to +5V and pins 2 and 4 are connected to GND. Ensure that the positive lead of the LED cable (usually a red wire or marked with a red stripe) is attached to pin 1 or 3 and the negative lead (usually a black wire) is attached to pin 2 or 4.

2. If you are using the internal SCSI cable, connect this cable to the controller.
3. Install the controller in an available 32- or 64-bit PCI bus slot and secure the controller bracket to the host system cabinet with the screw provided.

In a system with multiple controllers, the controller that has the lowest BIOS ROM address (typically, the lowest numbered PCI slot) will become the booting controller. Refer to the "Determining the Booting Controller" section for more information.

4. Connect any external cables to the controller.

NOTE

If you have disk drives attached to a SCSI controller with a Symbios chipset, use SMOR to set the Bootable Devices option to Disable.

Determining the Booting Controller

The controller whose BIOS has the lowest address will take control over the boot process and that controller will become the booting controller. Therefore, in a system with multiple controllers, you must ensure that the DPT I₂O BIOS occupies the lowest address if you want the DPT controller to be the booting controller.

- In systems with multiple DPT SmartRAID V controllers, the DPT controller in the lowest PCI slot number will be assigned the lowest BIOS address, and will be the booting controller.
- In systems with both SmartRAID IV and SmartRAID V controllers BIOS addresses are assigned in a system dependent manner. In this case, the booting controller can be determined by observing the system messages during the boot process.

If your system contains multiple DPT controllers, you can confirm which controller has been chosen as the booting controller by running SMOR. This utility will display a list of all DPT controllers, starting with the booting controller.

Controller IRQ and Address

During the host system boot process, the host system BIOS should automatically configure the DPT I₂O BIOS interrupt level (IRQ) and memory location for all DPT PCI controllers in the system. If problems occur, refer to Appendix B, “Troubleshooting” for additional help.

NVRAM Reset

SmartRAID V controllers retain their setup parameters even when powered off. These parameters are stored on the controller in an area of nonvolatile memory (NVRAM). There is a possibility that, through improper configuration, the controller can be put into a state where it hangs the system during boot. If this happens, the parameters stored in the NVRAM can be restored to their default settings by the following procedure:

1. Turn off power to the system.
2. Place a shorting jumper across pins 1 and 2 of P4 on the controller. Refer to Appendix A, “Assembly Drawings for the location of P4 on your controller.
3. Power on the system and wait until LEDs 3, 5, 7 and 8 on the controller begin flashing.
4. Turn off power to the system and remove the jumper.
5. Restart the host system. If the system restarts normally, the controller can now be configured using SMOR or Storage Manager.

If the system fails to boot, refer to Appendix B, “Troubleshooting” for additional information.

Using Microsoft Cluster Server

The information presented in this section is intended to help you configure SmartRAID V controllers and a storage subsystem for host systems that use Microsoft Cluster Server (MSCS) to provide fault-tolerant network server resources. For specific information about installing and configuring MSCS support on your Windows NT server, refer to the *Microsoft Cluster Server Administrator's Guide*.

MSCS lets you create a *server cluster*, that is two servers sharing a common storage subsystem. Both servers can provide resources to clients. However, they cannot both provide the same resources. If one server should fail, the other server can take over the resources of the failed server. This is called *failover*. The MSCS software on both servers manages the switchover if one server should experience a system failure. The storage subsystem controller in each server must also be able to respond to the switchover and transfer the responsibility for I/O requests from the failed server to the remaining server.

Clients do not see the individual servers in a cluster. They are presented with a virtual server that contains the specific resources they require.

MSCS provides the following advantages for network servers:

- Availability

MSCS automatically detects the failure of an application or server and restarts its resources on the other server. Users will experience only a brief interruption in service.

In some cases it might be necessary for users to log on again when the standby server assumes control. Refer to the *Microsoft Cluster Server Administrator's Guide* for additional information.

- Manageability

MSCS lets administrators view the status of cluster resources and move the server workload onto different servers within the cluster as necessary. This allows an administrator to perform manual load balancing or rolling updates on the servers without taking data storage or applications offline.

System Requirements

DPT SmartRAID V controllers include support for MSCS host configurations. To use Microsoft Cluster Server with a SmartRAID V controller you need to do the following:

- Use host systems that conform to the Microsoft Hardware Compatibility List for MSCS.
- Install Windows NT Advanced Server Enterprise Edition 4.0 (with Service Pack 5 or later) or Windows 2000 Advanced Server on both server systems.

Windows NT Workstation 4.0 does not support MSCS.

- Install and configure Microsoft Cluster Server software on both host systems.
- Connect the servers using a TCP/IP network. This connection is used by MSCS software to monitor the server operation and detect failures.

A static IP address is required for each server in the cluster. You cannot use DHCP address assignment with MSCS unless you use the DHCP server to assign the static IP addresses for MSCS resources. You can use WINS or DNS to provide computer name to IP address conversion. Refer to the *Microsoft Cluster Server Administrator's Guide* for additional information.

- Create a server cluster with two host systems that have SmartRAID V controllers that are connected to a common storage subsystem. The shared storage must use the NTFS file system.

NOTE

Only one server can control the storage subsystem under MSCS. Any changes to the storage subsystem must be made from the console for the server that currently owns the subsystem.

Do not install the server operating system on the storage that uses the shared SCSI bus.

- Enable Microsoft Cluster Server support on both SmartRAID V controllers. See Chapter 4, “Storage Manager on ROM” for information about activating SmartRAID V support for MSCS.

NOTE

Because the storage subsystem and controllers are on a common SCSI bus, both controllers must have a unique SCSI ID. To ensure they receive the highest priority for SCSI bus access, use SCSI ID 7 (the default) for one controller and SCSI ID 6 for the other controller. You can use SMOR to change the SCSI ID assigned to a controller.


How SmartRAID V Works with MSCS

When MSCS is operating on a server cluster, the servers continuously send a *heartbeat* to each other across the private network connection. When a server does not receive this signal for a preset interval, it automatically begins the failover process of providing the resources of the failed server and takes control of the storage subsystem.

When the transfer is complete, the failed server remains offline until the problem that caused the failure is corrected. When the failed server is restored, MSCS can initiate a *failback* operation so that the second server releases its control of the other server's resources and the previously failed server begins servicing client requests for its assigned resources.

A logical array that is deleted can continue to appear as available in a Storage Manager remote session from the other server in the cluster or from a remote client. The cluster servers must be restarted to ensure that the deleted array does not continue to be reported as available.

NOTE *Both SmartRAID V controllers must be connected to the shared storage subsystem using special cables that include pass-through termination. These cables can be purchased from DPT.*



CHAPTER 4:

Storage Manager on ROM

Storage Manager on ROM (SMOR) is a BIOS-based setup utility that lets you configure your DPT SmartRAID V controller without starting an operating system and using Storage Manager. You can also use SMOR to perform basic array configuration. SMOR makes the initial setup of your SmartRAID V controller and RAID storage easier and faster.

Run SMOR

Run SMOR by pressing **Ctrl+D** during system boot.

Configure your Controller

Use SMOR to set the hardware options on your controller. You can view the configuration of the storage subsystems, low-level format disk drives, and configure the DPT I₂O BIOS on your SmartRAID V controller.

Create Disk Arrays

Use SMOR to create disk arrays; install your operating system and your SmartRAID V system is ready to use.

Overview

To configure your hardware and create disk arrays when Storage Manager is not available, run Storage Manager on ROM (SMOR) during the system boot. This is especially useful for a new system where you need to create disk arrays before you install the operating system.

After your storage subsystem is configured, install your operating system according to the appropriate procedure in Chapter 5, “Software Installation”. For access to all of the advanced features of your controller, install the version of Storage Manager specific to your operating system.

Follow these steps to run SMOR and configure a new system:

1. Press **Ctrl+D** when the DPT BIOS message appears during boot to start SMOR.
2. Inspect the hardware configuration as shown by SMOR.
 - a. Verify that all peripheral devices and controllers are shown. If any devices are missing from the display, exit SMOR and check your hardware connections.
 - b. View the Information window for each controller to verify that all installed expansion and memory modules are shown. Note the IRQ and Address displayed in the Configuration window. The IRQ and Address values may be required during installation of your operating system.
3. Create disk arrays (see Array Operations in this chapter). Array Groups can be created or modified at any time after system installation. However, if the boot device will be an array, that array must be created before the operating system is installed.
4. Exit SMOR when you are finished with the configuration tasks.

Arrays that were created or modified start building at this time. For large arrays, this process may take several hours. You can perform other activities on the system while the build operation continues.

The array groups being built can be accessed while the build is in progress. However, access time will be slower until the build is complete.

If you have exited SMOR and you want to monitor the progress of the build operation, you can view the Array Group Information window for the array in Storage Manager. See Chapter 6, “Storage Manager” for additional information.

Keyboard Reference

The navigation keys work in a similar fashion to those of Windows Explorer. Use these keys to move around in SMOR:

Menu Control

Alt + (Menu Highlight)	Select the corresponding menu or menu item.
Enter	Initiate an action.
Up/Down Arrows	Move between menu choices.
Esc	Return to Tree View.

Left Pane - Tree View Control

Up/Down Arrows	Move between elements within the tree.
Left/Right Arrows	Scroll the tree left and right.
+	Expand the current branch, showing the devices attached to it. The element must be preceded by +.
–	Collapse the current branch. The element must be preceded by –.
Tab	Move to the right pane — Information View.

Right Pane – Information View Control

Alt + (tab highlight)	Select and go to the corresponding Tab Page within the Information View.
Tab	Move to the next field in the window.
Shift-Tab	Move to the previous field in the window.
Space	Select or deselect an item (check-boxes or radio buttons).
Up/Down Arrows	Change a combo-box (indicated by ↓) value.
Esc	Return to Tree View.

Menu Reference

The SMOR Main Menu changes dynamically depending on what is selected in the tree view. The following is a complete list of possible selections:

FILE

Read System Config	Rescan the system – unsaved configuration changes are lost.
Set System Config	Save and enable configuration changes.
Exit	Quit SMOR.

RAID

Create...	Create a new array.
Delete	Delete the currently selected array.
Rebuild	Rebuild a RAID 1, 5, 0+1 or 0+5 array.
Stop Build	Stop building or rebuilding an array.

ACTION

Make Hotspare	Designate the currently selected drive as a Hot Spare.
Remove Hotspare	Make the currently selected Hot Spare available for use by the operating system.
Format Drive	Low-level format a currently selected drive.
Flash HBA	Update the firmware, I ₂ O BIOS or SMOR image in controller ROM.
Save Firmware	Save the controller BIOS, firmware and SMOR images to a bootable diskette.

HELP

About...	Display information about SMOR.
Help	Display basic help information.

Icon Reference

SMOR uses the following icons in Tree View:

Controller



Disk



CD-ROM



Array



Tape




Other Device



Screen Layout

The SMOR interface works like the Windows Explorer tree-structured interface. The screen is divided into three major components: a menu bar across the top of the screen and two display panes below the menu bar.



The Menu Bar

To open a specific menu, press **Alt+(highlighted letter of the menu name)**. After a menu is open, you can select a specific menu item by pressing the key for the letter highlighted on the menu item. For example, to select the **Read System Configuration** item on the File menu, press **Alt+F** to open the File menu, then press **R** to select **Read System Configuration**.

NOTE *Depending on your configuration, not all menu items may be available. Unavailable menu items are shown in a low-contrast color.*

The Left Pane – Tree View

The *Tree View*, displayed in the left pane, is the central control for SMOR. This view displays a tree structure that represents the organization of the DPT storage subsystem. This includes DPT controllers, storage devices and arrays detected by SMOR. By moving the highlight with the up and down arrows, you can select items you want to view or configure. As items are highlighted, the associated information on the item is displayed in the Information View (display pane on the right side).

If an item in the Tree View is preceded by **+**, pressing the Enter or **+** key expands the tree, showing the devices associated with or attached to that item. If an item is preceded by **-**, pressing the Enter or **-** key will collapse that portion of the tree, hiding the devices under that item.

If the text for an item is larger than the width of the Tree View pane, you can scroll the pane horizontally by using the left and right arrow keys.

The Right Pane – Information View

To the right of the component tree is the Information View pane. This view displays information related to the currently selected item in the tree. The specific information displayed in the Information View varies depending on the item selected. When there are separate types of information available for the selected item, the Information View is separated into *Tab Pages*. Tab Pages are generally information or configuration parameters that are related to the selected item.


To select a specific Tab Page within the Information View, press **Alt+** (**the highlighted letter on the tab**). For example, to change to a controller's Configuration tab, press **Alt+C**. You can also press the **Tab** key when in the Tree View to move over to the currently displayed Information View tab page. On a tab page within the Information View, you can move between the items with the **Tab** or **Shift+Tab** keys. See the Keyboard Reference section in this chapter for additional details on changing between the Tree and Information Views, using the menu bar, and navigating within the SMOR interface.

Within the Information View, you select an item to configure by using the **Tab** or **Shift+Tab** keys to move the highlight to the item. Items that cannot be selected are shown in black. The way in which you change an item depends on the type of control associated with it. Check-boxes are toggled by using the **Spacebar**. List-box items (for example, SCSI Transfer Rate) are changed using the up and down arrow keys. List-box items can be recognized by the downward pointing arrow at the right of the item.

To leave the Information pane and return to the Tree View, press **Esc**. If you have changed the configuration, you are prompted: Save changes?. Press **Tab** to select Yes or No and press **Enter**.

NOTE *The items shown in the Information View, and the settings for those items, will vary depending on the particular type of controller, device or array selected in the Tree View.*

Running SMOR



Start SMOR by pressing **Ctrl+D** when the DPT I₂O BIOS message appears on the screen during the boot sequence.

The letters that appear during the initial device scan process are:


- C CD-ROM
- D Disk drive
- E Scanner, SAFTE or intelligent RAID enclosure, or a second controller (MSCS).
- H Hot spare drives
- T Tape device
- 0, 1, 5 Physical arrays identified by the RAID level

The position of a letter corresponds to the SCSI ID assigned to that device.

Information/Configuration Windows

When you highlight an item within the Tree View, the corresponding Information View is displayed.

DPT I₂O BIOS Settings



The example above is the default Information View when SMOR starts. The settings in this view affect the DPT I₂O BIOS and all the DPT controllers in your system. To view or change these settings, highlight DPT Configuration in the tree.

Controller Parameter	Default	Optional Settings
Bootable Devices	Normal	Disable
Enable Bootable CD-ROMs	Disabled	Enabled
DOS/Windows 3.1 Cache Setting	Write Through	Write Back
Scan Delay	1 second	1, 10, 20, 30 seconds
Smart ROM Options:		
EBDA Relocation	Disabled	Enabled
Enable Extended Int13	Enabled	Disabled

Bootable Devices

These settings let you modify the system boot process for host systems with multiple peripheral controllers in cases where the DPT I₂O BIOS does not provide effective or appropriate default operation.

The default setting causes the system to follow the order described in the Determining the Booting Controller section of Chapter 3. If you select Disabled, DPT controllers are not used as boot devices.

If you select Enable Bootable CD-ROMs, the DPT controller attempts to detect a bootable CD-ROM that uses the *El-Torito* format.

NOTE *This option is disabled by default, because some bootable CD-ROMs contain device-specific boot code that will not work with DPT controllers.*

DOS/Windows 3.1 Cache Setting

This parameter determines how the controller responds to Int13 write commands under DOS, Windows 3.1 and certain operating system installation programs. The default is Write Through to avoid problems that can occur during operating system installation if Write Back caching is enabled. After the operating system is installed, you can change to Write Back caching for improved performance.

Change this setting back to Write Through during future operating system installs or upgrades to avoid problems.

NOTE *The cache setting has no effect on controller cache operation under Windows NT, UNIX or NetWare.*

Scan Delay

Some SCSI devices require a time interval between power on and SCSI bus reset and scan or they do not respond correctly. If devices are not displayed in the Tree View after power on, set the delay to a longer interval.

EBDA Relocation

This setting determines the way that SmartRAID V controllers handle Extended BIOS Data Area (EBDA) relocation. You can enable this feature to help avoid conflicts with other adapter cards if the controller is installed in a host system with other adapters that follow standard EBDA relocation rules.


Enable Extended Int13

This setting enables extended logical block addressing (LBA) for disk devices. Logical block addressing enables operating system access to disks larger than 8.6GB. You should not change this setting.

Controller Information Windows

To view or change the configuration of a DPT RAID Controller, highlight the controller in the Tree View. Two tabs are available: *Information* and *Configuration*.

Controller Information Tab



The Information Tab for a Controller displays general information reported by that controller. Some of the fields have special conditions:

Model	DPT controller model number
Serial #	Controller serial number
Cache	Amount of cache memory installed
Revision	Controller firmware version
FW Type	Firmware type
ECC	Yes (if DPT ECC memory is used)
SCSI Bus:	
Width	Bus width (8-bits or 16-bits)
Busses	Number of busses on the controller
SCSI ID	SCSI ID assigned to the controller
Transfer	Maximum possible bus transfer rate

Host Bus:

Bus Type	Always PCI for SmartRAIDV
Transfer	Host PCI bus transfer rate. 132 MB/sec for 32-bit PCI bus 264 MB/sec for 64-bit PCI bus
Attached Modules:	Identifies the expansion modules and cache memory modules installed.

Attached Modules can be reported as:

SX405xU2-1, SX405xU2-2	SCSI Expansion Module*
SX405xF	Fibre Expansion Module*
RA4050	RAID Accelerator
BB4050	Battery Backup Module


*Bus Expansion Modules are always reported as either SX405xU2 or SX405xF. SMOR is not able to determine which specific model is attached.

Memory modules are reported as:

Bank n: nnMB ECC

Starting with Bank 0. ECC is displayed only when ECC memory is used.

HBA Configuration Tab



To modify the hardware parameters for the highlighted SmartRAID controller, press **Alt+C** to display the Configuration tab.

Select **Default** to reset the parameters on this tab to their default values.

NOTE *Depending on the specific hardware, some items displayed in the Configuration tab may be read-only.*

The settings are subdivided according to which parameters relate to the individual peripheral bus and which parameters relate to the entire controller.

Controller Parameter	Default	Optional Settings
Bus	N/A	0, 1, 2
ID	7	0 – 6 (SCSI) 0 – 126 (Fibre)*
TERMPWR	Enabled	Disabled
Termination:	Auto	On, Off, High Only
SCSI Xfer Rate (in MHz)	Auto	80, 40, 20, 10, 8, 5, Asynchronous

* Fibre Channel IDs are display only. They cannot be changed.

Bus

Each peripheral bus on a controller is assigned a number starting at 0.

SCSI ID

SmartRAID V controllers are configured by default at SCSI ID 7. This value should not be changed unless required for special configurations.

NOTE *Fibre Channel IDs can be 0 – 126. However, these IDs are configured dynamically and cannot be changed using SMOR or Storage Manager.*

TERMPWR

By default SmartRAID V controllers supply termination power for other SCSI devices through the TERMPWR line on the SCSI cable. If you want to change this setting, refer to the TERMPWR section in Chapter 7, “Theory of Operation” for more information.

Termination

This setting controls the SCSI termination for the controller and bus. The default value (**Auto**) should not be changed, unless both internal and external cables are attached to the controller or you are using an 8-bit (Narrow) cable. Refer to the Configuring SCSI Termination section in Chapter 3, “Configuration and Installation” for information on setting this parameter.

NOTE *Termination is not used for Fibre Channel controllers.*

SCSI Xfer Rate

DPT controllers automatically negotiate with each SCSI device at power-up or reset to set the maximum SCSI transfer rate. This parameter limits the SCSI transfer rate to the value selected. This setting should not be changed except when you are troubleshooting SCSI bus errors.

NOTE *If setting this parameter to 5MHz eliminates SCSI bus data errors, this is usually an indication that the SCSI bus is too long or that the bus is not terminated correctly.*


PCI Xfer Rate**Mem Address****IRQ**

These are display only fields for information purposes. The values in the Mem Address and IRQ fields may be needed when you configure your operating system.

Cluster Server Enable

This option enables or disables support for Microsoft Cluster Server configurations using the selected controller. Do not enable this option unless you are creating a cluster server configuration.

Device Information



Individual devices are listed in the Tree View under the controller to which they are connected. Highlight a device to view its configuration information.

The Device Information view displays general device information and hardware configuration. This view is divided into three parts: Identification, Capabilities and Status. Progress shows a numeric percentage of completion for active tasks.

Identification

The Identification section displays a general description of the highlighted device:

Description	The manufacturer name and model number as reported by the device, followed by the icon for the device.
Revision	The device firmware revision.
Address	The address of the device, in the form HBA <i>n</i> , Channel <i>n</i> , ID <i>n</i> , LUN <i>n</i> .
Capacity	The capacity of the device in megabytes. For removable media disk devices, the capacity reported is for the currently inserted media, or No Media Inserted if no media is inserted. Tape drives do not report media insertions.
Removable	As reported by the device
Read Only	As reported by the device
Block Size	Block size reported by the device.
Negotiated	Bus speed negotiated between the device and controller.
Transfer Rate	Maximum transfer rate for the negotiated bus speed and data path.

SCSI Capabilities


The capabilities section is a list of the capabilities defined in the SCSI specifications. A checkmark indicates that the device supports that SCSI function.

Status

The following status conditions can be indicated for attached devices:

Dead	The device failed to respond to controller commands. If the device becomes available it will only change status after the system configuration is read or the host is restarted.
Failed	A drive failure has occurred.
Impacted	An operation is being performed that results in performance degradation in response to server I/O requests.
Missing	The drive is physically missing or will not respond to commands on the device bus.
Optimal	The device is fully functional.
Uninitialized	The drive is operational but has not been initialized as a member of an array.
Verify	A Verify operation is being performed on the array. I/O performance will be affected.
Warning	This status indicates that failure may be imminent on a device with S.M.A.R.T. failure prediction.

Array and Array Group Information



SmartRAID V controllers implement RAID 0, 1 or 5 disk arrays in hardware. RAID 0 arrays are composed of any combination of individual drives. RAID 1 arrays are always composed of two drives. RAID 5 arrays contain three or more drives.

After the arrays have been created, one or more arrays of the same RAID level can be combined into a *Parity Group* (see the Creating a Parity Group section). Arrays are striped into Parity Groups by the controller firmware. All the drives in an array or Parity Group must be attached to the same controller, and appear to the host as a single Logical Storage Unit (LSU).

The Information window for any array may be viewed by highlighting that array.

NOTE *Arrays do not start building until a Set System Configuration action has been performed.*

The Array Information window displays general array information and hardware configuration. It is divided into three parts: identification, SCSI Capabilities and Status.

Identification

The identification section displays a general description of the highlighted array:

Description	The RAID level used for the array.
Revision	The firmware revision of the controller to which the array is attached.
Address	The address of the array, in the form HBA <i>n</i> , Channel <i>n</i> , ID <i>n</i> , LUN <i>n</i> . Arrays are always assigned the lowest logical address of any device in the array. This field displays as much information as is necessary to unambiguously define the address of the array.
Capacity	The usable capacity of the array in megabytes. The available capacity of an array depends on the RAID level of that array.
Removable	As reported by the devices in the array.
Block Size	Displays the sector (block) size for the selected device in bytes. For disk drives, this value should be 512. If the value is not 512, use SMOR to perform a low-level format and create 512 byte sectors.
Stripe Size	Displays the stripe size used to create the array.

SCSI Capabilities

This section displays the SCSI capabilities of the array, as reported to the operating system. The capabilities reported depend on the devices that were used to create the array.

Status

This field displays the current status of the array. A progress indicator (a numeric percentage of completion) can also appear if the array is Building or Rebuilding. See the following table for array status definitions.

Building	The array is being built.
Created	The array or device is defined but not initialized.
Dead	A write-back cache to the array command failed. This is an unrecoverable failure.
Degraded	A single drive in the array has failed; array performance is affected.
Impacted	A verification is being performed on the array; I/O performance is affected.
Missing	A drive is physically missing or will not respond to commands on the device bus.
Optimal	The array is fully functional.
Pending	The array has been created and the build is queued on the controller; but is not yet started.
Rebuilding	Data is being rebuilt onto a drive in the array.
Warning	This status indicates that a drive in a fault tolerant array has failed and the next drive failure will cause loss of the array.

Setting the Configuration

There are two configuration options on the File menu:

Read System Config	Causes SMOR to rescan to detect any changes in hardware configuration or status. Any changes that have been made and not saved are lost. This operation is run automatically when SMOR is started.
Set System Config	Causes SMOR to save changes that have been made to the storage subsystem configuration in the controller memory. If any array groups or parity groups have been created or modified, this operation causes the controller to initiate a build operation on the new groups.

Array Operations

You can use SMOR to create or manage disk arrays. The following sections describe how to use SMOR to create arrays and parity groups, delete arrays, assign hot spare drives, and rebuild an array.

Refer to the Chapter 7, “Theory of Operation” for a complete discussion of RAID levels and disk arrays.

Creating an Array

To create an array:

1. Select RAID—Create.

RAID type:

RAID-0 (No fault tolerance)

RAID-1 (Fault tolerance, Higher performance)

RAID-5 (Fault tolerance, Higher capacity)

Stripe size: 16 KB

2. When the RAID Type dialog appears, select the RAID level you want to use. The Stripe size is selected automatically; however you can select a different stripe size value by highlighting the field and using the up and down arrow keys to change the stripe size.

NOTE

Although you can change the stripe size, DPT recommends using the default value. This value has been selected for optimum performance based on the type of disk array you want to create.


When you are ready to proceed, select OK.

The Eligible Devices list will appear. Devices on this screen can be either individual disk drives or previously created array groups. Array groups appear in the list when you select RAID 0 and eligible array groups exist.


3. Select the devices you want to include in the array:
 - a. To add devices to the array, highlight the device and press the **Spacebar**. A checkmark appears next to the device to indicate that it has been selected.

You might need to scroll the display down to view all eligible devices.

- b. To remove a previously selected device from the array, highlight the device and press the **Spacebar**.



4. When you are finished selecting drives for the new array, select Done.
5. If you are creating a RAID 1 array, the RAID-1 Build Option dialog appears.



RAID 1 arrays are built by copying the existing data from one device to the other. Select the direction for the copy, then select OK.

6. Select File–Set System Config to start the build process. The array you have created will begin building at this time. If you have created multiple arrays, they are built serially in the order they were defined.

Alternatively, you can exit SMOR. You will be prompted to save the configuration changes. If you choose to save the configuration and have defined arrays, the build process will begin.

For large redundant arrays, the build process can take several hours to complete. You can exit SMOR and perform other activities on the system while the build continues. An array being built can be accessed during the build process.

If you exit SMOR and you want to monitor the progress of the build operation, you can use the Array Group Information window for the array in Storage Manger. See Chapter 6, “Storage Manager” for additional information.

Creating a Parity Group

Creating a parity group (RAID 0+1 or 0+5) is similar to creating a normal RAID 1 or RAID 5 array group. Do the following to create a RAID 0+1 or RAID 0+5 parity group:

1. Create and build your array groups as described in the preceding section (Creating an Array).
Do not initiate the build process on any arrays that you intend to use in a parity group.
2. After your initial array groups are created, select RAID—Create again.
3. Select RAID 0 for the RAID type and click on OK.
4. Select two or more arrays of the same type from the Eligible Devices list and click on Done.

NOTE *You cannot combine arrays that use different RAID levels.*

5. Select File—Set System Config to begin the build process for the parity group.

The Tree View will display the parity group LSU as:

(x,x,x,x) FW RAID-0


with the array groups that were striped together listed where disk drives would normally be listed. Selecting an array group component will branch to the disk drives for that array group. The LSU address will be the lowest address of the array logical addresses that make up the parity group.

Deleting an Array

To delete an array, follow the steps below:

1. In the left pane, highlight the array that you want to remove, then select RAID–Delete.
2. You will be warned that all data will be lost. Choose Yes or No.

The array configuration for the devices is not deleted until you select File–Set System Configuration or exit SMOR and choose to save your changes.



Hot Spares

Any disk drive not assigned to an array or in use by the operating system can be designated as a Hot Spare. Hot Spares automatically replace failed drives in RAID 1 or RAID 5 arrays and are not accessible by the operating system for other use. A Hot Spare can protect drives of equal or lesser capacity attached to any peripheral bus on the same controller.

To assign a drive as a Hot Spare:

1. Highlight the drive you want to use in the left pane.
2. Select Action–Make Hotspare.

Selecting Action–Remove Hotspare will cause the selected Hot Spare drive to be reassigned as a normal disk drive which is accessible by the operating system.

Refer to Hot Spares in Chapter 6, “Storage Manager” for additional information.

Rebuilding a Failed Array

If a drive in a RAID 1 or RAID 5 array fails and the drive is not protected by a Hot Spare, use the following procedure to replace the failed drive.

1. Remove and replace the failed drive according to the procedures in your hardware documentation.
2. When the failed drive has been replaced, choose RAID–Rebuild Array to start the rebuild process.

The status of the array will change to Rebuilding (view the Information window for that array). When the rebuild is complete, the array status will change to Optimal.

NOTE *A DPT RAIDstation enclosure will automatically detect the replacement of a failed drive and initiate a rebuild operation as soon as the new drive is online.*

Formatting a Drive

Formatting SCSI hard drives is not normally required. However, if you have a drive that was previously formatted with a sector size other than 512 bytes you must change the format to 512-byte sectors before you can use the drive with a SmartRAID V controller. You can use SMOR to start a low-level format operation and create a 512 byte/sector format.

IMPORTANT

Do not remove power from the drive until the format operation is completed. Doing so can cause some drives to be left in an indeterminate state that will require return to the manufacturer for repair or replacement.

Low-level formatting large capacity drives can take considerable time. Do the following to start a low-level format for a disk drive:

1. Highlight the drive to be formatted.
2. Select Action–Format Drive.
3. Select OK and confirm.

To determine if the format has completed, view the Information window for that drive.

Managing Controller Firmware

SMOR includes several features that let you upgrade, save and restore the firmware on your SmartRAID V controller. These options are listed on the **Action** menu when a controller is selected in the Tree View.

The **Flash HBA** feature lets you install the latest DPT controller firmware, I₂O BIOS and SMOR utility software. The **Save Firmware** feature lets you save the current controller firmware, I₂O BIOS and SMOR software along with the NVRAM settings to a floppy disk. This disk can be used to restore the controller or copy the firmware, I₂O BIOS, SMOR and NVRAM to another controller.

Upgrading Firmware

The SmartRAID V controller firmware, DPT I₂O BIOS and SMOR utility are contained in flash ROM and can be upgraded by using SMOR. Each component must be upgraded as a separate operation.


- Firmware image upgrades are contained in a xxxxxxxx.FWI file, where the 8-character file name consists of the 4-digit controller model and a 4-digit release number.
- DPT I₂O BIOS images are contained in a file named I2OBIOS.xxx (where, xxx is the version number).
- SMOR updates are contained in a file named SMORyyyy.xxx. Where, yyyy is the build number and the file extension (xxx) is the version number.
- The default NVRAM settings are contained in the file DPTV1_0.NVR.

DPT periodically releases updated firmware, I₂O BIOS and SMOR software. You can obtain the latest files by contacting DPT Technical Support or from our FTP site at <ftp.dpt.com>.

NOTE *It is much easier to perform the following procedure if the image files are placed in the root directory of a diskette.*

Do the following to upgrade controller NVRAM, firmware, I₂O BIOS, or SMOR utility:

1. Place the diskette containing the image files in the diskette drive of the system where the controller is installed.
2. In the Tree View, select the controller that you want to update.
3. Select Action–Flash HBA. The source file browser will appear.



4. Select the diskette drive in the source file browser window and press Enter to expand the drive listing.
5. Highlight the image file you want to use and select OK to update the controller flash ROM.

After the controller reads the image, it will display the version number of the component you selected.

Select Yes to confirm.

6. A progress indicator will appear showing the progress of the different stages of the flash operation.

If the operation does not complete successfully, refer to the procedures for recovering from an incomplete or failed flash ROM upgrade in Appendix B, "Troubleshooting".

Saving Controller Firmware to a Disk Image

This feature provides you with a way to save the current ROM software and NVRAM settings for your controller to a bootable diskette. The resulting diskette is a bootable disk and contains a copy of the three controller software components: firmware, I2O BIOS and SMOR. The utility also saves the current and default NVRAM settings.

The diskette will contain the following files:

SMORbbb.vvv

Where bbbb is the build number and vvv is the version.

I2OBIOS.vvv

Where vvv is the version.

ffffvvbb.FWI

Where ffff is the adapter firmware type (ffff can be "3754" or "2554"). vv is the version and bb is the build.

CURRENT.NVR

The current NVRAM settings for this controller.

DEFAULT.NVR

or

vvvvvvvv.NVR

Default NVRAM settings. vvvvvvvv is the specific version of the default NVRAM settings if previously named.

SMORSbbb.vvv

This file is used to guarantee that the diskette will boot if there is no current SMOR image available on the controller. (Where bbb is the build number and vvv is the version of the in-memory copy of SMOR.) The build and version may or may not be identical to the SMOR image copied from the flash memory of the controller.

Creating a Firmware Disk Image

To create the firmware backup diskette:

1. Press **Ctrl+D** when the DPT I2O BIOS banner appears during system startup to start SMOR.
2. Move the highlight to the controller that you want to backup.
3. Insert a blank, formatted diskette into the host diskette drive.

NOTE *This operation overwrites the entire diskette. Any existing data is erased.*

4. Press **Alt+A** to select the Action drop-down menu.
5. Select Save Firmware. Press **Tab** to highlight Yes when prompted. Press **Enter** to begin the flash update.

The operation starts immediately. SMOR displays a progress bar and numerical percentage of completion. When the operation is complete you can exit SMOR and start the system normally.

Restoring Firmware from a Disk Image

To use the firmware backup:

1. Insert the diskette with the backup images into your diskette drive.
2. Power on or restart your system. The system will boot from the diskette and start SMOR automatically.
3. Highlight the controller that you want to update.
4. Press **Alt+A** to open the **Action** menu and select **Flash HBA**.
5. Highlight the diskette drive and press **Enter**. SMOR will display a list of valid files on the diskette.
6. Highlight the software image you want to use and press **Tab** to highlight OK.

Press **Enter** to start the flash update operation. SMOR will read the file and verify that it is a valid flash image.

7. Press **Tab** to highlight Yes and press **Enter** to begin the flash update.
8. Press **Enter** when you see the confirmation prompt
9. When the flash update is complete you must restart the system to enable the new software.

CHAPTER 5:

Software Installation

Your new SmartRAID V controller uses I₂O drivers that may be supplied by DPT or your operating system vendor. This chapter discusses driver and operating system installation when using SmartRAID V controllers.

After you install the operating system, you can install Storage Manager. Storage Manager is available for:

Microsoft Windows NT 4.0

Microsoft Windows 95/98

SCO UNIX 3.2v4.2

SCO OpenServer 5

SCO UnixWare 7

Red Hat Linux 6.x

NOTE *If a device driver for your operating system is not supplied on the DPT diskettes or is not available from the DPT web site, contact the manufacturer of your operating system to obtain an I₂O OSM for your system.*

Windows NT 4.0

A DPT I₂O driver is supplied with your controller.

Windows 95/98

A DPT I₂O driver is supplied with your controller.

SCO UNIX 3.2V4.2, ODT 3.0, and OpenServer 5

SmartRAID V controllers include a SCO BTLD diskette with a DPT I₂O driver.

SCO UnixWare 7

An I₂O driver for UnixWare 7 is available from SCO.

NetWare 4.11, 4.2 and 5.0

A DPT-qualified I₂O driver from Novell (for NetWare 4.2 and 5.0) is supplied with your controller. The driver for NetWare 4.11 is available for download from the DPT web site.

Red Hat Linux 5.2, 6.0 and 6.1

Diskette images are available from DPT (www.dpt.com). These drivers support Linux kernel versions 2.0.36 and 2.2.5.

BSD/OS 4.1 and FreeBSD

Diskette images are available from DPT (www.dpt.com).

Windows NT 4.0

The DPT SmartRAID V driver for Windows NT 4.0 provides support for both disk drives and other SCSI devices, such as CD-ROMs and scanners.

NOTES

- *Windows NT must be updated with Service Pack 4 or later.*
- *If you choose the Microsoft I₂O OSM in place of the DPT class or miniport driver, you will not be able to use Storage Manager.*
- *The Windows NT 4.0 OSM is not compatible with Windows 2000. If you have a SmartRAID V controller installed under Windows 2000, use the DPT miniport driver instead of an OSM.*
- *If you are installing Windows NT from an IDE CD-ROM, press **F6** as soon as the NT Detect screen appears during the installation process. This will cause the installation program to prompt for installation of a mass storage driver earlier in the install process and ensure that the disk drives attached to the controller are available when required.*
- *The DPT class driver is installed and enabled automatically. The class driver provides enhanced performance and reduced CPU utilization during disk accesses. This driver will load before the Windows NT disk class driver and acquire all disks attached to DPT controllers. If you want to use the DPT miniport driver, do the following after you complete the initial installation:*

Open the Control Panel.

Double click the Devices icon.

Disable the entry for DPT DISK.

Restart the system.

There are three driver installation scenarios for Windows NT 4.0:

- Installing the SmartRAID V controller into a new system, then installing Windows NT 4.0
- Upgrading an existing Windows NT 4.0 system
- Adding a SmartRAID V controller into an existing Windows NT 4.0 system, to be used in addition to a currently installed SmartRAID IV or SmartCache IV controller

Each of these cases requires a slightly different procedure. Be sure you select the correct procedure and follow the procedure carefully. If you need additional assistance, contact DPT Technical Support.

Installing a New System

This procedure describes how to install a SmartRAID V controller and Windows NT 4.0 on a new system. If Windows NT is to coexist with another operating system, that operating system must be installed before you install Windows NT. During the Windows NT installation, you will need one blank high-density diskette to create an Emergency Repair Diskette.

To install a SmartRAID V controller and Windows NT 4.0 into a new computer system, follow the steps below:

1. Install the SmartRAID V controllers and storage devices according to the instructions in Chapter 3, "Configuration and Installation".
2. Boot your system and run SMOR to verify your configuration. Create your disk arrays now. Each array will appear to the operating system as a single logical drive.
3. Ensure that the Windows NT CD-ROM is in the CD-ROM drive. Boot the system from the Windows NT setup diskette 1.
4. Insert the additional setup diskettes when prompted.
5. Press **S** to skip Setup's mass storage detection. Press **S** to Specify Additional Devices. Select Other, then insert the DPT diskette for Windows NT.
6. Select DPT I2O SCSI Adapter Driver for NT 4.0 and greater.
7. Press **Enter** and continue with the installation as described in the Windows NT documentation.

NOTE *If a SmartRAID IV or SmartCache IV controller is installed, Windows NT mass storage detection routines will load an older DPT driver for that device from the Windows NT diskette or CD-ROM. After Windows NT installation completes, update the driver using the version contained on the DPT diskette that was supplied with your SmartRAID IV or SmartCache IV controller.*

Alternatively, if you have a controller from another manufacturer or other hardware that requires the use of Windows NT mass storage detection, follow the steps below:

1. Install the SmartRAID V controllers and storage devices according to the instructions in Chapter 3, "Configuration and Installation".
2. Boot your system and run SMOR to verify your configuration. Create your disk arrays now. Each array will appear to the operating system as a single logical drive.
3. Ensure that the Windows NT CD-ROM is in the CD-ROM drive. Boot the system from the Windows NT Setup Disk 1.
4. Insert additional Windows NT setup diskettes when prompted.
5. Press **Enter** to perform Setup's mass storage detection.
6. After Windows NT detects any controllers for which it has built-in drivers, you are prompted to either press **S** to specify additional controllers or press **Enter** to continue Windows NT installation without specifying additional controllers.
7. Press **S** to Specify Additional Devices. Select Other, then insert the DPT Windows NT diskette.
8. Select DPT I2O SCSI Adapter Driver for NT 4.0 and greater.
9. Press **Enter** and continue with the installation according to the instructions in the Windows NT documentation.

Upgrading an Existing System

NOTE *If you have already installed a SmartRAID V controller into your system and want to change drivers, refer to the Adding to an Existing System section instead of this procedure.*

To upgrade an existing Windows NT 4.0 system to a SmartRAID V controller, follow the steps below:

1. From the Control Panel, select the SCSI Adapters icon. Then select the Drivers tab and click Add.
2. Insert the DPT Windows NT diskette, then click Have Disk.
3. Select DPT I2O SCSI Adapter Driver for NT 4.0 and greater.
4. After the driver is loaded, shut down the system. Replace the existing controller with the DPT SmartRAID V controller.
5. Boot the system.
6. If you are removing the old DPT controller, you should also remove the old driver.

Adding to an Existing System

To add a DPT SmartRAID V controller to an existing Windows NT 4.0 system, do the following:

1. From Control Panel, select the SCSI Adapters icon. Then select the Drivers tab and click Add.
2. Insert the DPT I₂O drivers diskette, then click Have Disk.
3. Select DPT I2O SCSI Adapter Driver for NT 4.0 and greater.
4. After the driver is loaded, shut down the system. Install the new DPT SmartRAID V controller into the system, leaving the existing controller installed.
5. Boot the system.

Adding to an Existing System (Microsoft OSM)

NOTE *If you use the Microsoft I₂O OSM in place of the DPT miniport driver, you will not be able to run Storage Manager.*

To add a DPT SmartRAID V controller to an existing Windows NT 4.0 system using the Microsoft Windows NT OSM, do the following:

1. Obtain a copy of the self-extracting file for the Microsoft I₂O drivers and extract the drivers to a directory or diskette.
2. From Control Panel, select the SCSI Adapters icon. Then select the Drivers tab and click Add.
3. When the Install Driver dialog box appears, select Have Disk.
4. Insert the Microsoft Windows NT OSM I₂O driver diskette or type the path to the directory to which you unzipped the driver files.
5. Select Microsoft I20 Drivers.
6. After the driver is loaded, shut down the system. Add the new DPT SmartRAID V controller to the system, leaving the existing controller installed.
7. Boot the system.

The Microsoft I₂O OSM driver supports only disk drives. If you want CD-ROM, tape, scanner, or other SCSI device support on your SmartRAID V controller under Windows NT, you must to use the DPT Windows NT 4.0 miniport driver.

Additionally, the Microsoft I₂O OSM driver for Windows NT does not inherently support bootable controllers. If you want to boot the SmartRAID V controller with the Microsoft I₂O OSM, do the following:

1. Install Windows NT 4.0 with the DPT Windows NT 4.0 miniport driver.
2. After Windows NT is installed, remove the DPT Windows NT 4.0 miniport driver from the SCSI Adapters list.
3. Install the Microsoft Windows NT OSM I₂O driver. The I₂O BIOS ROM on the SmartRAID V controller will manage the Windows NT 4.0 boot process up to the point where the Microsoft I₂O OSM loads.

Windows 95/98

The DPT SmartRAID V driver for Windows 95/98 provides support for both disk drives and other devices, such as CD-ROMs and scanners.

There are several driver installation scenarios under Windows 95/98:

- Installing the SmartRAID V controller into a new system, then installing Windows 98
- Installing a SmartRAID V controller into a new system, then installing Windows 95
- Upgrading an existing Windows 95 system to Windows 98
- Adding a SmartRAID V controller to an existing Windows 95/98 system
- Upgrading Windows 3.1 to Windows 95 and installing a SmartRAID V controller

Each of these cases requires a slightly different procedure.

Installing Windows 98 (Full Install Version)

This section describes the steps to install Windows 98 (Full Installation Version) on one disk drive or array group using a SmartRAID V host controller. Ensure that your hard drives, arrays, CD-ROM drive, and any other SCSI device attached to the host controller are recognized by SMOR before proceeding.

Do the following to install Windows 98 (Full Installation Version):

1. Boot the system from a bootable DOS diskette.
2. Run FDISK and create a Primary DOS Partition of an appropriate size.
3. Mark the Primary DOS Partition Active.
4. Reboot the system from the DOS diskette.
5. Perform a system format (FORMAT C: /S).
6. Run the SETUPCD.EXE program on the DPT Windows NT diskette. This program creates an AUTOEXEC.BAT file and CONFIG.SYS file with support for your CD-ROM drive.
7. Ensure that the MSCDEX.EXE program is in your boot path or the root directory of the C: drive.

8. Remove the boot diskette from the floppy disk drive and reboot the system from the C: drive.
9. Insert the Windows 98 Full Installation CD in the CD-ROM drive.
10. Enter the drive letter assigned to the CD-ROM and run SETUP (for example, D:\SETUP).
11. Follow the Windows 98 installation prompts.
12. During one of the device detection boot processes, Windows 98 will identify PCI Card and/or Memory Controller devices. Click Next and display the list of drivers from a specific location.

NOTE

If you are not prompted for a PCI Card or Memory Controller Driver or the Device Manager shows PCI Card with a yellow exclamation mark in the Other Devices list, you might need a patch for your motherboard chipset to recognize multifunction bridge controllers.

Contact your motherboard vendor and apply the patch. After the patch is installed and the system is restarted, Windows 98 will repeat the device discovery process. If you are installing the operating system, go back to step 12 and continue the procedure. If you are adding a SmartRAID V to an existing configuration, go to step 3 on page 5-12 and continue with the procedure.

13. Select Have Disk and insert the DPT Windows 95/98 diskette when prompted. The system will then reboot back into Windows 98.

NOTE

If more than one DPT SmartRAID V controller is installed in the computer, repeat steps 12 and 13 for each controller.

Device Manager (in Control Panel/System) should now show a DPT I20 SCSI Host Adapter in the SCSI Controllers section.

You can use a text editor to remove the following entries from your CONFIG.SYS file:

```
DEVICE=I20DDL.SYS  
DEVICE=DPTCDROM.SYS
```

You can also use a text editor to remove the MSCDEX entry from your AUTOEXEC.BAT file. When you complete the installation procedure these CONFIG.SYS and AUTOEXEC.BAT file entries are no longer needed.

Installing Windows 95 (OEM SR2 – Version 950b)

This section describes the steps to install Windows 95 (OEM SR2 Version) on one disk drive or array group using a SmartRAID V controller. Ensure that your disk drives, arrays, CD-ROM drive, and any other SCSI devices attached to the controller are recognized by SMOR before proceeding.

Do the following to install Windows 95 (OEM SR2 Version) with a SmartRAID V controller:

1. Boot DOS from a bootable DOS diskette.
2. Run FDISK and create a Primary DOS Partition of an appropriate size.
3. Mark the Primary DOS Partition Active.
4. Reboot the system from the DOS diskette.
5. Perform a system format (FORMAT C: /S).
6. Run the SETUPCD.EXE program on the DPT diskette. This program will create an AUTOEXEC.BAT and CONFIG.SYS to support your CD-ROM drive.
7. Ensure that the MSCDEX.EXE program is in your boot path or the root directory of the C: drive.
8. Reboot the system from the C: drive.
9. Insert the Windows 95 OEM SR2 CD in the CD-ROM drive.
10. Enter the drive letter assigned to the CD-ROM and run SETUP (for example, D:\SETUP).
11. Follow the Windows 95 installation prompts.
12. When Windows 95 is fully installed, start Device Manager (in Control Panel – System) and look for a PCI Card entry under the Other Devices category. There may be multiple entries if you have multiple SmartRAID V host controllers installed. There may also be an entry for PCI Memory Controller.
13. Select PCI Card and choose Update Driver from the Driver tab.

NOTE

If you are not prompted for a PCI Card or Memory Controller Driver or if the Device Manager shows PCI Card with a yellow exclamation mark in the Other Devices list, you might need a patch for your motherboard chipset to recognize multifunction bridge controllers.

Contact your motherboard vendor and apply the patch. After the patch is installed and the system is restarted, Windows 95 will repeat the device discovery process. If you are installing the operating system, go back to step 12 and continue the procedure. If you are adding a SmartRAID V to an existing configuration, go to step 3 on page 5-12 and continue the procedure.

14. Insert the DPT Disk 1 diskette into the floppy drive and let Windows search for the drivers.
15. Windows should identify the PCI Card as DPT I2O SCSI Host Adapter. Select Finish.

At this point, you might need to force Windows 95 to copy the driver from A: rather than the CD-ROM drive.
16. Select Cancel for testing the Device ROM.
17. If the Other Devices category shows a PCI Memory Controller, select it and choose Update Driver from the Driver tab.
18. Let Windows search for the drivers on the DPT Windows 95/98 diskette.
19. Windows should now identify the PCI Memory Controller as DPT I2O Memory Controller. Select Finish.

At this point, you might need to force Windows 95 to copy the driver from A: rather than the CD-ROM drive.
20. If there are multiple SmartRAID V controllers, repeat steps 12 through 19 for each SmartRAID V controller in the computer. The system should ask you to reboot when this action is completed.
21. Device Manager should now show a DPT I2O SCSI Host Adapter in the SCSI Controllers section.

You can use a text editor to remove the following entries from your CONFIG.SYS file:

```
DEVICE=I2ODDL.SYS  
DEVICE=DPTCDROM.SYS
```

You can also use a text editor to remove the MSCDEX entry from your AUTOEXEC.BAT file. When you complete the installation procedure these CONFIG.SYS and AUTOEXEC.BAT file entries are no longer needed.

Installing Windows 95 (Retail Upgrade – Version 950a)

SmartRAID V controllers are not supported by Windows 3.1, therefore an upgrade process from Windows 3.1 to Windows 95 does not apply. However, the Retail Upgrade Version (950a) can be installed like a new operating system if you have your original Windows 3.1 diskettes.

Follow the installation instructions in the Installing Windows 95 (OEM SR2 950b) section of this chapter. During the first phase of the installation the Windows 95 installation program will prompt you to insert your original Windows 3.1 disk to verify your eligibility for the upgrade. After the upgrade is authenticated, the process continues as a normal installation on a new system.

Adding SmartRAID V to an Existing Windows 95/ 98 Configuration

This section describes the steps to install a SmartRAID V controller to an existing Windows 95/98 configuration. Ensure that your hard drives, arrays, CD-ROM drive, and any other SCSI device attached to the controller are recognized by SMOR before proceeding.

Do the following to install a SmartRAID V controller in an existing Windows 95/98 system:

1. Install the SmartRAID V controller in the system and start Windows 95/98. If Windows prompts for a driver to support a PCI Card or Memory Controller, go to step 7.
2. If Windows did not discover the devices during boot, start Device Manager (Control Panel – System) and look for a PCI Card entry in the Other Devices category. There may be multiple entries if you have multiple SmartRAID V controllers installed. There may also be an entry for PCI Memory Controller.

NOTE *If you are not prompted for a PCI Card or Memory Controller Driver, open the Device Manager. If Device Manager displays PCI Card with a yellow exclamation mark in the Other Devices list, you might need a patch for your motherboard chipset to recognize multifunction bridge controllers.*

Contact your motherboard vendor and apply the patch. After the patch is installed and the system is restarted, Windows 95 will repeat the device discovery process. If you are installing the operating system, go to step 12 on page 9 and continue the procedure. If you are adding a SmartRAID V to an existing configuration, go to step 3 and continue the procedure.

3. Select PCI Card and choose Update Driver from the Driver tab. Insert the DPT Windows 95/98 diskette into the floppy drive and let Windows search for the drivers.
4. Windows should now identify the PCI Card as DPT I2O SCSI Host Adapter. Select Finish. At this point, you might need to force Windows 95 to copy the driver from A: rather than the CD-ROM drive.
5. Select Cancel for testing the Device ROM.
6. If the Other Devices category shows a PCI Memory Controller, select it and choose Update Driver from the Driver tab.
7. Let Windows search for the drivers from the DPT Windows NT/95/98 driver diskette.
8. Windows should now identify the PCI Memory Controller as DPT I2O Memory Controller. Select Finish. At this point, you may need to force Windows 95 to copy the driver from A: rather than the CD-ROM drive.
9. If there are multiple SmartRAID V controllers in the computer, repeat steps 3 through 10 for each SmartRAID V controller. You may be asked to reboot when this action is completed.
10. Device Manager should now show a DPT I2O SCSI Host Adapter in the SCSI Controllers section.

Upgrading to Windows 98 from Windows 95 (Upgrade Version)

If the SmartRAID V controller is properly installed and recognized under Windows 95 before starting the Windows 98 upgrade, no further configuration is necessary. Perform the Windows 98 upgrade and the functionality of the SmartRAID V controller will be retained.

If the controller is being added in addition to the upgrade, follow the procedure in the Installing Windows 98 (Full Installation Version) section.

Installing Storage Manager for Windows

When the SmartRAID V controllers are properly recognized by Windows, run SETUP.EXE from the DPT Windows 95/98 diskette and follow the on-screen prompts to install the Storage Manager software.

The installation program detects which version of Windows you are using and installs the appropriate Storage Manager files for your operating system.

If you will use remote communication, be sure to select the Communication Server install option.

If you are using Windows NT 4.0, do the following after Storage Manager is installed to ensure optimum performance:

1. Start Storage Manager and double click on the controller icon to display the Host Bus Adapter Info window.
2. Select Configure to display the Configure Host Bus Adapter window.
3. Select Caching. When the HBA Caching Configuration dialog appears, change the settings from Mandatory to Advisory.
4. Select OK to exit the dialog and save the changes.
5. Reboot the host system to enable the new settings.

NOTE

If you reset the NVRAM on the controller, the changes to your cache settings return to the factory default.

SCO UNIX

A diskette for SCO UNIX 3.2V4.2 and SCO UNIX OpenServer 5 (3.2V5.x) is included with your SmartRAID V controller. The DPT diskette for SCO contains the drivers for both versions of SCO. A second diskette contains a Motif version of DPT Storage Manager for each version of SCO UNIX.

NOTE *When assigning numbers to controllers, SCO starts with zero. Storage Manager numbers controllers starting with one.*

Installing SCO UNIX 3.2V4.2 or OpenServer 5

This section describes the steps to install SCO UNIX 3.2V4.2 and up (including ODT 3.x) and SCO UNIX 3.2V5.0.x (OpenServer 5) on a single drive or array group. These SCO operating systems are configured to support one SCSI hard drive or array group at ID 0, one tape drive at ID 2, and one CD-ROM at ID 5. If these devices are to be installed at this time, make sure that their IDs have been set accordingly.

To install SCO, follow the steps below:

1. If installing SCO UNIX 3.2V4.2 or ODT 3.0, boot the system with the N1 diskette. Enter the following string at the boot prompt :

```
defbootstr link=dpti4
```

If installing SCO UNIX 3.2V5.0.x, boot the system with the Boot Disk. Enter the following string at the boot prompt:

```
defbootstr ahslink=dpti5
```

For SCO UNIX 3.2V5.04 or later the command is:

```
defbootstr link=dpti5
```

2. When prompted for the SCO BTLD diskette (DPT volume), insert the DPT BTLD diskette into the floppy drive.
3. Insert the N1 or Boot disk again when prompted.
4. If installing SCO 3.2V4.2 or ODT3.0, insert the N2 diskette when prompted. During the Hardware Roster, the following line should appear:

```
% adapter type=dpti ha=0 id=7 channel=0, PCI
```

If you are installing SCO UNIX 3.2V5.0.x., during the Hardware Roster, the following line should appear:

```
% adapter type=dpti ha=0 id=7, PCI
```

5. Continue the installation according to the SCO documentation.

NOTE

If you are installing from tape or CD-ROM, SCO UNIX 3.2V4.2 expects to find the tape at Controller 0, SCSI ID 2, LUN 0 and the CD-ROM at Controller 0, SCSI ID 5, LUN 0.

SCO OpenServer 5 will locate the tape or CD-ROM at any valid SCSI address.

Adding to an Existing SCO UNIX 3.2V4.2 or OpenServer 5 System

When adding a DPT controller to an existing SCO UNIX configuration, perform the following steps.

1. Install the DPT controller.
2. Boot SCO UNIX.
3. After SCO UNIX has booted, place the DPT SCO driver diskette in the floppy drive.
4. Run the installpkg utility.
SCO UNIX will read the diskette and prompt you to enter the package name to be installed. Enter `dpti4` for SCO UNIX 3.2V4.2 or ODT 3.0, and `dpti5` for SCO OpenServer 5.
5. Rebuild the kernel after the package is installed. Shutdown and reboot the system to install the new kernel and add devices on the controller.

SCO UnixWare 7

1. Install the SmartRAID V controller as in Chapter 3, “Controller Configuration and Installation”.
2. Obtain the latest I₂O supplement for UnixWare 7 from SCO (it should be PTF7067E or higher).
3. Copy or download the `ptf` file to the `/tmp` directory. Use the `pkgadd` utility to install the I₂O supplement by entering the command:

```
pkgadd -d /tmp/ptf7067e.s
```
4. Follow the on-screen prompts to install the SCO UnixWare I₂O supplement.
5. Shutdown and reboot the system.

NOTE *When you reboot several WARNING messages may appear and scroll off the screen quickly. These will not occur after “diskadd” is run and can be ignored.*

6. Use the diskadd utility to add drives or arrays that are attached to a SmartRAID V controller.

Run the `sdiconfig -l` utility in a terminal window or non-GUI screen. This will list all controllers recognized by the operating system and any attached devices. Use this listing to determine the proper ID to use for the diskadd utility.

The diskadd command to add devices on a secondary controller is:

```
diskadd cCbBtTdD
```

Where:

C specifies the ID for the controller in the system.

B is the controller bus number (from 0 – 7) to which the disks are attached.

T is the target controller number (ID). The value of *T* can be 0 – 31.

D is the Logical Unit Number (LUN) of the disk device, from 0 – 31.

See the `diskadd(1M)` man page for more information.

For example, if a new drive or array is on the DPT controller, on channel 0, with an ID of 0, the command would be:

```
diskadd c1b0t0d0
```

Novell NetWare

You must follow the procedures in the following sections to installing a SmartRAID VI controller for Novell NetWare, especially as a booting controller. There are specific steps that must be completed to ensure that NetWare will recognize the DPT controller and any attached devices.

The DPT diskette for NetWare contains the device drivers you need to install a DPT controller for NetWare 4.2 and 5.0. The diskette also contains additional modules that allow you to monitor and configure a NetWare server using Storage Manager on a remote client workstation.

If you are using NetWare 4.11, you must download the installation files from the DPT Technical Support web site.

NOTE *The I2O drivers in the following Novell Support Packs or driver kits will result in unexpected behavior of the SmartRAID VI controller or disk arrays:*

I2ODRV3
NetWare 5 Support Pack 2
NetWare 5 Support Pack 2A

If any of these Support Packs or updates are applied, use the Novell install procedure to update the drivers with the files from your DPT NetWare diskette.

After you have installed the I₂O drivers you can now use the normal NetWare procedures for modifying disk partitions, hot fixes, or volume maintenance.

You can use SMOR to create or modify disk arrays or add Hot Spare drives. If you install remote communication support for Storage Manager, you can use Storage Manager from a client workstation to manage the storage subsystem.

NetWare 4.11 – Boot Controller

This section describes how to install a SmartRAID VI controller as a boot device for NetWare 4.11 servers.

NOTE *Part of this procedure requires that you have enough free space on your C: drive to hold the contents of the NetWare CD-ROM.*

1. Download the NW411.ZIP file from the DPT Technical Support web site. Extract the files to a floppy disk.
2. Install the DPT controller as the primary controller and attach the disk drives. If other I/O controllers are present, ensure that the SmartRAID VI boot controller is in a lower number PCI slot than the other controllers.
3. Install and configure a secondary controller (SCSI or IDE) for the CD-ROM drive and any other devices such as a tape drive.
4. Boot the system and use SMOR to create any required disk arrays. Press **Ctrl+D** during boot to start SMOR.
5. Create a DOS partition on the logical storage unit (drive or array group) with the lowest SCSI ID.
6. Boot the system to DOS from the partition created in step 5. Ensure that you load the required CD-ROM drivers.
7. Insert the NetWare 4.11 release CD-ROM into the CD-ROM drive. Insert the diskette you created and run DPT411.BAT. This will copy the necessary files to the C: drive.
8. When asked to choose a disk driver select I2OPCI.NLM. Enter the slot number where the controller is installed and press **F10**.
9. Select Save parameters and load driver.
10. Choose Yes to select another driver.
11. Select BKSTROSM.HAM. Enter the slot number where the controller is installed and press **F10**.
12. Select Save parameters and load driver.
13. Install any additional drivers and continue the installation.
14. Ensure that BKSTROSM.HAM is listed after I2OPCI.NLM in your STARTUP.NCF file.

Complete the NetWare installation according to the Novell documentation.

NetWare 4.11 – Secondary Controller

This section describes how to integrate a DPT SmartRAID VI controller into a new or existing Novell NetWare 4.11 system as a secondary controller. Ensure that your NetWare version is at the minimum patch level specified by Novell.

NOTE *The server must have patch kit IWSP4 or later installed to use the drivers supplied by DPT. NetWare 4 Support Pack 8 contains the latest Novell I₂O drivers. These drivers are newer than the ones from DPT but have not been tested for compatibility with DPT controllers.*

To integrate a DPT controller into an existing Novell NetWare 4.11 system, do the following:

1. Download the NW411.ZIP file from the DPT Technical Support web site. Extract the files to a floppy disk.
2. Shutdown the server and switch off the power. Install the DPT controller and any attached storage devices as a secondary disk subsystem. Note the slot used by the controller; you will need this information later in the install process.
3. Power on the server and use SMOR to configure the storage subsystem. Press **Ctrl+D** during boot to start SMOR.
4. Start NetWare. When the console prompt appears type, **LOAD INSTALL** and press **Enter**.
5. Select **PRODUCT OPTIONS** and press **Enter**.
6. Select **INSTALL A PRODUCT NOT LISTED** and press **Enter**.
7. Insert the diskette you created in drive A: and install **I2O** and **BLOCK STORAGE** support only.
8. Accept the defaults for the remaining install options.
9. Return to the main install screen and select **NCF OPTIONS**.
10. Select **EDIT STARTUP.NCF**.
Ensure that **BKSTROSM.HAM** is listed after **I2OPCI.NLM**.
11. Shutdown and restart the server.

NetWare 4.2 – Boot Controller

This procedure is for installing a SmartRAID VI controller as the boot device in a NetWare 4.2 server.

1. Install the SmartRAID VI controller as the primary controller and attach the disk drives or storage subsystem.
Ensure that you are using a CD-ROM that is not attached to the DPT controller.
2. Create a directory on the C: drive named NWUPDATE.
3. Insert the DPT NetWare diskette into the floppy disk drive.
4. Copy A:\NW42 to C:\NWUPDATE.
5. Start the NetWare installation program from the CD-ROM. Use the Custom Installation option.
6. On the Server Drivers - Summary menu, highlight Disk and CDROM Drivers and press **Enter**.
7. Highlight Select an Additional Driver and press **Enter**.
Select I2OPCI.NLM and press **Enter**.
Enter the slot number.
Highlight Save Parameters and Continue. Press **Enter**.
8. Answer Yes when prompted to select an additional driver.
9. Select BKSTROSM.HAM and press **Enter**.
Enter the slot number.
Highlight Save Parameters and Continue. Press **Enter**.
10. Answer No when prompted to select an additional driver.
11. Highlight Continue Installation and press **Enter**.
12. Verify that BKSTROSM.HAM is listed after I2OPCI.NLM in your STARTUP.NCF file.

Continue with the NetWare 4.2 installation according to the Novell documentation.

NetWare 4.2 – Secondary Controller

This section describes how to integrate a DPT SmartRAID VI controller into a new or existing Novell NetWare 4.2 system as a secondary controller. Ensure that your NetWare version is at the minimum patch level specified by Novell.

NOTE *NetWare 4 Support Pack 8 contains the latest Novell I₂O drivers. These drivers are newer than the ones from DPT but have not been tested for compatibility with DPT controllers.*

To integrate a DPT controller into an existing Novell NetWare 4.2 system, do the following:

1. Download the NW411.ZIP file from the DPT Technical Support web site. Extract the files to a floppy disk.
2. Shutdown the server and switch off the power. Install the DPT controller and any attached storage devices as a secondary disk subsystem. Note the slot used by the controller; you will need this information later in the install process.
3. Power on the server and use SMOR to configure the storage subsystem. Press **Ctrl+D** during boot to start SMOR.
4. Start NetWare. When the console prompt appears type, **LOAD INSTALL** and press **Enter**.
5. Select **INSTALL A PRODUCT** and press **Enter**.
6. Select **INSTALL A PRODUCT NOT LISTED** and press **Enter**.
7. Insert the diskette you created from the download file in drive A: and install **I2O** and **BLOCK STORAGE** support only.
8. Accept the defaults for the remaining options.
9. Return to the main install screen and select **NCF OPTIONS**.
10. Select **EDIT STARTUP.NCF**.
Ensure that **I2OPCI.NLM** is listed after **BKSTROSM.HAM**.
11. Shutdown and restart the server.

NetWare 5.0 – Boot Controller

Use the following procedure to install support for a SmartRAID VI controller during installation of NetWare 5. The controller should be installed at the beginning of the procedure so that it can be detected by the install routine.

1. Install the DPT controller as the primary controller and attach the disk drives. You can use SMOR to create disk arrays or Hot Spare drives when you boot the system.
2. Install and configure a secondary controller (non-I2O SCSI or IDE) for the CD-ROM drive and any other storage devices such as a tape drive.
3. Create a directory on the C: drive named NWUPDATE.
4. Insert the DPT NetWare diskette into the floppy disk drive.
5. Copy A:\NW5 to C:\NWUPDATE.
6. Start the NetWare installation program from the CD-ROM. Use the Custom Installation option.
7. On the Server Drivers - Summary menu, highlight Disk and CDROM Drivers and press **Enter**.

When prompted choose I2OPCI.NLM and BKSTROSM.HAM as disk drivers.

8. Complete the NetWare installation according to the Novell documentation.

Verify that I2OPCI.NLM is listed after BKSTROSM.HAM in your STARTUP.NCF file.

9. Install the latest support pack for NetWare 5.0.

NOTE

Installing a NetWare Support Pack will overwrite the I₂O drivers supplied by DPT. If you encounter problems after installing the Support Pack, you can restore the DPT files by copying them from the DPT NetWare diskette.

NetWare 5.0 – Secondary Controller

This section describes how to integrate a DPT SmartRAID VI controller into a new or existing Novell NetWare 5.0 system as a secondary controller. Ensure that your NetWare version is at the minimum patch level specified by Novell.

NOTE *NetWare 5 Support Pack 4 contains the latest Novell I₂O drivers. These drivers are newer than the ones from DPT but have not been tested for compatibility with DPT controllers.*

To integrate a DPT controller into an existing Novell NetWare 5.0 system, do the following:

1. Shutdown the server and switch off the power. Install the DPT controller and any attached storage devices as a secondary disk subsystem. Note the slot used by the controller; you will need this information later in the install process.
2. Power on the server and use SMOR to configure the storage subsystem. Press **Ctrl+D** during boot to start SMOR.
3. Start NetWare and insert the DPT NetWare diskette in the floppy disk drive.
4. When the console prompt appears type, **LOAD NWCONFIG** and press **Enter**.
5. Select **DRIVER**.
6. Select **DISK DRIVER**.
7. Install **I2OPCI.NLM** and **BKSTROSM.HAM**. You will need to specify **A:\NW5** as the location for the files.
8. Ensure that **I2OPCI.NLM** is listed after **BKSTROSM.HAM** in your **STARTUP.NCF** file.

Installing Remote Communication Support

1. Insert the DPT NetWare diskette in the server's floppy disk drive.
2. Enter the following command at the prompt:

```
LOAD A:\DPTINST.NLM
```
3. You will be prompted to choose whether to load the remote communication support immediately or delay loading until the server is restarted.

If you choose to wait until the server restarts, you will not be able to monitor the DPT subsystem from a remote client until the server is shut down and restarted. Otherwise, the remote communication support is loaded and available as soon as you exit the install program.

Red Hat Linux

To install a DPT controller under Red Hat Linux 5.2 or 6.x, you must have the DPT Linux diskettes. The diskette images can be downloaded from the DPT web site (www.dpt.com).

NOTE *The DPT drivers are for Linux kernel versions 2.0.36 and 2.2.5 or higher. If your kernel has been updated by a patch, the drivers might not function. In this case, contact DPT Technical Support for assistance. Refer to the READ.ME file for the latest information Linux support for DPT SmartRAID V controllers.*

The REDHAT.TXT file is a HOWTO document that describes the installation of a SmartRAID V controller in a system using Linux.

DPT controller and RAID management is available through the DPT SMOR utility or Storage Manager for Linux. Storage Manager for Linux requires Linux 6.x (kernel version 2.2.5 or higher). See Chapter 4, "Storage Manager on ROM" or Chapter 6, "Storage Manager" for additional information about using these programs.

Red Hat Linux 5.2 and 6.0

These instructions are for installation of the DPT device driver for Linux on a system using Red Hat Linux 5.2 or 6.0.

1. Install and configure your DPT controller according to the instructions in Chapter 3, “Configuration and Installation”.
2. If you want to install Linux on a disk array, use SMOR to configure any disk arrays before beginning the operating system installation.

NOTE

Any partitions created on disks that are not part of an array will be unavailable if you subsequently use the disk in a RAID configuration.

3. Boot the system from the DPT Red Hat Linux boot diskette and continue with the Linux installation according to the instructions in the REDHAT.TXT file.

Red Hat Linux 6.1

These instructions are for installation of the DPT device driver for Linux on a system using Red Hat Linux 6.1.

1. Install and configure your DPT controller according to the instructions in Chapter 3, “Configuration and Installation”.
2. If you want to install Linux on a disk array, use SMOR to configure any disk arrays before beginning the operating system installation.

NOTE

Any partitions created on disks that are not part of an array will be unavailable if you subsequently use the disk in a RAID configuration.

If your hard drives do not have partition tables or do not contain a recognizable partition), you will be prompted to initialize these disks. The operating system can automatically remove the data or you can manually partition the drives. For more information, refer to the Red Hat documentation.

3. Boot the system with the Red Hat Linux 6.1 boot diskette in the floppy drive and CD Disk 1 in your CD-ROM drive.
4. When the Red Hat 6.1 Welcome screen appears, type:

`expert`

at the boot: prompt.

5. When prompted, insert the DPT driver diskette and press OK.
6. You will be prompted for the language and keyboard type.
7. You will be asked to specify the location of the media packages to be installed.

If you are installing from CD-ROM, select Local CD-ROM. If you selected CD-ROM, you will be asked what type of CD-ROM you have.
8. The system will ask you to specify a driver. Scroll down and select the DPT I2O driver.
9. The system will inform you that it has found DPT I2O SmartRAID.
10. Unless there are other third party devices to install in your system, select Done.

Continue with the Red Hat Linux 6.1 installation according to the Red Hat documentation.

Installing Storage Manager for Linux

The installation program detects which version you are using and installs the appropriate Storage Manager files for your operating system. If you will use remote communication, be sure to select the Communication Server install option.

Storage Manager for Linux requires X Window System support. The DPT distribution includes the LessTif components. DPT has tested Storage Manager operation with both the K Desktop Environment (KDE) and GNU Network Object Environment (GNOME) graphical user interface.

NOTE *Use of more than 256 colors in your GUI may result in Storage Manager displaying incorrect colors. If this occurs, reset your color setting to use only 256 colors.*

1. Create a temporary directory. To create a directory in Linux, type:

```
mkdir <directory name>
```
2. Change the working directory to the one you just created:

```
cd <...>
```

Download the Storage Manager for Linux archive from the DPT web site to this directory.

4. When the download is complete, run the following command from the prompt:

```
tar -xvf linsm218.tar
```

5. After the file extraction is finished, run the following command from the prompt:

```
./install
```

You will be asked if you want the DPT Communication Server to load on boot. The default is No. If you will access this host from a remote Storage Manager client, enable the DPT Communication Server.

6. Reboot the system, when the installation is complete.
7. Open a command prompt window and change the working directory to `/usr/dpt`.
8. To launch Storage Manager, type:

```
./dptmgr
```

This will open a Storage Manager window on your desktop.

CHAPTER 6:

Storage Manager

DPT's Storage Manager gives you complete control over your storage subsystem. You can manage your storage locally, remotely across a network or by using a modem.

Storage Manager brings out the best in your DPT hardware, from checking your equipment configuration – to managing your disk arrays – to providing online event logging and performance statistics.

SmartRAID V controllers also include Storage Manager on ROM, which lets you build disk arrays prior to installing your operating system and Storage Manager. See Chapter 4 for additional information about Storage Manager on ROM.

Physical View

Storage Manager's Physical View presents the storage subsystem as it is physically connected.

Logical View

Storage Manager's Logical View presents the storage subsystem as it appears to the operating system.

Icon Based

Each physical or logical storage device is shown as an icon. To display information or configure the device, click on its icon.

Event Notification

DPT controllers store events – fault conditions as well as status changes – in controller RAM. Events can thus be viewed even if the storage subsystem is not operating.

Remote Communication

Storage Manager can be used to configure controllers and disk arrays on remote systems across a TCP/IP network.

Introduction

DPT Storage Manager is included with your SmartRAID V controller. This utility performs several functions:

- Checks hardware configuration.
- Allows you to create, expand or delete disk arrays.
- Provides online functions for the DPT storage subsystem such as event logging and notification, array status and I/O statistics.
- Provides remote access to DPT hardware and attached storage devices across a TCP/IP network.

Storage Manager versions for supported operating systems are on the DPT diskettes that were included in your controller kit.

System Requirements

Storage Manager can be installed on a computer with one of the following operating systems:

- Windows 95/98
- Windows NT 4.0
- SCO UNIX 3.2V4.2
- SCO OpenServer 5
- SCO UnixWare 7.0
- Linux 6.x

NOTE *The versions of Storage Manager for SCO platforms uses the Motif graphical user interface. Storage Manager will not display correctly if your display is set to use more than 256 colors.*

Before running Storage Manager, be sure that your mouse driver is installed.

Running Storage Manager

You can run Storage Manager:

- On the same computer that contains the DPT hardware and peripheral devices (local operation).
- Remotely, across a TCP/IP network. This lets you view and configure servers from remote locations.
- In *demo* mode, where Storage Manager simulates a storage subsystem that contains various types of DPT controllers and peripheral devices. This lets you experiment with various storage configurations.


Using Storage Manager Locally

Storage Manager initially scans for DPT hardware installed on the computer on which it is run. If one or more DPT controllers are found, the storage subsystem hardware configuration is displayed.

Using Storage Manager Remotely

Windows NT, NetWare, SCO UNIX servers and Windows 95/98 systems can be viewed and configured across a TCP/IP network from Windows NT, Windows 95/98, or SCO UNIX workstations running Storage Manager.

To install the DPT communication server software, ensure that Communications Server is selected in the DPT Storage Manager Setup dialog. Refer to the Remote Communication section in this chapter for detailed information about using the remote communication feature.



Storage Manager on ROM


Storage Manager on ROM (SMOR) is a ROM-based version of Storage Manager which is provided on your SmartRAID V controller. If you are installing a new system, use SMOR to configure your RAID subsystem prior to installing your operating system.

You can access SMOR during the system boot by pressing **Ctrl+D** after the DPT L₂OBIOS is loaded. Refer to “Chapter 4, Storage Manager on ROM” for more information.

Physical Configuration View

The first window displayed by Storage Manager is the Physical Configuration View. This window displays each DPT controller in the system along with the peripheral buses and attached devices. Icons representing disk drives, CD-ROMs, tapes, printers, bridge controllers, scanners and jukeboxes are displayed. Devices are sorted by controller number and device ID from lowest to highest. To see a list of all icons and their meaning, select **Help – Legend of Icons** in Storage Manager.

Disk drives that are part of an array have the word RAID on the drive icon. Disk drives that are assigned as Hot Spares have a red circle with a white cross on the drive icon. Select Legend of Icons from the Storage Manager Help menu to see a list of the various icons and their meaning.




The Switch View button toggles between the Physical Configuration View and the Logical Configuration View window. Create Array Group starts the process of creating a RAID logical disk. Print will print a text report of the subsystem configuration.

Logical Configuration View

On the right side of the Logical Configuration View window are all physical devices that are attached to DPT controllers. On the left side of the window are the associated logical devices as seen by the host computer.


Non-disk devices use the same icon for both logical and physical views. Disk drives can be seen either as individual drives or as members of arrays. In either case, the drive or array is represented on the left side of the window as a Logical Storage Unit (LSU). Arrays that make up a Parity Group are displayed as RAID 1 or RAID 5 icons that appear between the LSU icon on the left and the drives on the right.

Devices are displayed in order of device type, with all non-disk devices displayed first, followed by all disk drives not assigned to an array, Hot Spares, and finally, all arrays by RAID level.



Logical Device Address

Every device and array is assigned a logical device address by Storage Manager. This is the address used by the host operating system to access the device or array. Logical device addresses appear in parentheses under the logical device and LSU icons on the Logical Configuration View window.



The logical device address is composed of four fields (HBA, Bus, Device, LUN) and are assigned to devices as follows:

HBA (Host Bus Adapter)

The controller to which the device is attached. PCI bus slots are scanned from lowest to highest looking for DPT controllers. As DPT controllers are found they are assigned numbers incrementally, starting with 0.

Bus

The controller bus to which the device is attached. SmartRAID V controllers can have up to three buses.

Device

The unique ID for that device. For an array, this is the lowest ID among the drives that make up the array.

LUN

Logical Unit Number for that device (normally 0).

NOTE *Array groups are automatically assigned an address that corresponds to the lowest logical device address used by a device in that array group. For example, if the lowest member device address for an array is HBA:0 Bus:1 ID:12 LUN:0, the LSU address will be HBA:0 Bus:1 ID:12 LUN:0.*

When an Array Group has been created, its logical device address will not change if the drive with the lowest ID is replaced by a Hot Spare. When a Hot Spare replacement occurs, the failed drive automatically becomes the new Hot Spare. If you choose not to use that drive as a Hot Spare, Storage Manager will prompt you to select an unused logical device address for that drive.

Status

Status is reported by SmartRAID V controllers for arrays and drives. Some status conditions are indicated by Storage Manager through status flags on the drive or array icons. View the information window for the drive or array to see specific status information. Changes in status conditions are logged and can also be broadcast to selected recipients.

The following table lists the general status conditions that can be indicated for drives or arrays. The Status field in the device or array information window displays additional information for any reported status condition other than Optimal.

Building	<p>Status flag: blue - This flag appears on an array icon when an array that was created is being built.</p> <p>Status flag: white - This flag appears on the drive icon that data will be copied to in a RAID 1 array build.</p>
Failed	<p>Status flag: red - This flag appears on a drive icon when the drive has failed.</p> <p>On an array icon, this flag indicates that one drive has failed in a RAID 0 array or two or more drives have failed in a redundant array.</p>
Impacted	<p>Status Flag: white - The array is in a degraded mode but no host I/O request has occurred since the degraded status was reported.</p>
Missing	<p>Status flag: black - This flag appears on a drive icon when the drive is physically missing or will not respond to commands on the peripheral bus.</p> <p>On an array icon, this flag indicates that the array has been created or modified within Storage Manager but the array has not yet been built.</p> <p>On a Hot Spare icon this flag indicates that the Hot Spare has not yet been created by the controller.</p>
Optimal	<p>Status flag: none - The drive or array is fully functional and is not running any operations that impact performance.</p>
Pending	<p>Status flag: blue - This flag appears on an array icon when the array has been created and the build is queued on the controller, but is not yet started.</p>
Rebuilding	<p>Status flag: blue - This flag appears on an array icon when the array is being rebuilt after a drive failure.</p> <p>Status flag: white - This flag appears on a drive icon when data is being rebuilt onto that drive.</p>
Verifying	<p>Status flag: white - This flag appears on drive or array icons to indicate that redundancy is being verified on the array. Performance may be affected.</p>
Warning	<p>Status flag: yellow - This flag appears on a drive icon (with S.M.A.R.T. failure prediction) to indicate that failure may be imminent.</p> <p>This flag appears on a RAID 1 or RAID 5 array that has a failed or missing drive.</p>

Information Windows

Double click on a controller or device icon to display an Information window for that controller or device.



Host Bus Adapter Information Window

The Host Bus Adapter Info window displays configuration information reported by that controller.

The Controller section displays the Model, Serial #, Firmware revision and amount of installed Cache. ECC is checked only if DPT ECC SIMMs or DIMMs are installed. The current temperature reported by the onboard sensor is also displayed.

The Attached Modules section shows the expansion modules and type and capacity of memory modules installed.

The SCSI Bus and Host Bus sections display the current configuration of the respective bus. Buttons available include Configure, Event Log, I/O Stats and Print. Battery displays the Battery Backup Configuration dialog if a BB4050 module is installed.


Host Bus Adapter Info	
Controller	
Model:	DPT PM3755U2B
Serial#:	12-000414
Firmware:	300H
Cache:	16 MB <input checked="" type="checkbox"/> ECC
Temp:	44 C 111 F
Attached Modules	
 SX405xU2-2  1: 16MB ECC Memory	
SCSI Bus	
Width:	<input type="radio"/> 8 bit <input checked="" type="radio"/> 16 bit
Type:	Ultra2
Busses:	3
Host Bus	
Type:	PCI 64-bit
Transfer:	132 MB/Sec in 32-bit slot 264 MB/Sec in 64-bit slot
<input type="button" value="Configure"/> <input type="button" value="Event Log"/> <input type="button" value="I/O Stats"/> <input type="button" value="Print"/> <input type="button" value="OK"/>	

Battery Backup Configuration

NOTE *During the initial calibration cycle for a BB4050 module, the controller disables automatic, low-battery write-through mode. After the calibration, use the Battery Backup Configuration dialog to set a threshold for entering write-through mode when the battery charge drops below a predetermined level.*

This option lets you view the status of the BB4050 Battery Backup Module and set operating parameters when the battery capacity reaches a predetermined level. The battery Status and available Backup capacity (in hours) is displayed. The Backup value is monitored periodically by software and changes whenever the battery pack is charging or discharging.

Battery Backup Configuration

 Status: Charging
Backup: 85 Hours

Backup Capacity Warnings

Low: Auto Write-Through: 12 Hrs.

Predictive Failure Warning: 24 Hrs.

Maintenance Defaults OK

The Backup Capacity Warnings parameters let you activate the following options when the BB4050 module reaches a predetermined level of remaining backup capacity (in hours). The capacity warning thresholds can change depending on the capacity and number of memory modules. Generally, more cache will result in lower battery backup capacity.

Low: Auto Write-Through

When checked this option automatically sets the cache to write-through mode when the specified number of hours (Hrs.) of battery capacity remain. The number of hours must be greater than or equal to the number of hours for a Predictive Failure Warning.

Predictive Failure Warning

When this option is checked a warning message will be issued when the battery backup capacity is almost depleted. Enter the number of hours (Hrs.) of remaining backup capacity when this message should be issued.

Click the Defaults button to set the Battery Capacity Warnings to their default values. Actual default values are calculated by the controller based on the size of the cache memory.

BB4050 Battery Status Messages

Battery Module status is reported as one of the following:

Full	The battery is fully charged.
Charging	The battery is charging after being partially or fully discharged.
Initial calibration charge	The battery is in the first phase (charging) of the initial calibration cycle.
Initial calibration discharge	The battery is in the discharge phase of the initial calibration cycle.
Initial calibration recharge	The battery is in the final phase (recharge after discharge) of the initial calibration cycle.
Maintenance calibration discharge	The battery is being discharged as part of the maintenance cycle.
Maintenance calibration charge	The battery is charging as part of the maintenance cycle.

Initial Calibration (BB4050)

The Initial Calibration operation is started when a BB4050 Battery Backup Module is first installed on a controller. This function ensures the battery is fully charged for subsequent backup operation. The calibration cycle requires approximately 24 hours to complete. The BB4050 module will not be able to provide backup capability during this operation. When the process is completed, the BB4050 module is ready for normal operation.

This function has three phases:

1. Initial charge: The battery is charged to its full capacity.
2. Discharge: The battery is discharged until no backup capacity remains.
3. Recharge: The battery is recharged to full capacity.

Battery Maintenance (BB4050)

IMPORTANT

The BB4050 module will not be able to provide backup capability during this operation.

The Maintenance operation can be used to ensure the battery remains capable of accepting a full charge. The Maintenance cycle completely discharges and then recharges the battery pack. This helps to eliminate any voltage-depression effects resulting from the battery pack being partially discharged and then recharged repeatedly during normal operation.

When this option is selected, the date of the most recent Maintenance cycle is displayed.

HBA Configuration

To modify hardware parameters for the SmartRAID V controller, click the Configure button in the Host Bus Adapter Info window. The Configure Host Bus Adapter window appears.

Configure Host Bus Adapter

Bus 0	Bus 1	Bus 2
SCSI ID: 7	SCSI ID: 7	SCSI ID: 7
<input checked="" type="checkbox"/> SCSI TERMPWR	<input checked="" type="checkbox"/> SCSI TERMPWR	<input checked="" type="checkbox"/> SCSI TERMPWR
Transfer: 20 MHz	Transfer: 40 MHz	Transfer: 40 MHz
Termination: <input type="radio"/> OFF <input type="radio"/> ON <input type="radio"/> High Only <input checked="" type="radio"/> Auto	Termination: <input type="radio"/> OFF <input checked="" type="radio"/> ON <input type="radio"/> High Only	Termination: <input type="radio"/> OFF <input checked="" type="radio"/> ON <input type="radio"/> High Only
Controller Address: D8000000 IRQ: 11 Level	<input type="button" value="Test Alarm"/> <input type="button" value="Flash"/> <input type="button" value="Caching"/>	
<input type="button" value="Defaults"/> <input type="button" value="Cancel"/> <input type="button" value="OK"/>		

SCSI ID	<p>DPT controllers are set at ID 7 by default. The ID for a SmartRAID V Fibre Channel controller can change dynamically as the Fibre Channel loop self-configures.</p> <p>Refer to Chapter 3, “Configuration and Installation” for information about selecting an alternate SCSI ID.</p>
SCSI TERMPWR	<p>By default SmartRAID V controllers supply termination power through the TERMPWR line on the SCSI cable. Refer to the information on TERMPWR in Chapter 7, “Theory of Operation” before you change this parameter.</p>
Ext. Cable Detect	<p>This option causes the SmartRAID V controller to check for the presence of an external SCSI cable and automatically lower the maximum SCSI bus rate to 5MHz when an external cable is found. Some external SCSI cables are not capable of handling higher transfer rates without producing data errors. Enable this feature to prevent data integrity problems if you have external SCSI devices with long cables.</p>
Transfer	<p>The maximum possible SCSI transfer rate. SmartRAID V controllers automatically negotiate with each SCSI device at power-up, or reset, to determine the maximum SCSI transfer rate. This parameter should not be changed except when troubleshooting SCSI bus errors. If data errors are eliminated by setting the value to a lower rate, there might be problems with the length of the bus or the bus termination.</p>
Termination	<p>This parameter sets SCSI termination for the controller. The default (Auto) should not be changed unless both internal and external Wide SCSI cables or 8-bit (Narrow) cables are connected to the controller. Refer to Chapter 3, “Configuration and Installation” for information about configuring SCSI bus termination.</p>
Address	<p>This field displays the controller memory address assigned by the host BIOS. This value cannot be changed.</p>

Buttons available are:

Test Alarm – lets you test the audible alarm on the controller.

Flash – displays the Flash Configuration dialog to update the controller firmware and BIOS.

Caching – allows you to select the controller cache parameters.

Defaults – resets the controller configuration to factory default settings.


Cancel – cancels any changes you have made and returns to the Host Bus Adapter Info window.

NOTE *The specific buttons you see depend on the controller model and configuration.*

Flash Configuration

This dialog is displayed when you click on the Flash button in the Configure Host Bus Adapter window.

NOTE *It is easier to perform an update if the image files are placed in the root directory of a diskette. Each component must be upgraded as a separate operation.*



The image shows a 'Flash Configuration' dialog box with a teal title bar. It contains several sections for configuration:

- HBA Section:** Includes fields for Model (DPT PM3754U2), Firmware Version (2118), and Firmware Type (375).
- Filename Section:** A text field containing 'A:\I20BIOS.12A' and a 'Browse...' button.
- HBA Firmware Section:** Fields for Version (n/a), Date (n/a), and Type (n/a). A 'Flash' checkbox is present and is currently unchecked.
- I20 BIOS Section:** Fields for Version (1.2A) and Date (5/12/99). A 'Flash' checkbox is present and is checked.
- SMOR Section:** Fields for Version (n/a), Date (n/a), and Build (n/a). A 'Flash' checkbox is present and is unchecked.

At the bottom right, there are 'OK' and 'Cancel' buttons.

The current controller Model, Firmware Version and Type are displayed. To specify an image file for the flash operation, you can type a path and filename in the Filename field or click on Browse to use the standard file selection dialog.

Firmware images are contained in a xxxxxxxx.FWI file, where the 8-character file name consists of the 4-digit controller model and a 4-digit release number. A DPT I₂O BIOS image is contained in a file named I2OBIOS.xxx (where, xxx is the version number). SMOR updates are contained in a file named SMORyyyy.xxx. Where, yyyy is the version number and the file extension (xxx) is the build number. You can obtain the latest files by contacting DPT Technical Support or download the files from our FTP site at ftp.dpt.com.

When you select an image file, Storage Manager reads the file to determine the type of image selected, firmware, I₂O BIOS, or SMOR. The Version, Date and Type are displayed in the corresponding section of the dialog.

Click OK to begin the flash operation. Click Cancel to return to the Configure Host Bus Adapter window.

Controller Caching for Windows NT

The SmartRAID V controller manages its data cache according to built-in algorithms (see Caching Configuration in this chapter and Chapter 7, “Theory of Operation” for additional information). If you are using Windows NT 4.0, do the following to ensure optimum performance:

1. Click Caching in the Configure Host Bus Adapter window to display the HBA Caching Configuration dialog.
2. When the HBA Caching Configuration dialog appears, change both of the settings to Advisory.
3. Click OK to exit the dialog and save the changes.
4. Reboot the Windows NT system to enable the new settings.

NOTE

If you reset the NVRAM on the controller, the changes to your cache settings return to the factory default of Mandatory. In that case, repeat this procedure to ensure optimum performance under Windows NT.

Device Information Window

This window displays the following information:

The screenshot shows the 'SCSI Device Information' window with the following fields and values:

- Description:** SEAGATE ST34520W
- Revision:** 1206
- Address:** HBA: 0, Bus: 1, ID: 12, LUN: 0
- Capacity:** 4339 MB
- Sectors:** 8887899
- Bytes/Sector:** 512
- Transfer:** 20 MHz, 40 MB/second
- Status:** Optimal
- SCSI Capabilities:**
 - Soft Reset
 - Cmd Queuing
 - Linked Cmds
 - Synchronous
 - Wide 16
 - Wide 32
 - Relative Addr
 - SCSI-II
 - S.M.A.R.T.
 - SCAM
 - SCSI-3
 - SAF-TE
- Member of Array Group:** (RAID-5)
- Stripe Size:** 32 KB

Buttons at the bottom include: Fail Drive, Print, Event Log, and OK.

Description The manufacturer and model.

Revision The drive firmware version.

Address The logical address of the device.

Capacity Storage capacity of the device in megabytes.

For removable media disk devices, Capacity is reported for the currently inserted media. Disk devices also display the number of Sectors on the media along with the Physical and Logical sector size.

Other information such as the Transfer rate or whether the device supports Removable media are also reported depending on the system configuration.

The current device Status is displayed. General status conditions (other than Optimal) are also indicated by colored flags on the device icon. SCSI Capabilities shows which supported features are enabled [x] for the device.

Members of an array display the name and RAID level of the array to which they belong and the Stripe Size for the array.

Various buttons are available depending upon the type of device. Disk drive devices will have an Event Log and I/O Stats button. Disk drives that are not members of arrays have Make HotSpare, Configure and Format buttons. Print is always available.

Disk drives that are members of arrays display a Fail Drive button.


If the drive is a Hot Spare, the Remove Hotspare button replaces the Make Hotspare button.

Caching Configuration

Clicking the Configure button in the SCSI Device Information or the Array Group Information window displays the Device Configuration dialog. This dialog lets you change the Write caching parameters.

Click Defaults to set the cache operation to the default setting.

Click Cancel to exit this dialog without saving changes. Click OK to exit with changes.



Write back mode defers writes to disk until after command completion and generally provides better performance. Write through mode writes all data to disk for each write command before command complete status is returned to the host. The data can also be cached for subsequent read commands.

The Predictive Cache checkbox enables and disables the predictive caching feature on SmartRAID V controllers. By default the box is not checked and the feature is disabled.

Predictive caching is a feature of SmartRAID V controllers that attempts to reduce average disk access time by determining when the host is requesting data that it read previously and reading in additional sequential data before it is actually requested.

This feature can provide enhanced performance when you have a host with 20 or more users who are frequently accessing large, individual sequential files. Unless your configuration is similar to this, you will not see any benefit from using Predictive Cache and using it will adversely affect overall controller performance. For additional information about predictive caching, see Predictive Caching Algorithms in Chapter 7.

Array Groups


The tool bar at the top of the Logical Configuration View window contains Create Array Group, Expand Array Group (Windows NT only) and Delete Array Group buttons. The Expand Array Group button allows you to add drives to an existing array and dynamically resize the logical drive.

SmartRAID V controllers can implement any combination of RAID level 0, 1 or 5 disk arrays. RAID 0 arrays can be any combination of individual drives. RAID 1 arrays are composed of two drives. RAID 5 arrays must contain at least three drives. One or more arrays of the same RAID level can be combined into a Parity Group. (This is also referred to as RAID 0+1 for multiple RAID 1 arrays or RAID 0+5 for multiple RAID 5 arrays.) The drives in a Parity Group appear as a single Logical Storage Unit (LSU) to the host computer.

NOTE

On SmartRAID V controllers, all drives in an array must be attached to the same controller. For controllers with drives on multiple SCSI bus channels, arrays are built using the drives in the order in which they were selected regardless of the bus to which the drive is attached.

This behavior can be used to create fault-tolerant SCSI bus configurations using pairs of drives on alternate channels in a RAID 1 or RAID 0+1 array or with drives distributed across all three channels for a RAID 5 or RAID 0+5 array.



From the Logical Configuration View, you can double-click on an Array Group icon to display the Array Group Information window. Information windows for arrays that are part of a Parity Group can be viewed by clicking on the icons for those arrays.

Array Group Information	
Name:	<input type="text"/>
Address:	HBA: <input type="text" value="0"/> Bus: <input type="text" value="2"/> ID: <input type="text" value="12"/> LUN: <input type="text" value="0"/>
Capacity:	<input type="text" value="8679"/> MB
Status:	<input type="text" value="Optimal"/>
Hotspares:	<input type="text" value="(0,1,14,0) SEAGATE ST34520W 4339 MB"/>
Components:	<input type="text" value="(0,1,12,0) SEAGATE ST34520W Stripe: 32 KB"/> <input type="text" value="(0,1,13,0) SEAGATE ST34520W Stripe: 32 KB"/> <input type="text" value="(0,2,11,0) SEAGATE ST34520W Stripe: 32 KB"/>
<input type="button" value="Configure"/> <input type="button" value="Print"/>	
<input type="button" value="Event Log"/> <input type="button" value="I/O Stats"/> <input type="button" value="Verify"/> <input type="button" value="Name"/> <input type="button" value="OK"/>	

The Array Group Information window displays the following information:

Name	The descriptive name assigned to the array. An icon in the upper right corner of the window indicates the RAID level.
Address	This is the logical device address used by the host operating system to access the logical drive. The address is the same one as the lowest device address disk drive in the array.
Capacity	The total usable storage capacity of the array in megabytes (MB).
Status	The current status of the array as reported by the controller.
Hotspares	Displays a list of any Hot Spare drives that are available to protect the array in the event of a drive failure.
Components	Displays the logical address, model and stripe size for each member of the array. If this a Parity Group information window, the list displays the address or name and stripe size for each disk array that is a member of the parity group.

NOTE *The availability of the various buttons depends on the current configuration and state of the array.*

Buttons include Configure, Print, Event Log, I/O Stats, Verify/Fix and Name.

A Rebuild button will appear for redundant arrays that have a failed drive.

For arrays that are building or rebuilding, a Stop Bld button is displayed.

For arrays that have a build pending, a Build button is displayed.

Arrays running Verification will have Stop Vfy button.

Creating an Array Group

To create an Array Group, do the following:

1. Click the Create Array Group button.
2. The Select Array Type dialog appears.

The screenshot shows a dialog box titled "Select Array Type". It is divided into three sections:

- Fault Tolerance:** Contains two radio buttons. "Drive fault tolerance" is selected (indicated by a filled circle), and "No fault tolerance" is unselected (indicated by an empty circle).
- Optimization:** Contains two radio buttons. "Optimize for Capacity" is selected (indicated by a filled circle), and "Optimize for Performance" is unselected (indicated by an empty circle).
- Chosen Array Parameters:** Displays "RAID-5" and "Stripe Size: 32 KB". Below this information is a button labeled "Override".

At the bottom right of the dialog, there are two buttons: "Continue" and "Cancel".

Specify whether or not you want Drive fault tolerance (RAID 1 or 5) or No fault tolerance (RAID 0)

Select whether the array is to be Optimized for Capacity (RAID 5) or Optimized for Performance (RAID 1).

As you make your selections, the Chosen Array Parameters change to indicate which RAID level and stripe size best suit your selection.

You can customize the RAID level and stripe size defaults by selecting the Override button.

3. Click Continue to select the drives you want to use. The Logical Configuration View window will appear with the caption Choosing drives for Array (RAID n), where n is the RAID level chosen.

Select the drives you want to use in the Array Group as follows:

- **To add drives:**

Mark each drive to be added by clicking on it. A green check mark indicates that a drive is selected.

Click Include Drive to add the marked drives to the new Array Group. You may need to scroll the window to view the Array Group.

- **To remove drives:**

Click on the drive icons you want to remove and then click Remove Drive.

During the drive selection process some drives might be displayed in a blue color. This indicates that these drives cannot be included in the array unless you change the configuration. You must either select more drives for the array or remove one or more drives from the array. See the introduction to the Array Groups section for rules regarding the number of drives that can be included in arrays.

4. When you finish selecting the drives to be included in the new Array Group, click Done.

The icon for the Array Group will appear with a black flag until you start the build process by saving your changes.

5. When you are finished creating arrays, exit Storage Manager.


You will be prompted to save the configuration changes. If you save the configuration, the build operation will start automatically. If you have created multiple arrays, they are built one at a time in the order they were created.

You can also start the build without exiting Storage Manager by selecting **File—Set System Configuration**.

NOTE:

For large redundant arrays, this process can take several hours to complete. You can exit Storage Manager and perform other activities on the system while the build continues. The arrays being built can be accessed during the build as non-redundant arrays. The arrays will be redundant when the build is complete.

6. RAID 1 arrays are created by copying the data on one drive of the mirrored pair to the other. If you have specified a RAID 1 array, you are prompted to select the direction of the copy.



If you want to monitor the progress of the build operation, display the Array Group Information window for the new array group. The build progress is displayed as a percentage of completion in the Status field. You can also view the Information window for an array that is a member of a Parity Group to monitor the progress for that component of the Parity Group.

Naming an Array Group

Click the Name button in the Array Group Information window to assign a unique name to an Array Group or Parity Group. This name will be displayed under the array icon and other locations that display the array identifier. The name can be 1 – 13 characters in length.

NOTE *You must restart the host computer before the new array name will take effect.*

Dynamic Array Expansion

NOTE *Dynamic Array Expansion is available only for arrays created with SmartRAID V controllers running in a Windows NT host system.*

Dynamic Array Expansion allows you to increase your storage capacity by adding one or more drives to your RAID 0 and RAID 5 arrays while your system remains online. As additional drives are added, the controller redistributes the data on the array, placing the new space at the end of the LSU and increasing the size of the logical drive as seen by Windows NT.

Before this feature was available, to increase the size of an array you had to backup the data on the array, shutdown the host system, delete the old array, and then build a larger array that included the new drives. After the larger array was built, you would reinstall the operating system (if necessary) and restore the data from the backup. This entire process could keep your system off-line for at least one day and possibly longer.

Dynamic Array Expansion lets you add the new drives to the array while the system is active and users are logged in and accessing data. After the array is expanded, use Windows NT Disk Administrator to add the additional space to the volume set of the array, then shutdown the system and restart. When the system restarts, Windows NT recognizes the additional space as part of the existing logical drive.

NOTE *There is a significant impact on system performance during array expansion. The relative priorities given to system performance and the array expansion process can be adjusted by use of the Background Task Priority setting in Storage Manager.*

Dynamic Array Expansion maintains the performance gains of RAID 0 and RAID 5, spreading accesses randomly across the drives in the array. The DPT controller presents the same number of LSUs to the operating system after the expansion. There is no need for manual load balancing, which would be required if the new space were presented as an additional LSU.

Requirements and Restrictions

Expand refers to the process of adding additional space to an existing array group using the Dynamic Array Expansion feature. *Extend* refers to the process of adding the new space created by the array expansion to the existing Windows NT volume (LSU).

Dynamic Array Expansion has the following system requirements:

- Windows NT Server or Windows NT Workstation (Version 4.0 and later with the most recent Service Pack).
- Dynamic Array Expansion requires the I₂O OSM supplied by DPT.

The Microsoft-supplied OSM does not support Dynamic Array Expansion.

- Dynamic Array Expansion and volume extension is supported only for RAID 0 or RAID 5 array groups using the NTFS file system.

You cannot extend a volume that has a FAT partition. The expanded space must be added as a separate LSU.

You cannot extend the Windows NT boot partition.

- The array must have Optimal status before beginning the expansion. If the array status is not Optimal, correct the problem and complete a rebuild of the existing array before continuing with expansion.

NOTE *If a drive fails during expansion, the expansion will complete successfully. However, the new, larger array will be in a degraded state until the problem is fixed.*

If there is a Hot Spare associated with the array, the degraded array is rebuilt using the Hot Spare. If there is no Hot Spare, replace the defective drive, and start a rebuild of the array.

- Each new drive added to an array must be at least equal to the capacity of the smallest capacity drive already in the array.

In any RAID configuration, the drive with the least capacity in the array determines the usable capacity of all the drives in the array. Therefore, there is no advantage in adding a drive with a capacity larger than the smallest capacity drive already in the array.

Expanding an Array Group

IMPORTANT

DPT recommends that you backup your data before performing an operation that affects the configuration of a disk array. Do not power off the host system while the expansion operation is running.

To expand an existing Array Group, do the following:

1. Connect the additional drives to the peripheral bus and power-on the drives. Refer to the Chapter 3, “Configuration and Installation” if necessary.

NOTE *If the drives are not in hot-pluggable carriers, power down the system before adding drives to the peripheral bus.*

2. Start Storage Manager and click Switch View to change to the Logical Configuration View.
3. Select the Array Group to which you want to add drives by clicking the corresponding RAID 0 or RAID 5 icon.
4. Click Expand Array Group.
5. Mark the drives to be added to the array by clicking on them. A green check mark indicates that a drive is selected.
6. Click Include Drive. This will cause the marked drives to join the existing Array Group. The drives to be added are now marked New.

7. When you are finished choosing drives, click Done. The icon for the Array Group appears with a black flag until the expansion process is started.
8. Select **File—Set System Configuration** to start the array expansion. The status flag on the Array Group turns blue and the flags on the components turn white during the expansion process.

You can perform other activity on the system while the expansion continues, because the array is fully functional during the expansion process.

NOTE *For large arrays, the expansion can take several hours to complete. Host I/O activity can prolong the expansion process.*

If you want to monitor the progress of the expansion operation, you can use Storage Manager to view the Array Group Information window. Status is Expanding during the expansion process, Optimal when it has completed.

Reconfiguring Windows NT After Array Expansion

When the array expansion is complete, do the following to allow Windows NT to recognize the additional space:

1. Shut down and restart Windows NT.

NOTE *When restarting, Windows NT will run CHKDSK to verify the new space. This might take an extended period of time for large volumes.*

2. Start Disk Administrator. The new space appears as Free Space at the end of the existing logical drive.
3. Select both the original logical drive and the free space by highlighting both segments.
4. Select **Partition—Extend Volume Set...**

Click Yes when prompted to save your changes and to restart Windows NT.

Use the RDISK.EXE utility to update your emergency repair diskette with the new disk configuration information.

Deleting an Array Group

To delete an Array Group, do the following:

1. From the Logical Configuration View window, select the LSU or Array Group icon of the array you want to delete. Then click Delete Array Group.
2. Click OK when the confirmation message appears to complete the delete operation.

Click Cancel to exit without deleting the Array Group.

An array is not physically deleted until you exit Storage Manager and choose to save changes or select **File—Set System Configuration**.

NOTE *In a Microsoft Cluster Server configuration, a logical array that is deleted can continue to appear as available in a remote session from the other server in the cluster or from a remote client. The cluster servers must be restarted to ensure that the deleted array does not continue to be reported as available.*

Saving the Subsystem Configuration

The Storage Manager File menu has four options:

Read System Configuration

Causes Storage Manager to read the current hardware configuration. Any changes that have been made and not saved are lost. This operation also occurs automatically when Storage Manager is started.

Set System Configuration

Causes Storage Manager to save any changes that you made to the storage subsystem configuration. If any arrays have been created or modified, this action causes the controller to start build operations for the new arrays.

Load Configuration File

Lets you load a previously saved configuration into Storage Manager and apply it to the current hardware.

Save Configuration File

Lets you save the current configuration, or any changes to that configuration, to a file for later use. This feature allows storage subsystems to be configured for other machines with the same size and type drives, then later loaded from the configuration file.

NOTE *If you reset the NVRAM on the controller, any changes to your controller parameters return to the factory defaults.*

Events

Events are generated for detected fault conditions as well as subsystem status changes. The events are grouped into four categories as follows:

1 – Soft Error

An operation on a disk drive that caused an error but was successful after a retry.

2 – Recoverable Hard Error

An error on a disk drive, controller or peripheral bus, where the data was recovered using ECC or from redundant array information.

3 – Nonrecoverable Hard Error


An error on a disk drive, controller or peripheral bus where the data could not be recovered using ECC or from redundant array information.

4 – Status Change

The status of an array or drive changed. Examples of this would be a drive or array failure or an array build or rebuild operation that was initiated or completed.

Event Logging

When events occur, they are automatically logged in the cache on the SmartRAID V controller where they occurred. In addition, you can specify that Storage Manager maintain an event log on disk (see Event Notification). The contents of the event log can be displayed by clicking Event Log in any controller, drive or array information window. Only the events pertaining to that controller, drive or array are displayed.



When the Event Log button is selected, the Event Log window appears. The Event Log window lets you specify that the display be limited only to events of a specific level or higher (the default is level 4).


NOTE *Some important events may not be displayed by the default level. You should select one of the higher event levels to ensure that you are aware of significant errors that might have occurred.*

Click on the arrow buttons to adjust the Display Threshold to the desired level.

Click View Log to see the event messages whose levels match the selected levels.

Event Notification

If your operating system supports a Broadcaster, Storage Manager lets you specify that event messages be sent to users, groups, devices, through e-mail, to the system error log and the DPT Log File. Select **Options—Event Broadcast Control** to display the Event Broadcasting dialog. The options in the Event Broadcasting dialog may vary depending upon your operating system.



The dialog box titled "Event Broadcasting - Version 2.0G" contains the following elements:

- Time Interval:** A text box containing "1" followed by "minutes (1-120)".
- Event Messages:** A list of checkboxes:
 - Broadcast to computer(s)
 - Local desktop message
 - Email to Users
 - Log to Event Viewer
 - Send to a numeric pager
- Computer Names:** A vertical list of five empty text boxes.
- Email Users:** A vertical list of five empty text boxes.
- Display Threshold:** A vertical slider with a green bar. To its right is a list:
 - 1 Soft Errors
 - 2 Recoverable Hard Errors
 - 3 Nonrecoverable Hard Errors
 - 4 Status Changes
- Begin Page:** A vertical list of three empty text boxes.
- End Page:** A vertical list of three empty text boxes.
- Buttons:** Four buttons at the bottom: "Stop Broadcasting", "Unload Broadcaster", "Print", and "OK".

Click Stop Broadcasting to stop Storage Manager from sending event messages to the locations or addresses specified.

Click Unload Broadcaster to remove the Broadcaster service from the current set of active services.

You can select or modify the following parameters:

Time Interval

Specified time interval at which point the Broadcaster will read the event logs of all DPT controllers with cache. Any new event messages are broadcast to each specified destination (based on the Display Threshold setting).

Broadcast to Computer(s)

Enable this option to send event messages to each system in the Computer Names list.

Local Desktop Message

Enable this option to have event messages displayed on the local system desktop.

E-Mail to Users

Enable this option to mail event messages to each e-mail address in the Email Users list.

Log to Event Viewer

Enable this option to also log and display event messages in the Windows NT Event Viewer.

Computer Names / Email Users

Use these fields to specify a list of computer systems or e-mail addresses that are to receive broadcast event messages.

Display Threshold

Click on the arrow buttons to adjust the indicator to the threshold you want to use for reporting events. Messages will be broadcast for all events whose levels match those selected.

Pager Event Messaging

DPT Storage Manager for Windows NT can also send event messages to alphanumeric paging devices. The messages are sent as e-mail to pagers that support e-mail text message delivery.

NOTE: *This feature should work with any alphanumeric paging system that supports message delivery via e-mail. Contact your service provider for specific information.*

The following procedure applies to the system that is running the Storage Manager Event Logger to monitor DPT controllers and attached disk arrays.

To configure alphanumeric pager support, do the following:

1. Ensure your pager is working and activated through a service provider.
2. Establish a permanent connection to an Internet service provider (ISP) or create Dial-up Networking connection to your ISP.
3. Configure your e-mail client software to access your Internet mail server.
4. Determine the e-mail addresses for the people you want to receive event messages.
5. In Storage Manager:
 - a. Set the Display Threshold to the level where you want to start broadcast messages.
 - b. Enable E-Mail to Users in the Event Broadcasting dialog (Options—Event Broadcast Control).
 - c. Enter the e-mail addresses for the pagers in the E-Mail Users list.
 - d. Click on OK to exit the dialog and save the changes.

When the Event Broadcaster is active, the Event Logger will send text messages for selected events to the pager using the e-mail address you specified.

Broadcasters

Broadcasters are provided on the DPT diskettes for Windows NT, SCO UNIX and SCO UnixWare. The Broadcaster collects events logged by DPT controllers in the host computer on which that broadcaster is running. The Broadcaster records these events to disk files for each controller for use by Storage Manager. Additionally, events whose levels are greater than or equal to the current Broadcast Threshold are sent to destinations as specified in the Storage Manager Event Broadcasting dialog (see Event Notification).

Broadcaster for NetWare

A Broadcaster is provided for NetWare. The Broadcaster collects events from DPT controllers and records them to files in the SYS:\SYSTEM\DPT directory for use by Storage Manager. Additionally, events are broadcast to the User/Group list, the system console and the system error log file as specified in the Storage Manager Event Broadcast Control window.

Installing the Broadcaster

The DPT diskette for NetWare contains the Broadcaster for NetWare. When this diskette is installed, the Broadcaster is placed, by default, in the SYS:\SYSTEM\DPT directory on the server. During Broadcaster installation, you will be prompted to specify if the Broadcaster is to be loaded automatically when the server is booted. Doing so will allow events to be gathered and recorded without user intervention.

Stopping/Restarting the Broadcaster

The Broadcaster is a NetWare Loadable Module (NLM) that can be loaded or unloaded from the server's command prompt:

<code>unload DPTELOG</code>	unloads the Broadcaster
<code>load SYS:\SYSTEM\DPT\DPTELOG</code>	loads the Broadcaster

Viewing Events

Events can be viewed on a network workstation through the Event Log Display window in Storage Manager (see the Event Logging section). Events can also be viewed by examining the System Error Log file SYS\$LOG.ERR on the server if the Broadcaster has been configured to send events to that file.

Broadcaster for SCO UNIX Systems

DPT provides a Broadcaster for SCO UNIX 3.2V4.2, SCO OpenServer 5 and SCO UnixWare 7. The Broadcaster collects events from DPT controllers and saves them to files in the /usr/dpt directory for use by Storage Manager. Events can also be sent to an ASCII file, specified devices, the User/Group list or e-mailed to users as specified in the Event Broadcasting dialog.

Installing the Broadcaster

The DPT diskette for SCO contains the Broadcaster for SCO. When you install the software on this diskette, the Broadcaster is copied to /usr/dpt. During Broadcaster installation, you are prompted to specify if the Broadcaster will be loaded automatically when the system is started in multi-user mode.

If you specify automatic loading, events are gathered and recorded without user intervention. This also copies a script file, S33dpt, to the /etc/rc2.d directory. This script automatically loads the Broadcaster as a background process when the system goes into multi-user mode.

NOTE *Do not use the S33dpt script file for UnixWare 7 Broadcaster operation.*

Stopping/Restarting the Broadcaster

A script file (dptlog) is provided that lets you stop and restart the Broadcaster from the UNIX prompt. Use the following commands to stop or start the Broadcaster:

```
dptlog stop            stops the Broadcaster
dptlog start          restarts the Broadcaster
```

Viewing Events

Events can be viewed from the system console or a terminal by using the Event Logs window in Storage Manager (see Event Logging).

Broadcaster for Windows NT

The Windows NT Broadcaster collects events from DPT controllers and records them to files in the \DPTMGR directory for use by Storage Manager. Additionally, events are sent to the Windows NT Event Viewer.

Installing the Broadcaster

When the DPT installation program runs, the Broadcaster is copied to the C:\DPTMGR subdirectory by default. The Broadcaster is installed as a Windows NT service and runs automatically whenever the system is started. This allows events to be gathered and recorded without user intervention.

Stopping/Restarting the Broadcaster

Because the DPT Broadcaster is a Windows NT Service it must be managed from one of the Windows NT service management applications:

- The Broadcaster can be controlled using the Services Control Panel. Services is accessed by selecting the Services icon in the Control Panel folder.

Highlight the DPTSERV entry in the Services list. Then click on Start or Stop to start or stop the Broadcaster service.

- The Broadcaster can also be started or stopped from a command line prompt by using the NET command as follows:

NET START DPTSERV	starts the Broadcaster
NET STOP DPTSERV	stops the Broadcaster

Viewing Events

Events can be viewed either through the Event Log Display window in Storage Manager (see Event Logging) or the Windows NT Event Viewer. The Event Viewer is part of the Windows NT operating system.

To run the Event Viewer, select Event Viewer from the Administrative Tools group on the Start menu. The Event Viewer lets you view events that have been placed in the System, Security, and Application logs. To view DPT events, select **Log—Application**.

This window displays a list of the events submitted to the Application Log by the DPT Broadcaster, as well as other applications. Events are single-line entries that contain the following information:

Icon	An icon that indicates the Windows NT severity level for the event. DPT events can be assigned severity levels of Error, Warning, Information, Operation, or Unknown.
Date	The date the event was logged by the controller.
Time	The time the event was logged by the controller.
Source	The software component that triggered the event. This can be an application, a component of Windows NT or a device driver. DPT events can have DPTELOG, DPTENG32 or DPTSCOM in their Source field.
Category	DPT events can display None, Operation, Warning or a hexadecimal event code.
Event ID	A number assigned by the Broadcaster to identify the event for Windows NT.
User	DPT events always display N/A.
Computer	The name of the computer where the event occurred.

Additional information about an event can be obtained by selecting **View–Detail**. The Description and Data fields display additional information about the event. The Description field contains a detailed text description of the event. The Data field contains the original DPT Event Log data, generated by the controller. This data might be requested by DPT Technical Support when troubleshooting problems.

Event information can be saved by the Event Viewer to a file. If the file is saved in text format then only the event description is saved. Archiving in Event Log (.EVT) file format saves all event information which can then be sent to another person for troubleshooting purposes.

Formatting Drives

SmartRAID V controllers can perform a *low-level* format on attached fixed disk drives. This function is available from the SCSI Device Information window in Storage Manager. SmartRAID V controllers format drives in standard 512-byte format.

A low-level format is not normally required before using a disk drive. However, if a drive has been previously formatted with a different sector size, it must be reformatted with 512 byte sectors before it can be recognized by the SmartRAID V controller.



Do not power-down the drive or reboot the computer until after the format operation is complete. Doing so can cause drives to be left in an unusable state and require them to be returned to the manufacturer for repair.

To perform a low-level format on a disk drive:

1. Click Format in the drive's SCSI Device Information window. The Format Options dialog appears.
2. Click Format in the Format Options dialog to start the operation.
3. You can now exit Storage Manager. The format operation will continue even though Storage Manager is not running.

To determine if the format has finished, run Storage Manager and look at the drive's icon. A blue flag indicates that the format is still in progress. If the drive icon has no flag, the format is complete.

Drive Failures

Drive failures are indicated by flags on the icons associated with the Array Group, array and individual drives. Failure conditions are indicated as follows:

A drive belonging to an Array Group fails

The drive icon displays a red flag in both the Physical and Logical Configuration Views.

The failed drive belongs to a RAID 0 Array Group

The icon for the failed drive displays black flag. Loss of any drive in a RAID 0 array means the array has failed and data on that array has been lost.

The failed drive belongs to a RAID 1, 0+1, 5, or 0+5 Array Group

The array icon displays a yellow flag, indicating that the array is currently running in degraded mode. If two or more drives belonging to the same array show a red flag, the yellow flag on the array changes to red, indicating that the array has failed and that data has been lost.

Audible Alarm

DPT controllers with caching capability (Millennium models or Decade/Century models using an RA4050 module) have an audible alarm. The failure of a drive which is a member of an array attached to the controller causes the audible alarm to sound. The alarm stops automatically (after the initial system scan) when you start Storage Manager or SMOR.

Alarms that occur while Storage Manager is running can be stopped by selecting **Options–Turn Off Audible Alarms**.

Rebuilding a Degraded Array

NOTE *You can select Rebuild even if the failed drive has not been replaced and try using the drive again. If the rebuild attempt is not successful, replace the drive before starting another rebuild.*

When a drive in a RAID 1 or RAID 5 array fails, and that drive is not protected by a Hot Spare, do the following to restore the array to Optimal status:

1. Replace the failed drive according to the procedure in your hardware documentation.
2. After the failed drive has been replaced, choose the Logical Configuration View in Storage Manager.
3. Double click the array group icon to open the Array Group Information window.
4. Click Rebuild in the Array Group Information window to start the rebuild process.

The drive will display a white flag to indicate that a rebuild operation is in process. The array and LSU icons will display yellow flags. The percentage completion of the rebuild operation is displayed in the Array Group Information window. When the rebuild is complete, the flags will disappear and the array status should be Optimal.

NOTE *If you are using a DPT RAIDstation storage cabinet with a SmartRAID V controller, failed drives can be replaced and rebuilt without using Storage Manager. RAIDstation storage cabinets and drives have hot swap (SCA-2) connectors so that failed drives can be removed or replaced without first quieting the bus. The RAIDstation subsystem will detect that a failed drive has been physically replaced and the controller will automatically start a rebuild operation.*

Hot Spares

To assign a drive as a Hot Spare, click Make Hotspare in the drive's SCSI Device Information window. Click Remove Hotspare to reassign an existing Hot Spare drive as a normal drive.

Any drive that is not assigned to an array can be assigned as a Hot Spare. Hot Spares are reserved to automatically replace failed drives in RAID 1 or 0+1 and RAID 5 or 0+5 arrays and cannot be accessed by the operating system for data storage. Hot Spares can only protect drives of equal or less capacity that are attached to the same controller as the Hot Spare.

When a drive failure occurs in an array protected by a Hot Spare, the controller automatically starts rebuilding data onto the Hot Spare. During this process, Storage Manager swaps the positions of the failed drive and the Hot Spare in the Logical Configuration View. The failed drive will appear with a red failed flag in the former position of the Hot Spare, and the Hot Spare will appear as a member of the Array Group with a white flag indicating that a rebuild operation is in process. The array and LSU icons appear with yellow (degraded) flags.

When the rebuild is complete, the Hot Spare icon and flags will disappear and the drive will be displayed as a normal member of the array. The red flag will remain on the failed drive until that drive is replaced or returned to Optimal status.

Do the following to replace the failed drive:

1. Follow the steps in your hardware documentation to remove and replace the failed drive.
2. Click Make Optimal in the new drive's information window.

The new drive will become the a Hot Spare, replacing the previous Hot Spare that is now a member of the rebuilt Array Group.

NOTE

You can select Make Optimal without replacing the drive if you want to try using the drive again. If the operation fails, you should replace the drive.

Verify

NOTE *Data inconsistencies should not occur under normal conditions. However, a power failure that interrupts an array write operation can cause inconsistencies. Using the Verify function to make the data consistent does not ensure that the new consistent data is the correct data.*

Running a Verify operation for RAID 1 and RAID 5 arrays ensures that the redundant information contained in the array is consistent. This operation is performed by the SmartRAID V controller concurrent with normal system operation and requires no user or host computer intervention.

To start data verification on an array, select Verify in the Array Group Information window.

If any inconsistencies in the data redundancy are found, they are made consistent.

For RAID 1 arrays, the mirrored drive pairs are compared sector by sector to ensure that both drives contain identical data.

For RAID 5 arrays, parity is recalculated and checked against the stored parity information.

For RAID 0, only a disk media ECC check is performed.


Running Verify on an array that is in a degraded state can result in significantly reduced I/O performance. Although there is no impact on the host CPU, system I/O performance can be affected due to increased demand on controller resources. If this is a concern, use the Background Task Priority feature to assign a lower level priority to background processes.

Background Task Priority

You can run rebuild and verification operations without taking an array offline. These functions are performed as background tasks on the SmartRAID V controller and are transparent to the host operating system. However, the controller interleaves I/O from the operating system with I/O from the background task and this can affect system performance. The relative priority given to I/O from the operating system and the background task can be controlled by selecting **Options–Background Task Priority**.

The Task Priority section of the dialog assigns the background task priority for all DPT controllers in the host computer. Set the Priority by using the arrow buttons to move the indicator . The indicator moves between Background and Foreground in ten increments.

If the indicator is closer to Background, background tasks are processed only when there is no disk I/O from the host for a period of at least 250 milliseconds. As the indicator is moved toward Foreground, more of the controller resources are allocated to background tasks. All of the resources are allocated to background tasks during periods when there is no disk I/O from the host system.



I/O Statistics

SmartRAID V controllers keep a cumulative record of I/O operations in cache RAM for use in analyzing the efficiency of the storage subsystem. You can view this data by selecting I/O Stats in the Information window for any, controller, drive or array. By analyzing these statistics, the array configuration, cache and stripe size can be optimized for your particular system configuration.

Controller I/O Statistics

The screenshot shows a dialog box titled "HBA Statistics". It is divided into two main sections: "Cache Statistics" and "Commands".

Cache Statistics	
Total Pages	1784
Used Pages	1000
Dirty Pages	0
Read-Ahead Pages	128289
ECC Fault Pages	0

Commands	
Total Commands	35944
Mis-aligned Transfers	0
SCSI Bus Resets	0

At the bottom of the dialog box, there are three buttons: "Clear", "Print", and "OK".

Click the I/O Stats button in the Host Bus Adapter Information window to see cache statistics for that controller. These statistics include:

Cache Statistics

Total Pages	The total number of pages contained in the controller cache.
Used Pages	The number of pages that currently contain disk data.
Dirty Pages	The number of pages that contain dirty data.
Read-Ahead Pages	The number of cache pages that contain data that has been loaded from disk as a result of read-ahead functions.
ECC Fault Pages	The number of pages that have been mapped for non-use after a RAM fault was discovered by the controller ECC feature

Command Statistics

Total Commands	The total number of commands received from the host computer. This includes read and write commands and other commands that may not involve device I/O.
Misaligned Transfer	The number of commands that required data to be transferred starting at a RAM address location that was not an even byte value.
SCSI Bus Resets	The total number of SCSI bus resets that have been issued by the controller. A large number of resets can indicate a problem with the SCSI bus or an attached device.

Device I/O Statistics

Hard Drive I/O Statistics		
Read Statistics		
Total Sectors	89720	
Cache Hits	17351	
Cache Misses	72369	
Read-Ahead Hits	17343	
Write Statistics		
Total Sectors	62963	
Write-Backs	62963	
Write-Throughs	0	
I/O Commands		
	Reads	Writes
1 KB	327	2724
2 KB	303	624
4 KB	980	1106
8 KB	229	391
16 KB	457	1187
32 KB	1309	34
64 KB	80	31
128 KB	0	0
256 KB	0	0
512 KB	0	0
1 MB+	0	0
Total	3685	6097
<input type="button" value="Clear"/> <input type="button" value="Print"/> <input type="button" value="OK"/>		

Write-Backs + Write-Throughs = the total number of sectors written to disk by the controller.

I/O Commands	The number of read and write commands issued by the computer to the controller. If you use RAID and caching, the number of commands issued to the drives can differ significantly from this value.
Total Sectors	The total number of sectors read and written from the host computer.
Cache Hits	The total number of sectors (read or written from the host computer) that were found in the controller cache and did not require a disk access.
Read-Ahead Hits	The number of the cache hits for data read requests satisfied by data held in the cache from previous disk read-ahead operations.
Write-Backs	The number of sectors written to disk that were held in the controller cache and written some time after the host write command reported as completed.
Write-Throughs	The number of sectors written directly to disk before the write command ended.

In RAID 1 arrays, (Write-Backs + Write-Throughs) can be up to twice the value of Total Sectors because each sector written from the host results in a write to each mirrored disk. In RAID 5 arrays, each write from the host can generate up to two disk reads and two disk writes. If the controller has cache memory, this can result in the actual number of sectors read from or written to disk being reported as less than this value.

Environments with a large number of sequential reads should generate a high number of Read-Ahead Hits relative to Total Sectors. These hits reduce the number of seek operations and increase performance. The read-ahead hits count can be increased by adding more cache memory to the controller. A high percentage of 4KB or smaller I/O operations also indicates that increasing the controller cache would be beneficial.

If cache hits are low, adding more cache RAM can also increase the hit count. Systems with a large number of disk writes also derive significant performance benefits from the controller cache.


For RAID 0 and RAID 5 arrays, the default stripe size is set for optimal performance in most environments. However, some specific environments can benefit from smaller or larger stripes. For example, when a RAID 5 write operation accesses all drives there will be a large number of stripe crossings. By using a larger stripe size, the RAID 5 parity data can be generated more efficiently. This results in better write performance. However, if the write crosses one or more stripes but does not involve all of the drives, the performance will be *less* efficient with the larger stripe size.

You should choose the stripe size relative to both the I/O segment size and the number of drives in the array, so that most I/O operations either:

- Do not cross stripes and involve only a single drive
- OR
- Cross many stripes and involve all the drives in the array.


Remote Communication

The Storage Manager Remote Communication feature lets you use Storage Manager running on your local workstation to manage remote server systems that contain DPT controllers. The Available Connections window shows the types of connections you can use and any predefined connections you have created.



Communicating Across a Network

Storage Manager can run as a client/server application across a network using a TCP/IP connection. The Storage Manager client runs on a supported workstation operating system and connects to one of the supported networked servers running the DPT communication engine. The following illustration shows the supported workstation and server connections for a TCP/IP network.



Installation and Configuration

Remote Communication uses both workstation-based and server-based software components. The workstation (client) remote communication software is automatically installed during Storage Manager setup. You are given the option whether to install the Communication Server software when you run the Storage Manager setup program on an operating system that supports a DPT communication server (Windows 95/98, Windows NT, NetWare or SCO platforms).

You must configure Remote Communication before it can be used. For both workstations and servers, this is done by editing the DPT configuration file (DPTMGR.INI). There may be additional server configuration steps, depending on your operating system. You must have physical connections between the servers and client workstations.

NOTE *Under Windows 95/98, the server must be started manually by selecting the DPT Communication Server icon. This version of the communication server runs in a DOS window.*

Editing the Configuration File

Both the workstation and server communication engines use the DPT configuration file DPTMGR.INI. This file is contained in the directory in which you installed Storage Manager.

The [OPTIONS] section of the file controls the behavior of the communication server. To control the display of messages from the server, change the Verbose parameter:

```
[OPTIONS]
Verbose=x
```

where x is:

- 0 No messages
- 1 Basic messages (such as errors, connects and disconnects)
- 2 More messages (option 1 messages + socket numbers and TCP/IP addresses)
- 3 All messages (option 2 messages + message tracing)

The default is 1.

The [MODULES] section of the file tells the communication server the protocol you want to use for communication.

```
[MODULES]      (Specify as many as needed)
TCP            (Comm server will use TCP protocol)
```

Each protocol can have its own section, in which you can set additional parameters specific to the protocol. The following list shows all supported options. The value listed is the default; optional values are in parentheses.

```
[TCP]          (Available options for TCP protocol)
SOCKET=2091   (TCP socket on which to listen
               Can be any valid socket number)
```

Setting up the Server

If you are using an operating system that supports the DPT communication server and selected the Communication Server option during Storage Manager setup, the server was automatically installed at that time. Additional steps may be required to complete the installation, depending on your operating system. Some operating systems (such as Windows NT) require setting up a user name and/or password before the server can be accessed. The default password is `password`.

Windows NT Server

Under Windows NT, the server is installed as a service named DPT Communication Service and starts automatically when Windows NT starts.

Windows NT server access requires both a user name and password. The user name must be defined through the Windows NT User Manager. Additionally, the user name must have Administrator level privileges. Setup the user account for use by performing the following steps:

1. Log in with Administrator privileges.
2. From the Start menu select Programs–Administrative Tools–User Manager.
3. Select Policies–User Rights and check the Show Advanced User Rights box when the User Rights Policy dialog appears.
4. Grant the Act as part of the operating system and Log on as batch job rights to the Administrators group.
5. Reboot Windows NT before you attempt to use Remote Communication.

Windows 95/98

Under Windows 95/98, the communication server is installed as a DOS command line application. You can start the communication server by clicking on DPT Communication Server in the DPT folder on the Start menu.

The Windows 95/98 server is accessed by a password only; a user name is not required. The initial default password is `password`. To change the password, run Change Communication Password from the DPT folder in the Start menu.

SCO UNIX

Under SCO UNIX, a communication server entry is placed into the `rc.d` files, which causes it to be started when the system is booted into multi-user mode.

During installation, the file `dptcom.chk` is created in the directory into which Storage Manager is installed. The ownership of this file is set to `root/dtadmain`, and permissions are `-rw-rw---` (`6608`).

Access to SCO servers requires both a user name and password. After determining that the user name and password are valid on the system on which it is running, the communication server will attempt to open `dptcom.chk` using the user name.

Connecting Servers and Workstations

The Storage Manager client must have a valid network connection to connect to a remote server. Use the following guidelines to ensure that the workstation and server can communicate.


Servers and workstations communicating by TCP/IP must be connected by a local area network or the Internet. Some operating systems may require additional TCP/IP protocol configuration before use. Refer to your operating system documentation for more information.

The client workstation specifies the TCP/IP address of the server, along with a user name and password as required by the server.

Connecting to Remote Systems

Select Communication—Make Connection to use Storage Manager to manage DPT hardware in a remote server system using the remote communication feature. This menu item displays the Available Connections window.

NOTE: *You can also use the IP=*address* command line parameter when you start Storage Manager. This parameter causes Storage Manager to connect to the remote system at the specified IP address instead of the default Local connection.*




From this window, you can make a connection either by selecting an available protocol under Manual Connections and entering the name, address and password of the server; or by selecting an entry under Custom Connections. Custom connections are those for which you previously stored address information in the Phonebook (see Using the Phonebook for more information).

Making a Manual Connection

Under the Manual Connections section of the Available Connections window, there is an icon the TCP/IP protocol that you configured in the DPTMGR.INI file, and an icon for the system you are using (Local).

To make a connection to a remote system, click the icon that represents the protocol for that system. (To select the system from which you are running Storage Manager, select the Local icon). For icons except Local, the Connection Information dialog is displayed. Enter the address, user name (if required) and password for the server selected. Refer to Connecting Servers and Workstations for more information.




The image shows a dialog box titled "Connection Information" with a teal header. It contains four text input fields labeled "Computer:", "Address:", "Username:", and "Password:". Below the fields are two buttons: "OK" and "Cancel".

When you click OK, Storage Manager attempts to connect to the remote system. If the connection is successful, Storage Manager scans the DPT hardware on the remote system. When the hardware scan is complete, the Physical Configuration View window for the remote system appears.

Using the Phonebook

You can save the server name, address, user name and protocol of systems you frequently access in the Phonebook. After you have entered data for a system, you can place an icon under Custom Connections to make future connections to that system without having to reenter the connection information each time.

To make an entry in the Phonebook, fill in the appropriate fields.



The screenshot shows the 'Phonebook' dialog box. It has a teal title bar. On the left, there are four text input fields labeled 'Server Name:', 'Address:', 'Username:', and 'Protocol:'. The 'Protocol' field has two radio buttons: 'TCP/IP' (selected) and 'Modem'. Below these fields is a checkbox labeled 'Display icon for this entry' which is currently unchecked. To the left of this checkbox is a small icon of two computers connected by a line, with 'TCP' written above it. Below the checkbox is a 'Choose Icon' button. On the right side of the dialog, there is a list box containing the text 'Home Legacy'. To the right of the list box are five buttons: 'Add', 'Save', 'Delete', 'Connect', and 'Close', arranged vertically.

Select Display icon for this entry if you want an icon for this connection displayed in the Available Connections window. You can customize the icon to be used by clicking Choose Icon.


Click Add to add the new entry. Click Delete to remove unwanted entries. When you are finished, click Save to save your changes.

To make a connection from within the Phonebook, highlight the desired system and click Connect.

Using a Custom Connection

Under the Custom Connections section of the Available Connections window, there is one icon for each system that you marked for display in the Phonebook.

To make a connection to a remote system, double-click the icon. The Connection Information dialog appears. Enter the password of the server selected. Refer to Connecting Servers and Workstations for details.



The image shows a dialog box titled "Connection Information" with a teal header. It contains four text input fields labeled "Computer:", "Address:", "Username:", and "Password:". Below the fields are two buttons: "OK" and "Cancel".

When you click OK, Storage Manager will attempt to connect to the remote system. If the connection is successful, Storage Manager scans the DPT hardware on the remote system. After the scan is complete the Physical Configuration View window for the remote system appears.

NOTE: *You can also use the IP=address command line parameter when you start Storage Manager. This parameter causes Storage Manager to connect to the remote system at the specified IP address instead of the default local connection.*

CHAPTER 7:

Theory of Operation

This chapter provides background and reference information about:

- Operation of SmartRAID V controllers
- Disk array configuration
- SCSI device interfaces and cabling

Chapter Topics:

- Intelligent RAID Controllers
- Pipelined Parallel Processing
- Caching Algorithms
- RAID Levels
- Controller Architecture
- I₂O Messaging
- PCI Data Transfer
- On-board Microprocessor
- SCSI Interface
- Cabling and Termination
- Fibre Channel Arbitrated Loop
- I₂O BIOS

Intelligent RAID Controllers

File servers achieve maximum throughput when the performance of their component subsystems is optimized for the CPU bandwidth. If any component is not capable of supplying data at an optimum rate, that component will restrict the data path performance and slow down the entire system. Conversely, a component with significantly greater performance than the rest of the system can have much of its performance potential unused. Any attempt to speed up a server by increasing the performance of only some system components usually results in a negligible overall increase.

The speed of CPUs used in currently available file servers has increased greatly over those available a few years ago. However, the performance of data storage subsystems has not kept up. As a result, many servers have data storage subsystems that are not capable of supplying data to the CPU fast enough. Consequently the CPU can be idle for significant periods waiting for data and these servers cannot perform at their full potential.

In a traditional server, the host CPU handles the processing of I/O interrupts from peripherals, disk storage and network devices. This design was developed for the single-user and non-multitasking operating systems which were in use when microcomputers first became widely available. However, this design becomes a performance restriction when incorporated into graphics workstations or multi-user servers that have pipelined-architecture processors. On a busy server, the large amount of I/O interrupts sent to the host CPU reduces the number CPU clock cycles available to process application software instructions. Additionally, each interrupt causes the CPU internal pipelines and caches to flush their data, which results in additional CPU performance degradation.

Intelligent I/O

To maximize the performance of a busy server requires a data storage subsystem that incorporates intelligent I/O. Such a subsystem would have a microprocessor embedded in the I/O and storage subsystem that is dedicated to handling interrupt requests and I/O processing functions in place of the host CPU. Intelligent I/O frees the CPU to process user application software and requests, which significantly increases data throughput and overall system response. DPT SmartRAID V controllers implement intelligent I/O using an onboard RISC microprocessor.

Benefits

Controllers that depend on the host CPU for processing low-level I/O functions can require a significant portion of the total processing power of the system: from 25% to nearly 100%, depending on the task. Non-intelligent RAID controllers (that is, controllers without embedded I/O processors) also use the host CPU for RAID functions such as, striping and parity calculations, RAID-generated disk interrupts, and read and write data transfers. Intelligent controllers incorporating hardware-based RAID relieve the CPU from handling of these additional processes.

Intelligent host adapters and RAID controllers can provide the following benefits:

Optimum server performance – An I/O subsystem with performance matching the current powerful host CPUs allows servers to reach their maximum application processing potential.

I/O subsystem scalability – Server scalability through symmetric multiprocessing (SMP) can be matched with the installation of multiple intelligent controllers or by having multiple data channels per intelligent controller.

A greater number of users per server – With servers free to process more applications with greater bandwidth, more users can be assigned to each server.

Increased end-user productivity – With more CPU cycles devoted to servicing applications and user requests, system performance is improved yielding faster response time.

Reduced total cost of ownership – With improved performance, servers can support more users and fewer servers may be required to meet the overall needs of the organization. In addition, fewer servers and their support structure may be needed in the future.

I₂O and Intelligent RAID Controllers


Several information technology industry leaders have formed a Special Interest Group (SIG) to promote intelligent I/O standards for the entire industry. These standards, referred to as the Intelligent I/O (I₂O) specification, address the performance issues caused by I/O interrupts sent to the host CPU and the need for unique drivers for every combination of I/O device and operating system.

I₂O-compliant products include both intelligent host adapters and RAID controllers (those incorporating a microprocessor) and non-intelligent host adapters and RAID controllers (those without a microprocessor). Maximizing a server's potential requires more than just I₂O. It requires an intelligent adapter or controller with a dedicated microprocessor.

Intelligent I/O (both intelligent adapters and RAID controllers) has been available from DPT for two decades. The I₂O-compliant SmartRAID V controllers are the latest intelligent adapter technology, with fast RISC-based embedded I/O processors and our new Pipelined Parallel Processing (P³) technology.

The following illustration depicts the two-part device driver architecture used by I₂O compliant products. This design allows for much faster device driver development for specific operating system platforms. For additional information, see the SmartRAID V Architecture section in this chapter.


I₂O Split Driver Architecture



Pipelined Parallel Processing (P³)

Traditional RAID controller designs execute host commands sequentially. Each command initiates a sequence of hardware activities that are processed one after the other until the command is complete. If any of these activities are delayed, hardware components must wait. These delays compromise performance. DPT's P³ technology addresses this problem in five important areas:

- **Real-Time Control System** – P³ technology can process a virtually unlimited number of host commands in parallel. The SmartRAID V Real-Time Control System (RTCS) breaks each command down into sub-tasks that are then routed to one of the following hardware processors on the controller:
 - DMA processor
 - XOR processor
 - SCSI or Fibre Channel interface.



- **Hardware Request Schedulers** – Each hardware processor has an associated hardware request scheduler that coordinates its queued requests and manages the queue so that all subtasks are processed efficiently. The disk hardware request scheduler manages one request queue for each disk drive attached to the controller. To achieve maximum throughput from each drive, sorted disk queues are maintained by grouping requests when possible. This results in an increased number of read and write operations per drive.

- **Hardware RAID Processor** – DPT's P³ architecture is based on a new DPT-exclusive ASIC. This specially designed integrated circuit provides memory-to-memory and disk-to-memory data transfers that are fully concurrent with controller CPU execution. Depending on whether the PCI bus is 32-bit or 64-bit, data transfers occur at 132 or 264 MB/sec data rates, respectively. Independent DMA and XOR processors execute Scripts-based programs, enabling DMA and XOR tasks to be chained and executed without the intervention of the controller CPU. The hardware RAID processor also generates 128-bit parallel error-correcting code (ECC) for the controller cache memory. This powerful ECC is capable of correcting an error of up to 32 bits for each 512-byte block of data.
- **Intelligent Caching** – Because most popular operating systems are heavily cached, a SmartRAID V controller does not cache data read by the host. Instead, the controller cache is used for predictive and write-back caching and provides groups write data for efficient RAID 5 operation. For those environments where read caching on the controller will improve performance (particularly those without software disk caching), read caching can be enabled using Storage Manager.

SmartRAID V controllers also incorporate predictive caching algorithms. These algorithms are described in the Software and Hardware Caching section.

- **Virtual Cache** – In addition to normal caching functions, SmartRAID V controllers also maintain a large virtual cache used for pattern recognition and prediction. The total amount of cache space supported by a SmartRAID V controller is fixed. Some of this total cache space is used when physical memory modules are installed on the controller to be used for standard cache. The space not used for standard cache is available for virtual caching. SmartRAID V Century controllers support a total cache space of 128MB with up to 64MB of physical cache (depending on the number of memory modules installed). SmartRAID V Millennium controllers support a total cache space of 512MB with up to 256MB of physical cache. As an example, if 128MB of cache memory were installed on a SmartRAID V Millennium controller then $(512 - 128)\text{MB} = 384\text{MB}$ of virtual cache would be available.


Disk Caching

SmartRAID V Millennium controllers can be configured with up to 256MB of cache RAM. SmartRAID V Century controllers (equipped with an RA4050 RAID Accelerator) can be configured with up to 64MB of cache RAM. Adding more cache to a SmartRAID V controller can result in better RAID performance – especially for RAID 5.



Software and Hardware Caching

The SmartRAID V cache is designed to enhance performance in environments that are already software cached, such as UNIX, Novell and Windows NT. Although software caches are beneficial, hardware caching offers a significant advantage in larger, heavily loaded systems when combined with the software cache for the operating system.

The purpose of the operating system cache is to minimize disk reads. If data requested by an application is found in the operating system cache, a disk read is eliminated. A software cache can also improve application response time by immediately accepting data to be written to disk from application programs and postponing the actual writes until the disk is idle.



Although write caching through the operating system can benefit a lightly loaded system, it can result in performance degradation in large multi-user environments. The greater I/O demands in such systems reduce the periods of system idle time required to flush the operating system cache to disk. As disk activity becomes more intense, the periods of system idle time become shorter and less frequent. The operating system cache fills up with dirty sectors waiting to be written to disk, which take up space that could be used for more recently requested data. When cache RAM is added to a SmartRAID V controller, the operating system cache buffers must still be flushed. However, the controller receives and caches the flushed data in a fraction of the time required to actually write to a disk. The controller can also write the data back to disk in an *elevator-sorted* order without interrupting other system activity.





As an example, consider an operating system with 4MB of dirty data in its cache buffers. With a 4KB record size and an average disk I/O time of 11ms per record, this flush operation would take 11 seconds. However, with controller cache installed the entire flush operation from the software cache would take approximately 1 second instead of 11 seconds. The SmartRAID V controller can then flush its cache to disk in elevator-sorted order using its separate I/O bus, concurrently with other system activity.

Elevator Sorting

SmartRAID V cache flush operations occur much faster than from the operating system cache, because all data in the controller cache is kept in elevator sorted order. Data is written to disk in order of increasing block address, minimizing both physical disk seeks and rotational latency. This feature, called *Elevator Sorted Write-back*, eliminates much of the head thrashing commonly associated with disk-intensive operating systems like Novell NetWare, Windows NT and UNIX. By elevator sorting the sectors in cache, the average write access time to the drive may be reduced from the normal 11ms (seek + rotation) time, to between 1 and 5ms.

A good analogy is an elevator in a multistory building. Consider how much slower the elevator would be if it went to the requested floors in the same sequence that the buttons were pressed, instead of in floor number sequence! An additional benefit of elevator sorting is that multiple short disk write operations can often be coalesced within the controller cache into one large write operation, significantly reducing peripheral bus overhead.



Caching

SmartRAID V controllers can operate in write-back or write-through mode and also use a predictive caching algorithm to optimize disk I/O for the host system. This section describes the methods and rules used by SmartRAID V controllers to cache data for host I/O operations.

Write-back and Write-through Algorithm

Write-back is a method of postponing data to be written to a peripheral device, such as a disk drive, by temporarily saving the data in a cache. The data can then be written at a later time when the device would otherwise be idle. In Write-back mode, writes to disk are deferred until after command completion. This type of caching generally provides better I/O performance.

In addition, the data can be processed by techniques such as elevator sorting, to increase write operation performance.

In *Write-through* mode, all data is written immediately to disk for each write command before command complete status is returned to the host. The data may also be held in cache for subsequent read requests.

NOTE *When you first install a PM3755U2B controller with a BB4050 module, automatic low-battery write-through mode is disabled. Use the Battery Backup Configuration dialog in Storage Manager to set a threshold for when write-through mode should be used if the battery backup capability drops below a predetermined level.*

Flush Strategy

DPT SmartRAID V controllers continually flush all dirty cache pages to disk, with bursts occurring every second and increasing to 4 times per second as the number of dirty pages increases. The data is written to disk in elevator sorted order. The cache flushing routine establishes a flush rate that writes all the dirty pages to disk within three minutes. If there is no host activity, the cache flush will occur in less than three minutes.

Predictive Caching Algorithms

SmartRAID V predictive caching dramatically increases disk read performance in computer systems with highly fragmented file structures. The SmartRAID V pattern recognition algorithms are capable of predicting disk read requests from the host computer by recognizing patterns within seemingly random disk accesses. The SmartRAID V pattern recognition algorithms not only look for hidden sequential strings, but also analyze historical read/write patterns to determine when the host is accessing files that were previously paged out of host cache.

Virtual Cache

SmartRAID V controllers use virtual cache to track the patterns of data access for the most recently accessed disk data without actually caching that data. The collected information can then be used for more intelligent predictive algorithms. Additionally, the use of virtual cache enables the controller to track how many hits would have resulted from installing more controller or host cache. Virtual cache does not actually use RAM.

Read Ahead

Because disk data is often grouped as contiguous sectors on the disk, it is sometimes beneficial to continue to read sequential sectors into cache following a sector that has been requested by the computer. The SmartRAID V controller uses algorithms that analyze the pattern of disk access, looking for cases where sequential I/O may be occurring. If it is determined that a read command from the computer is part of a pattern of sequential reads, the controller reads additional sequential sectors into cache so that future read commands will result in cache hits.



Pre-Fetch

The SmartRAID V pre-fetch algorithm analyses disk access patterns to detect whether the host is reading data that it previously read. By using records stored in virtual cache, the caching algorithm determines the boundaries of the contiguous block of previously read data surrounding the current host read request, then reads that data block into cache.

Predictive Caching in Multi-user Systems

Disk read-ahead is effective in a multi-user environment when a large number of read-ahead sectors from many different areas of the disk are cached. This is because multi-user and networking operating systems contain highly fragmented files and time-slice I/O requests from many different users or tasks. Data that has been cached by a read-ahead operation may not be accessed until after other queued commands are processed and the same user or task has another chance to access the disk.

In addition, patterns of sequential I/O are harder to detect in large multi-user systems because they are typically interleaved with I/O from many users. This is why the read-ahead FIFO buffer on a drive (which can store only a limited number of data segments) provides acceptable performance in a single-user system, but must be augmented by the larger cache on the SmartRAID V controller in a system with multiple users.



Caching Host Reads

Because there is no advantage in using controller cache to duplicate the operating system cache, SmartRAID V controllers with cache only cache predictive and dirty data. Read cache misses are transferred directly from disk to host, bypassing the controller cache.

Optimizing Operating System Cache Size

When configuring a server, you should always consider the effect of the operating system cache on the disk subsystem. Although many disk read operations can be eliminated by the operating system cache, all writes must get through to the disk. In effect, the operating system cache is acting as a read filter for the disk subsystem.

As the operating system cache size is increased, more read hits are serviced from the operating system cache resulting in fewer reads issued to the disk subsystem. However, the number of disk writes stays relatively constant. At some point, adding more cache to the operating system will not result in significantly reduced disk I/O. At this point it is better to add more cache to the controller to improve write throughput.

NOTE *Most operating systems that have caching capability can automatically manage the size of their disk cache.*

Optimizing Controller Cache Size

The SmartRAID V cache is used for predictive reads, elevator sorted write-backs and as temporary storage during RAID 5 parity calculations. Increasing the size of the cache makes these features more efficient. More cache RAM allows the controller to hold and elevator-sort more records, resulting in closer spacing between consecutive write-back segments. This results in lower average access time for disk write operations and higher disk throughput.

The SmartRAID V cache can be expanded incrementally as needed to maintain optimum system performance. More cache is typically required for systems with many active users than for single-user systems. Systems with large data files also benefit from a larger cache. However, a system that has a large number of users who all access the same data, will require less cache than the previous examples.

NOTE *DPT recommends a minimum of 16MB of cache for SmartRAID V controllers.*

RAID

The basic idea of RAID (Redundant Array of Independent Disks) is to combine multiple inexpensive disk drives into an array of disk drives to obtain performance, capacity and reliability that exceeds that of a single large drive. The array of drives appears to the host computer as a single logical drive.


The Mean Time Between Failure (MTBF) of the array is equal to the MTBF of an individual drive, divided by the number of drives in the array. Because of this, the MTBF of a non-redundant array (RAID 0) is too low for mission-critical systems. However, disk arrays can be made fault-tolerant by redundantly storing information in various ways.

Five types of array architectures, RAID 1 through RAID 5, were originally defined, each provides disk fault-tolerance with different compromises in features and performance. In addition to these five redundant array architectures, it has become popular to refer to a non-redundant array of disk drives as a RAID 0 array.

Disk Striping

Fundamental to RAID technology is *striping*. This is a method of combining multiple drives into one logical storage unit. Striping partitions the storage space of each drive into stripes, which can be as small as one sector (512 bytes) or as large as several megabytes. These stripes are then interleaved in a rotating sequence, so that the combined space is composed alternately of stripes from each drive. The specific type of operating environment determines whether large or small stripes should be used.


Most operating systems today support concurrent disk I/O operations across multiple drives. However, in order to maximize throughput for the disk subsystem, the I/O load must be balanced across all the drives so that each drive can be kept busy as much as possible. In a multiple drive system without striping, the disk I/O load is never perfectly balanced. Some drives will contain data files that are frequently accessed and some drives will rarely be accessed.




By striping the drives in the array with stripes large enough so that each record falls entirely within one stripe, most records can be evenly distributed across all drives. This keeps all drives in the array busy during heavy load situations. This situation allows all drives to work concurrently on different I/O operations, and thus maximize the number of simultaneous I/O operations that can be performed by the array.

Definition of RAID Levels


RAID 0 is typically defined as a group of striped disk drives without parity or data redundancy. RAID 0 arrays can be configured with large stripes for multi-user environments or small stripes for single-user systems that access long sequential records. RAID 0 arrays deliver the best data storage efficiency and performance of any array type. The disadvantage is that if one drive in a RAID 0 array fails, the entire array fails.




RAID 1, also known as *disk mirroring*, is simply a pair of disk drives that store duplicate data but appear to the computer as a single drive. Although striping is not used within a single mirrored drive pair, multiple RAID 1 arrays can be striped together to create a single large array consisting of pairs of mirrored drives. All writes must go to both drives of a mirrored pair so that the information on the drives is kept identical. However, each individual drive can perform simultaneous, independent read operations. Mirroring thus doubles the read performance of a single non-mirrored drive and while the write performance is unchanged. RAID 1 delivers the best performance of any redundant array type. In addition, there is less performance degradation during drive failure than in RAID 5 arrays.




RAID 2 arrays sector-stripe data across groups of drives, with some drives assigned to store ECC information. Because all disk drives today embed ECC information within each sector, RAID 2 offers no significant advantages over other RAID architectures and is not supported by SmartRAID V.




RAID 3, as with RAID 2, sector-stripes data across groups of drives, but one drive in the group is dedicated to storing parity information. RAID 3 relies on the embedded ECC in each sector for error detection. In the case of drive failure, data recovery is accomplished by calculating the exclusive OR (XOR) of the information recorded on the remaining drives. Records typically span all drives, which optimizes the disk transfer rate. Because each I/O request accesses every drive in the array, RAID 3 arrays can satisfy only one I/O request at a time. RAID 3 delivers the best performance for single-user, single-tasking environments with long records. Synchronized-spindle drives are required for RAID 3 arrays in order to avoid performance degradation with short records. Because RAID 5 arrays with small stripes can yield similar performance to RAID 3 arrays, RAID 3 is not supported by SmartRAID V.



RAID 4 is identical to RAID 3 except that large stripes are used, so that records can be read from any individual drive in the array (except the parity drive). This allows read operations to be overlapped. However, since all write operations must update the parity drive, they cannot be overlapped. This architecture offers no significant advantages over other RAID levels and is not supported by SmartRAID V.



RAID 5, sometimes called a Rotating Parity Array, avoids the write bottleneck caused by the single dedicated parity drive of RAID 4. Under RAID 5 parity information is distributed across all the drives. Since there is no dedicated parity drive, all drives contain data and read operations can be overlapped on every drive in the array. Write operations will typically access one data drive and one parity drive. However, because different records store their parity on different drives, write operations can usually be overlapped.



In summary:

- RAID 0 is the fastest and most efficient array type but offers no fault-tolerance. RAID 0 requires a minimum of two drives.
- RAID 1 is the best choice for performance-critical, fault-tolerant environments. RAID 1 is the only choice for fault-tolerance if no more than two drives are used.
- RAID 2 is seldom used today since ECC is embedded in all hard drives. RAID 2 is not supported by SmartRAID V.
- RAID 3 can be used to speed up data transfer and provide fault-tolerance in single-user environments that access long sequential records. However, RAID 3 does not allow overlapping of multiple I/O operations and requires synchronized-spindle drives to avoid performance degradation with short records. Because RAID 5 with a small stripe size offers similar performance, RAID 3 is not supported by SmartRAID V.
- RAID 4 offers no advantages over RAID 5 and does not support multiple simultaneous write operations. RAID 4 is not supported by SmartRAID V.
- RAID 5 combines efficient, fault-tolerant data storage with good performance characteristics. However, write performance and performance during drive failure is slower than with RAID 1. Rebuild operations also require more time than with RAID 1 because parity information is also reconstructed. At least three drives are required for RAID 5 arrays.

Dual-Level RAID

In addition to the standard RAID levels, SmartRAID V controllers can combine multiple hardware RAID arrays into a single array group or *parity group*. In a dual-level RAID configuration, the controller firmware stripes two or more hardware arrays into a single array.

NOTE *The arrays being combined must both use the same RAID level.*

Dual-level RAID achieves a balance between the increased data availability inherent in RAID 1 and RAID 5 and the increased read performance inherent in disk striping (RAID 0). These arrays are sometimes referred to as RAID 0+1 or RAID 10 and RAID 0+5 or RAID 50.


Creating Data Redundancy

RAID 5 offers improved storage efficiency over RAID 1 because only the parity information is stored, rather than a complete redundant copy of all data. The result is that three or more drives can be combined into a RAID 5 array, with the storage capacity of only one drive dedicated to store the parity information. Therefore, RAID 5 arrays provide greater storage efficiency than RAID 1 arrays. However, this efficiency must be balanced against a corresponding loss in performance.

The parity data for each stripe of a RAID 5 array is the XOR of all the data in that stripe, across all the drives in the array. When the data in a stripe is changed, the parity information is also updated. There are two ways to accomplish this:

The first method is based on accessing all of the data in the modified stripe and regenerating parity from that data. For a write that changes all the data in a stripe, parity can be generated without having to read from the disk, because the data for the entire stripe will be in the cache. This is known as *full-stripe write*. If only some of the data in a stripe is to change, the missing data (the data the host does not write) must be read from the disks to create the new parity. This is known as *partial-stripe write*. The efficiency of this method for a particular write operation depends on the number of drives in the RAID 5 array and what portion of the complete stripe is written.

The second method of updating parity is to determine which data bits were changed by the write operation and then change only the corresponding parity bits. This is done by first reading the old data which is to be overwritten. This data is then XORed with the new data that is to be written. The result is a bit mask which has a 1 in the position of every bit which has changed. This bit mask is then XORed with the old parity information from the array. This results in the corresponding bits being changed in the parity information. The new updated parity is then written back to the array. This results in two reads, two writes and two XOR operations. This is known as *read-modify-write*.



The cost of storing parity, rather than redundant data as in RAID 1, is the extra time required for the write operations to regenerate the parity information. This additional time results in slower write performance for RAID 5 arrays over RAID 1. Because SmartRAID V controllers generate XOR in hardware, the negative effect of parity generation is primarily from the additional disk I/O required to read the missing information and write the new parity. SmartRAID V controllers can generate parity using either the full- or partial-stripe write algorithm or the read-modify-write algorithm. The parity update method chosen for any given write operation is determined by calculating the number of I/O operations needed for each type and choosing the one with the smallest result. To increase the number of full stripe writes, the cache is used to combine small write operations into larger blocks of data.

Handling I/O Errors

SmartRAID V controllers maintain two lists for each RAID 5 array: a Bad Parity List, and a Bad Data List. These lists contain the physical block number of any parity or data block that could not be successfully written during normal write, rebuild or dynamic array expansion operations. These lists alert the controller that the data or parity in these blocks is not valid. If the controller subsequently needs data from a listed block and cannot recreate the data from existing redundant data, it returns an error condition to the host.

Blocks are removed from the Bad Parity List or the Bad Data List if the controller successfully writes to them on a subsequent attempt.

Degraded Mode

When a drive fails in a RAID 0 array, the entire array fails. In a RAID 1 array, a failed drive reduces read performance by 50%, as data can only be read from the remaining drive. Write performance is increased slightly because only one drive is accessed. A RAID array operating with a failed drive is said to be in *degraded mode*.

RAID 5 arrays synthesize the requested data by reading and XORing the corresponding data stripes from the remaining drives in the array. For RAID 5, the magnitude of the performance impact in degraded mode depends on the number of drives in the array. An array with a large number of drives will experience more performance degradation than an array with small number of drives.

Rebuilding a Failed Hard Drive

A failed drive can be replaced in a RAID 1 or RAID 5 array by physically removing the drive and replacing it or by a designated Hot Spare. SmartRAID V controllers will rebuild the data for the failed drive onto the new drive or Hot Spare. This rebuild operation occurs online while normal host reads and writes are being processed by the array.

RAID 1 arrays are rebuilt relatively quickly, because the data is simply copied from the duplicate (mirrored) drive to the replacement drive. For RAID 5 arrays, the data for the replacement drive must be synthesized by reading and XORing the corresponding stripes from the remaining drives in the array. RAID 5 arrays that contain a large number of drives will require more time for a rebuild than a small array.

SmartRAID V Architecture

SmartRAID V controllers can process commands from the operating system using two different protocols:

- ASPI (Advanced SCSI Programming Interface), which is compatible with tape and CD-ROM application software.
- I₂O Messaging, which uses the full performance capability and function of the PCI bus.

ASPI Protocol

SmartRAID V controllers can communicate with any ASPI protocol device under Windows NT and Windows 95/98.

ASPI support under MS-DOS is limited to CD-ROM drives only. MS-DOS support is provided by the I2ODDL.SYS and DPTCDROM.SYS driver files.

I₂O Messaging Protocol

Intelligent I/O architecture (I₂O) is a device driver architecture that provides a standardized interface between I/O devices and operating systems. I₂O supports PCI bus mastering, overlapped I/O processing, command queuing, scatter/gather memory access and auto-request sense.

The I₂O architecture uses a split-driver model, where an I/O driver consists of two parts:

An Operating system Services Module (OSM) that translates operating system specific I/O calls into a neutral message-based format.

A Hardware Device Module (HDM) that accepts the OSM messages and processes them on a specific controller and devices. (The SmartRAID V controller functions as an HDM.)

This messaging system enables the modules to communicate without specific knowledge of the underlying operating system or I/O bus.

Command Processing

The I₂O messaging protocol is based on the existence of a messaging FIFO (first-in, first-out) queue and a reply FIFO queue. Each queue consists of a list of message frames. The messaging queue contains requests for I/O processing that are read by the HDM. The reply queue is where completion statuses are posted by the controller and read by the OSM. DPT SmartRAID V controllers use I₂O messaging to process a command from the host computer as follows:

1. The OSM acquires a frame in controller RAM from the messaging queue on the controller, fills it out and returns it to the messaging queue to initiate the I/O command.
2. The controller HDM firmware processes the frame.
3. The controller completes the I/O command; transferring data if necessary.
4. The controller acquires a frame from the reply queue, fills it out and returns it to the queue and issues an interrupt.
5. On interrupt, the OSM retrieves the completed reply frame from the reply queue and uses the information in the frame to complete the I/O operation. It then returns the frame to the reply queue.

Command Overlapping

Command overlapping is a technique that lets a controller receive and respond to multiple host requests before any particular request is completed. SmartRAID V controllers can receive additional commands before the previous command has finished executing. By allowing multiple outstanding commands, SmartRAID V controllers can optimize performance by overlapping commands for multiple devices, thereby keeping all devices busy as much as possible. The Decade and Century family of controllers can queue up to 2000 commands. The Millennium family of controllers can queue up to 8000 commands.

Command Queuing

I₂O messaging allows the controller to queue multiple commands from the host and execute them out of order for greater efficiency. When a command is complete, the controller transfers status information to host memory. This status message contains information indicating which command was just completed and enables commands to be executed in a different order than they were issued by the host. This allows commands to be queued and rearranged so that they are executed in a more efficient order for the particular peripheral configuration.

SmartRAID V controllers also support Tagged Command Queuing on the peripheral bus. This feature allows the controller to transfer multiple commands to a single device if that device can accept queued commands.

Auto Request Sense

When a SCSI error occurs, the controller automatically issues a Request Sense command and returns the data to the host in the message reply frame. Data returned by this command is stored in the controller's Event Log. You can use Storage Manager to view the Event Log.

Byte/Word Alignment

Data to be read or written by the SmartRAID V controllers need not be aligned to word or long-word boundaries in system memory. If the data starts on an odd memory address, the necessary bus control signals will be generated by the SmartRAID V to access 8-bit, 16-bit, 24-bit and 32-bit data as required. Data blocks of any byte length are correctly handled by SmartRAID V.

Scatter/Gather

SmartRAID V controllers support Scatter/Gather. This is a method of providing multiple memory addresses for data transfer in one host command. This ability greatly increases performance in environments such as UNIX, Novell NetWare and Windows NT. Scatter/Gather is necessary because when using virtual memory addressing schemes, system memory that may appear contiguous to the user can actually be fragmented into many widely scattered physical address locations. Because of this, when accessing a large amount of contiguous data from a peripheral device, it is often necessary to split the transfer into many different locations in system memory.

PCI Data Transfer and Bus Mastering

The Peripheral Component Interconnect (PCI) bus provides a means to interconnect peripheral chips and expansion cards to the computer backplane. PCI is optimized for peripheral device controllers that transfer data in blocks. PCI allows for data transfer rates of 132MB/sec (32-bit PCI) and 264MB/sec (64-bit PCI). If a Plug-and-Play BIOS is available, automatic expansion card configuration is also available.

All SmartRAID V controllers use a PCI bus for internal communication as well as their interface to the host computer. SmartRAID V Century controllers are configured by the host BIOS as multifunction PCI devices. SmartRAID V Millennium controllers are seen by the host computer as standard PCI-to-PCI bridge devices. Millennium controllers are available in both 32-bit and 64-bit PCI versions.

The PCI bus uses a 33MHz clock rate as opposed to the 8.33MHz clock used by ISA and EISA buses. To maintain data integrity at the higher clock rate, the PCI bus is limited to four card slots and six devices integral to the motherboard. However, motherboard designs can include multiple PCI buses that are interconnected through bridge devices.

PCI supports two modes of data transfer: Bus mastering and PIO. Third party DMA is not supported by the PCI architecture.

Each PCI device contains configuration registers that allow the system to be configured for maximized throughput. Parameters such as Latency Timer, Cache Line Size, Minimum Bus Grant, Maximum Latency, as well as configurable address and IRQs, can be read or written by the PCI system BIOS. SmartRAID V controllers support the full range of required and optional features described by revision 2.1 of the PCI specification.

SmartRAID V controllers are also fully compliant with revision 2.1 of the PCI specification for bus drivers and receivers. These transceivers are unique in their ability to vary the drive current in order to minimize signal reflections.

All mandatory and optional memory read/write commands are supported by SmartRAID V controllers. Mandatory commands include Memory Read and Memory Write, which are used by all PCI bus-mastering devices. Optional commands include Memory Read Line, Memory Read Multiple and Memory Write and Invalidate. These commands maximize performance in PCI systems with intelligent bridges that perform CPU cache line optimization.

On-Board Microprocessor

SmartRAID V controllers use embedded processors to maximize their performance when installed in fully loaded servers. The onboard microprocessor performs high-level processing of commands from the host and controls the sequencing of command execution on the controller. A fast microprocessor enables the controller to process more I/O commands per second which is especially important when caching and RAID are used.

SmartRAID V Millennium controllers use a high-performance RISC processor. SmartRAID V Decade and Century controllers use an Intel i960® embedded I/O processor.

SCSI Interface

The Small Computer Systems Interface (SCSI) is a standard parallel interface designed to communicate with intelligent peripheral devices. SmartRAID V controllers conform to the ANSI SCSI specification defined in ANSI document number X3.131-1986 and subsequent standards defined in ANSI X3.131-1994 (SCSI-2) and various SCSI-3 specification documents.

SCSI Device IDs

The original SCSI specification allowed up to eight SCSI devices, including the controller, to be connected to a single 8-bit SCSI bus. Wide (16-bit) SCSI busses support up to fifteen devices and one controller per bus. All SCSI devices, including the controller, must be assigned a unique numeric identifier. These SCSI IDs can be any number from 0 – 7 or, for Wide SCSI devices, 0 – 15. The SmartRAID V controller ID is set by default to ID 7.

In 8-bit SCSI systems, the device with ID 7 has the highest priority and ID 0 has the lowest priority when arbitrating for use of the SCSI bus. In a Wide SCSI system, IDs have the following priority (highest to lowest):

7, 6, 5, 4, 3, 2, 1, 0, 15, 14, 13, 12, 11, 10, 9, 8

The IDs 8 – 15 always have a lower priority during arbitration than 8-bit devices, this allows 8-bit devices which do not recognize IDs 8 – 15 to coexist on a SCSI bus with Wide SCSI devices which may be assigned those IDs. However, when controlling 8-bit devices, a Wide SCSI controller cannot be assigned an ID greater than 7 because 8-bit devices would not be able to recognize the controller.

Logical Unit Numbers (LUN)

A SCSI device may contain up to eight sub-devices or Logical Units, assigned Logical Unit Numbers (LUN) 0 – 7. SmartRAID V controllers support multiple LUNs. However, most devices other than bridge controllers consist of only one LUN and are accessed as LUN 0 by SmartRAID V controllers.

Bridge Controllers

Bridge controllers are single devices that can, in turn, control multiple peripheral devices. These devices may be disk drives configured as a remote RAID subsystem. Each of the peripheral devices attached to the bridge controller is assigned a Logical Unit Number. A SmartRAID V controller supports 250 physical devices. These devices can be individual SCSI IDs for actual physical devices or LUNs within an ID (such as on a bridge controller).

Commands and Messages

All SCSI commands are supported by SmartRAID V. SmartRAID V controllers pass through any SCSI command from the host computer to the SCSI peripheral device.

SmartRAID V also supports one byte, two byte, and extended messages, such as Initiator Detected Error, Parity Error, Simple Queue, Wide Negotiation and Synchronous Negotiation. The SCSI message protocol is normally handled automatically by SmartRAID V controllers without requiring intervention by the host computer. This allows much faster SCSI protocol handling and reduces the load on the host CPU, freeing it for other tasks.

Disconnect/Reconnect

SmartRAID V provides full support for Disconnect and Reconnect commands by SCSI peripheral devices. All Disconnect/Reconnect commands are handled automatically by SmartRAID V controllers, without host intervention.

Disconnection allows a SCSI device or controller to temporarily release control of the SCSI bus, during periods of non-activity while a SCSI command is in process, so that another SCSI device can share the bus.

Transfer Padding and Residue Reporting

In unusual cases, a SCSI peripheral device might read or write more data than was requested by the host. If this occurs during a write operation, SmartRAID V controllers automatically *transfer pad* data by adding additional bytes to the end of the data. If this occurs during a read operation, the controller automatically strips off additional bytes of data read from the device. This prevents the data from overwriting valid data in host memory.

It is also possible for a SCSI peripheral device to read or write less data than was requested by the host. If this occurs, SmartRAID V controllers will report the actual number of bytes transferred as less than the requested number of bytes.

Single-Ended and Differential SCSI

The SCSI electrical specification has two transceiver specifications:

1. Single-Ended TTL transceivers which allow:

Asynchronous data transfer at a maximum cable length of 6 meters (19.6 feet). No maximum transfer rate is specified but typical rates range from 1.5MHz to 3MHz.

Synchronous data transfer up to 5MHz at a maximum cable length of 6 meters.

10MHz (Fast) synchronous data transfer at a maximum cable length of 3 meters (9.8 feet).

20MHz (Ultra) synchronous data transfer at a maximum cable length of 3 meters with up to 4 devices and 1.5 meters (4.9 feet) with up to eight devices.

2. Differential SCSI: *Differential* electrical signal protocol transmits information through a current loop rather than by changes in voltage, thereby reducing susceptibility to electrical interference. Differential SCSI has two variants:

High Voltage Differential (HVD) SCSI uses RS-485 transceivers that allow up to 20MHz data transfer with a maximum cable length of 25 meters (82 feet).

Ultra2 SCSI Low Voltage Differential (LVD) transmission. This transmission method has the benefits of differential SCSI without the need for external, high-voltage bus transceivers. Ultra2 SCSI allows synchronous transfers up to 40MHz with a maximum cable length of 12 meters. SmartRAID V products support multimode Ultra2 SCSI, which includes LVD operation.

Multi-Mode SCSI

To ensure backward compatibility with existing SCSI devices, all SmartRAID V Ultra2 controllers support both LVD and single-ended devices. This is referred to as *multimode SCSI*. Both types of devices can be attached to the same SCSI bus with the following restrictions:

- If all devices on the bus are Ultra2, the bus operates in LVD mode and runs at the maximum Ultra2 speed (40 MHz).
- If the devices are a mix of 40 MHz Ultra2 and 20 MHz Ultra single-ended, the bus operates in single-ended mode and runs at 20MHz.



Do not use both LVD and High Voltage Differential devices on the same SCSI bus.

Do not attach High Voltage Differential devices to an Ultra2 bus.

Wide SCSI

The SCSI-2 specification defines 8-bit, 16-bit and 32-bit bus widths. All SmartRAID V controllers use a 16-bit bus and support both 8-bit and 16-bit SCSI devices.

SCSI Transfer Rate

SmartRAID V controllers are capable of handling a combination of SCSI devices with different transfer speeds, and both synchronous and asynchronous protocols on the same SCSI bus. Using the SCSI message protocol, SmartRAID V controllers automatically negotiate with each device during the power-on sequence to determine the fastest transfer speed and protocol for that device.

SmartRAID V controllers can also detect the presence of an external SCSI cable and automatically lower the maximum SCSI bus transfer rate when an external cable is present. (Both the external and internal cable transfer rates are lowered.) Because some external SCSI cabling methods are not capable of handling the maximum possible transfer rates without causing data errors, this feature protects you from data integrity problems.

The original SCSI specification synchronous transfer rates of up to 5MHz. The SCSI-2 specification increased the maximum synchronous rate to 10MHz. Devices that support the faster 10MHz rate are called Fast SCSI devices. The SCSI-3 specification defines transfer rates up to 20MHz (Fast-20/Ultra SCSI).

The SCSI-3 SPI-2 specification defines synchronous data transmission speeds of up to 40MHz. The 40MHz transfer speed provides data transfer rates up to 40MB/sec on an 8-bit bus and 80MB/sec on a 16-bit SCSI bus. Devices that support these rates are called Ultra2 SCSI devices. Ultra2 SCSI is also known as Fast-40 SCSI. A device must use Low Voltage Differential signaling to achieve the maximum Ultra2 speed.

Fibre Channel Arbitrated Loop (FC-AL) controllers transfer data at a maximum speed of 1GHz per loop (100 MB/sec).

Cabling Single-Ended SCSI

The SCSI cable is an electrical transmission line that has a characteristic impedance. The value of the impedance depends on the type and configuration of the cable. Differences in this impedance can cause signal reflections. These impedance variations can be the result of extra capacitance internal to SCSI devices, connectors, incorrect termination, mixing of different cable types, cable stubs, and so on.

A properly configured Single-Ended SCSI bus can reliably transfer data at up to 20MHz. However, the following guidelines should be used to ensure success:

Use as short a cable length as possible. For 10MHz data transfers the total SCSI bus length should not exceed 3 meters (9.8 feet). For 20MHz data transfers, total SCSI bus length should not exceed 3 meters with up to 4 devices on the bus, or 1.5 meters (4.9 feet) with between 5 and 8 devices on the bus.

NOTE

When an external SCSI storage cabinet is used, the cabinet's internal SCSI backplane will add additional length to the bus.

Avoid stub clustering. Avoid spacing SCSI devices on the cable closer than 0.3 meters (11.8 in). When devices are clustered closely together on the SCSI cable, their capacitance adds together to create an impedance discontinuity and thus reflections. SCSI devices should be spaced as evenly as possible.

Cable stub length should not exceed 10 cm (3.9 in). Some SCSI devices may create stubs internal to the device which exceed this value. This can result in excessive capacitive loading and signal reflections. This factor is controlled by the SCSI device manufacturer. The SCSI cabling itself should not include stubs.

Beware of capacitance changes. As devices are added to a SCSI bus, capacitance is introduced to each signal from the connectors, receivers, and circuit board traces. The SCSI-3 working specification limits this capacitance to 25pF because added capacitance lowers the impedance of the cable near the device and adds delay. Look for input filters that may be attached to the SCSI front-end of the device's printed circuit board. These filters add capacitance.

Avoid unnecessary connector converters. They cause impedance discontinuity and signal reflections.

Route the cable with care. Avoid rolling the cable up on itself, running the cable alongside of metal for long lengths or routing the cable past noise generators (such as power supplies). Placing the cable near ground planes created by grounded metal components also reduces its impedance. The SCSI-3 draft specification suggests that to minimize discontinuity due to local impedance variation, a flat cable should be spaced at least 1.27 mm (0.050 in.) from other cables, any other conductor, or the cable itself when the cable is folded.

Follow the SCSI specification for cable impedance. Cable impedance for 10MHz SCSI systems should be limited to 84 ± 12 Ohms (Ω). Cable impedance for 20MHz SCSI systems should be limited to $90 \pm 12\Omega$ for REQ and ACK signals and $90 \pm 10\Omega$ for all other signals.

Avoid mixing cable types. Select either flat or round, shielded or unshielded. Typically mixing cables mixes impedance. Cable impedance mismatch is a common problem that results in signal reflections. Internal cables are normally unshielded flat ribbon cables, while external cables should be shielded. Where they offer easier routing, size advantages, and better air flow, round cables can also be used internally. This may be beneficial if it allows for better impedance matching to the external cable.

When round cable is used, select a cable that uses an optimal placement of signals within the cable. Ribbon cable has good crosstalk rejection due to the GND-Signal-GND layout. With standard 25-pair round cable, pairs are arranged in three layers. The closer a pair is to the cable center, the higher the impedance. Using centrally located high impedance pairs for speed-critical signals such as REQ and ACK is a good choice. Locating the data pairs in the outermost layer of the cable minimizes crosstalk between REQ, ACK and the data lines. The middle layer might contain status lines such as C/D, I/O, MSG, ATN, and so on. Make sure that the lowest impedance wire in the cable is used for TERMPWR to minimize transmission line effects on this voltage supply line. Some SCSI cables have a low-impedance conductor specifically for this purpose.

Cabling Ultra2 (LVD) SCSI

When the total length of a SCSI cable must exceed the maximum length for single-ended buses, DPT recommends the use of an Ultra2 Low Voltage Differential SCSI interface.

The following guidelines will help ensure reliability when configuring Ultra2 SCSI systems:

- **Use twisted-pair cable.** Twisted-pair cable (either twisted-flat or discrete wire twisted-pairs) provides greater signal integrity over longer distances because noise coupled into a twisted-pair generally appears equally on both wires. Because the differential receivers respond to differences between the conductors of the twisted-pair, the coupled common-mode noise is rejected.

Flat non-twisted ribbon cable can cause two problems. First, noise introduced into parallel conductors tends not to be common mode. Second, while the single-ended conductor arrangement interleaves ground wires between signal wires, there are not enough conductors to interleave grounds between each differential signal pair. These factors lead to increased crosstalk between adjacent conductors on a flat non-twisted ribbon cable.

- The maximum cable length for an LVD bus is 12 meters (39.3 feet).
- Because Ultra2 cables are sensitive to cable capacitance, the following table of minimum spacing between devices should be followed:

Cable Capacitance	Minimum Spacing
40 pF/m	36 cm
65 pF/m	22 cm
90 pF/m	16 cm
115 pF/m	13 cm
140 pF/m	10 cm

- Stub lengths should not exceed 0.1 meters (3.9 in.). The difference in stub length should be less than 1.27 cm (0.05 in.) for the REQ, ACK, DATA and PARITY signals.
- Terminators should be installed only at each physical end of the bus, either on the last device attached or the unused connector at the end of the cable. Ultra2 buses must be terminated with LVD terminators. DPT cables are supplied with an LVD terminator installed at the end of the cable.

SCSI Termination

SCSI termination for SmartRAID V controllers is controlled through Storage Manager or SMOR. Refer to Chapter 3, “Configuration and Installation” for information about setting SCSI termination for SmartRAID V controllers.

SmartRAID V controllers contain onboard active SCSI terminators for maximum reliability with Fast and Ultra SCSI devices. Active termination for a single-ended bus uses one 110Ω resistor per signal, pulled up to a locally supplied voltage that is regulated at 2.85V. Active termination for Ultra2 SCSI uses a differential impedance of 100Ω with a 1.25V bias.

Features of active termination include:

- Better immunity to fluctuations in TERMPWR.
- Closer match to the characteristic impedance of the cable minimizes reflections.
- Increased signal-to-noise ratio.

Passive termination employs one 220Ω pull-up and one 330Ω pull-down resistor per signal. Active terminators should be used whenever possible. However, active and passive termination can be mixed on a SCSI bus and will result in better reliability than using only passive termination.

IMPORTANT

Do not use passive termination for Fast-20 or Ultra SCSI in a single-ended bus configuration.

TERMPWR

SCSI terminators need power to operate. SmartRAID V controllers always supply power for their own onboard SCSI terminators and, by default, supply termination power for other devices using the TERMPWR line on the SCSI cable. Most SCSI devices allow the way in which TERMPWR is supplied to their onboard SCSI terminators to be selected using jumpers on the device. Devices that supply SCSI bus termination should be configured to supply their own isolated TERMPWR. This prevents loss of receiver noise margin due to a DC voltage drop across the cable.

TERMPWR should remain enabled if there is a possibility of power-loss on an external SCSI device that supplies its own TERMPWR.

If all devices supplying termination for the SCSI cable are also capable of supplying their own termination power, then TERMPWR supplied to the SCSI cable from SmartRAID V controllers can be disabled using SMOR or Storage Manager.

SmartRAID V controllers supply termination power onto the SCSI cable through a circuit breaker which protects the controller from a short-to-ground on the TERMPWR line. Some SCSI devices use a fuse for protection; this can require the replacement of the part if a short occurs or if the SCSI cable is inserted incorrectly.

The ANSI XT3T9.3 SCSI-3 Parallel Interface working group recommends that all TERMPWR lines be decoupled at each terminator to minimize TERMPWR glitch coupling. The minimum recommended values are a 2.2 μ F solid tantalum capacitor along with .01 μ F ceramic capacitor in parallel to suppress high frequency, low voltage noise. These capacitors supply the high frequency, low impedance path to ground necessary to provide a clean supply voltage.

Fibre Channel Arbitrated Loop (FC-AL)

Fibre Channel is an industry standard set of protocols for information transfer using a serial bus. Fibre Channel provides for reliable high-speed transfer of large amounts of information over long cable lengths. SmartRAID V Fibre Channel controllers support transfer rates of 1GHz among up to 126 devices over a maximum of 30 meters (98 feet) of copper or 10 km (6.2 miles) of optical cable.

DPT Fibre Channel controllers use Arbitrated Loop (FC-AL) topology, where all devices and the controller are connected in a serial (loop) fashion. FC-AL provides a cost-effective method of implementing a Fibre Channel storage subsystem, while maintaining high bandwidth and reliability characteristics.

Redundancy can be added to a Fibre Channel storage subsystem by using a *dual loop* configuration. By forming two arbitrated loops on a dual channel controller and connecting dual-port devices to both loops, fault tolerance is provided for cable failure. In normal operation, the controller will use both loops to communicate with the devices, thus providing an effective controller bandwidth of 200MB/sec.

DPT SmartRAID V Fibre Channel controllers can have a one or two HSSDC (copper) connectors. If you want to use a cable length greater than 30 meters, a Media Interface Adapter (MIA) can be used to convert electrical signals to optical signals for use with fiber optic cable. Optical cable has complete immunity to electrical noise and the ability to use significantly longer cable lengths without signal loss.

DPT I₂O BIOS

SmartRAID V controllers are shipped with the DPT I₂O BIOS loaded on an EEPROM. This BIOS intercepts and processes Int13 requests with an embedded DOS driver.

The host system Plug-and-Play BIOS can automatically disable or change the address of the I₂O BIOS ROM. In systems with multiple DPT controllers, the first DPT I₂O controller found during boot loads its BIOS and installs all of the DPT I₂O hardware on the system. DPT I₂O controllers found subsequently automatically detect the presence of the first controller and disable their BIOS code. If another manufacturer's BIOS occupies address C8000H, then an alternate BIOS ROM address will be selected for either the DPT controller or the other card. The disk controller that has the lowest BIOS ROM address (typically, the lowest PCI slot) will become the booting controller. Therefore, in a system with multiple controllers, ensure that the DPT ROM occupies the lowest address if you want the DPT controller to be the booting controller.

If the DPT I₂O BIOS is correctly configured, the following message appears during boot-up, followed by a list of attached devices:



```
DPT I2O SCSI BIOS V001.xx (yyyy/mm/dd)
Distributed Processing Technology
©Copyright 1996-99
All Rights Reserved
Hit <CTRL+D> for DPT setup
```

APPENDIX A:

Assembly Drawings

This chapter contains outline drawings of DPT's SmartRAID V products with jumpers and connectors labeled for easy reference.

See the SmartRAID V Controller LEDs section in Chapter 2 for specific information about the LED indicators on your controller or module.

Millennium Controllers

PM3755F
PM3755U2B
PM3754U2

Decade/Century Controllers

PM1554U2
PM2554U2
PM2654U2

Bus Expansion Modules

SX4054U2-1
SX4054U2-2
SX4055U2-1
SX4055U2-2
SX4055F


RAID Accelerator

RA4050

Battery Module


BB4050

PM3755F




P4	Pins 1-2 NVRAM Clear Pins 3-4 Misc (Reserved, do not use)
P6	Disk Activity LED Connector
P9	Pins 1-2 Load Pins 3-4 Run
J7	32-bit Bus Expansion Module Connector
J8	64-bit Bus Expansion Module Connector
J9	External Fibre Channel HSSDC Connector (Bus 0)
1...8, IRQ	Adapter Activity LEDs
ECC EN	ECC Enabled LED (Green)
ECC ERR	ECC Error LED (Red)

PM3755U2B




- P4 Pins 1-2 NVRAM Clear
Pins 3-4 Misc (Reserved, do not use)
- P6 Disk Activity LED Connector
- P9 Pins 1-2 Load
Pins 3-4 Run
- J7 32-bit Bus Expansion Module Connector
- J8 64-bit Bus Expansion Module Connector
- J10 Internal Wide Ultra2 SCSI Connector (Bus 0)
- J11 External Wide Ultra2 SCSI Connector (Bus 0)
- 1...8, IRQ Adapter Activity LEDs
- ECC EN ECC Enabled LED (Green)
- ECC ERR ECC Error LED (Red)

PM3754U2




P4	Pins 1-2 NVRAM Clear Pins 3-4 Misc (Reserved, do not use)
P6	Disk Activity LED Connector
P9	Pins 1-2 Load Pins 3-4 Run
J4	Bus Expansion Module Connector
J10	Internal Wide Ultra2 SCSI Connector (Bus 0)
J11	External Wide Ultra2 SCSI Connector (Bus 0)
1...8+IRQ	Adapter Activity LEDs
ECC EN	ECC Enabled LED (Green)
ECC ERR	ECC Error LED (Red)

PM1554U2, PM2554U2 and PM2654U2




- P4 Pins 1-2 NVRAM Clear
Pins 3-4 Misc (Reserved, do not use)
- P6 Disk Activity LED Connector
- P9 Pins 1-2 Retry (Reserved, do not use)
Pins 3-4 Reset (Reserved, do not use)
- J7 Bus Expansion Module Connector
- J10 Internal Ultra2 Wide SCSI Connector (Bus 0)
- J11 External Ultra2 Wide SCSI Connector (Bus 0)
- 1...8, IRQ Adapter Activity LEDs

SX4054U2-1 Bus Expansion Module




- J2 Internal Ultra2 Wide SCSI Connector (Bus 1)
- J3 External Ultra2 Wide SCSI Connector (Bus 1)
- P5 Mating Connector for SmartRAID V Controller

SX4054U2-2 Bus Expansion Module




- J1 External Ultra2 Wide SCSI Connector (Bus 2)
- J2 Internal Ultra2 Wide SCSI Connector (Bus 1)
- J3 External Ultra2 Wide SCSI Connector (Bus 1)
- J4 Internal Ultra2 Wide SCSI Connector (Bus 2)
- P5 Mating Connector for SmartRAID V Controller

SX4055U2-1 Bus Expansion Module




- J2 Internal Wide Ultra2 SCSI Connector (Bus 1)
- J3 External Wide Ultra2 SCSI Connector (Bus 1)
- P3 64-bit SmartRAID V Adapter Connector
- P5 Mating Connector for SmartRAID V Controller

SX4055U2-2 Bus Expansion Module




- J1 External Wide Ultra2 SCSI Connector (Bus 2)
- J2 Internal Wide Ultra2 SCSI Connector (Bus 1)
- J3 External Wide Ultra2 SCSI Connector (Bus 1)
- J4 Internal Wide Ultra2 SCSI Connector (Bus 2)
- P3 64-bit SmartRAID V Adapter Connector
- P5 Mating Connector for SmartRAID V Controller

SX4055F FC-AL Bus Expansion Module




- P2 Fibre Channel (FC-AL) Connector (Bus 1)
- P3 64-bit SmartRAID V Adapter Connector
- P5 Mating Connector for SmartRAID V Controller

RA4050 RAID Accelerator



- J1 Docking Connector
- ECC EN ECC Enabled LED (Green)
- ECC ERR ECC Error LED (Red)

BB4050 Battery Module



Board shown without Stability Bracket

J1	Battery Cable Connector
P12	Connector for SmartRAID V PM3755U2B
TRICKLE	LED indicator for trickle charge activity
CHARGE	LED indicator for charging/recharging cycle



Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer. Dispose of used batteries according to the manufacturer's instructions.

APPENDIX B:

Troubleshooting

This chapter provides answers to many commonly asked questions. If a situation occurs that is not covered in this chapter, or if the recommendations here do not correct the problem, contact DPT Technical Support. We are always ready to assist you.

DPT Technical Support

Phone: 407-830-5522
(Press 6 and follow the prompts.)

Fax: 407-830-4793

Internet: <http://www.dpt.com>

Product information and the latest versions of DPT drivers and utilities can be obtained at no charge from the DPT FTP site (<ftp.dpt.com>) or from the Technical Support section of our World Wide Web site 24 hours a day.

DPT also offers *priority Technical Support* as a fee-based option. If you choose one of these options, your call is given priority over all other support calls:

900-555-4378
at the rate of \$1.35 per minute

407-830-5522
Press 6 and select the Priority Technical Support option. The rate is \$30 for the first hour and \$1.00 per minute after the first hour.

Problem: When the DPT I₂O BIOS displays the peripheral devices at system boot, a device does not appear.

Solution: The following conditions can cause this to occur:

The device ID might be set to the same ID as the DPT controller (ID 7). Ensure that all devices have a unique ID. Fibre Channel devices automatically configure a unique ID for each device on the bus.

The device might not be powered on.

The device is not connected to the SCSI cable or the connection is loose.

Problem: In addition to the SmartRAID V controller, the system contains another manufacturer's SCSI controller and hangs during boot.

Solution: The other controller does not correctly implement EBDA usage rules. Use SMOR to try a different setting for the EBDA Relocation parameter or rearrange the controller slot assignments.

If your system BIOS supports configuring the boot order, you can also try changing those settings.

Problem: The system contains another manufacturer's SCSI controller in addition to the SmartRAID V controller. During boot, messages from each controller's BIOS appear, but one controller cannot communicate with its attached drives.

Solution: The other controller does not properly implement EBDA usage rules. Use SMOR to try a different setting for the EBDA Relocation parameter or rearrange the controller slot assignments.

If your system BIOS supports configuring the boot order, you can also try changing those settings.

Problem: Windows NT displays a blue screen error message that references the system video controller.

Solution: The video controller does not properly implement extended BIOS data area (EBDA) usage rules. Use SMOR to enable the EBDA Relocation option.

Problem: The controller does not respond and the IRQ LED (and possibly other LEDs) remains lit. See Appendix A for the location of the LEDs on your controller.

Solution: The IRQ LED indicates that the controller IRQ assignment is pending. This usually indicates an IRQ conflict with another card. Ensure that each card is set to a unique IRQ.

Problem: The controller does not respond and one of the following LED patterns occurs at power-up:

LEDs 6 and 7 alternating with LEDs 5 and 8

LEDs 5 and 6 alternating with LEDs 7 and 8

LEDs 5 and 7 alternating with LEDs 6 and 8

Solution: These patterns indicate that the DPT controller is not being configured by the motherboard BIOS. SmartRAID V Century controllers require a motherboard BIOS that supports multifunction devices, where one of the devices is a PCI-PCI bridge. All SmartRAID V controllers require a BIOS that supports large memory-mapped address ranges.

Refer to the SmartRAID V READ.ME file on the DPT diskette for information about motherboard compatibility and a list of motherboards that DPT has tested with SmartRAID V products.

Problem: The controller does not respond and one of the following patterns of LEDs flash once per second at power-up:

PATTERN	MEANING
7, 6, 5, 2, 1	None
7, 6, 5, 3, 1	High
7, 6, 5, 3, 2	Mismatch
7, 6, 5, 3, 2, 1	Invalid

Solution: These patterns indicate that there is a problem with the memory modules on the controller.

None: Either no memory modules were detected on the controller, or there is no module in socket 1. Socket 1 must always have a 16MB or 64MB 60ns EDO memory module installed.

High: Too much memory has been detected on a Decade or Century controller. Remove memory so that the total is less than or equal to 64MB.

Mismatch: Memory modules of mixed sizes have been detected or a SIMM slot was skipped. All installed modules must be the same size and must be filled sequentially from socket 1 to socket 4.

Invalid: A memory module of a size other than 16MB or 64MB has been detected. Use only 16MB or 64MB memory modules.

NOTE: *Do not install non-EDO SIMMs or DIMMs. This will cause data corruption.*

Problem: The controller does not respond and various LEDs in the 1–4 range flash once per second.

Solution: This pattern indicates an internal microprocessor trap occurred in the controller. Remove all attached devices, cables and option modules and retry. If the trap error disappears, reconnect the cables and devices, one device at a time, until the faulty device, cable or module is isolated. If the error persists, contact DPT Technical Support.

Problem: Pressing **Ctrl+D** to access SMOR does not work or the information displayed is garbled.

Solution: If this happens, use the following procedure to restore the parameters in the NVRAM to their default settings:

1. Turn off power to the system.
2. Place a shorting jumper across pins 1 and 2 of P4 on the controller.
3. Power on the system and wait until the LEDs 3, 5, 7 and 8 on the controller begin flashing.
4. Turn off power to the system and remove the jumper.

The controller can now be reconfigured using SMOR or Storage Manager.

Problem: During the installation of SCO UNIX with a DPT PCI controller the following message appears:

```
Warning: SCSI controller cannot install interrupts  
vecno=xx, type = 2, IPL=5  
Vector xx is private.
```

Solution: SCO UNIX reserves certain interrupts for its internal use. This error indicates that the DPT controller has been assigned one of these reserved interrupts. Assign a different interrupt to the controller and start the installation again.

Problem: You want the system to boot from a drive that is not attached to a DPT controller. However, during boot, the DPT I₂O BIOS message appears first which indicates that a drive attached to a DPT controller will be the boot drive.

Solution: Use SMOR to modify the Bootable Devices parameter by selecting Disabled. This will prevent the DPT controller from being used as the booting controller for system.

-
- Problem:** The SmartRAID V controller I₂O BIOS reports the drive as a *disk* instead of a *drive*.
- Solution:** This typically happens when a drive that is attached to a SmartRAID V controller has been formatted with a sector size other than 512 bytes . Use Storage Manager or SMOR to reformat the drive with 512 byte sectors.

This can also occur if the drive is the 9th or higher logical drive attached to the controller.

NOTE *Using SMOR to set Bootable Devices to Disabled as in the previous problem will result in the same symptoms. If you require access to disk drives connected to the SmartRAID V controller during the boot process, change Bootable Devices to Normal.*

-
- Problem:** Although the SCSI devices can be accessed by the SmartRAID V controller, the fault LEDs on the devices in a RAIDstation storage cabinet do not flash during boot-up and the SmartRAID V controller does not detect drive swaps or cabinet failures.

- Solution:** These symptoms indicate that the RAIDstation storage cabinet status signals are not being properly received by the SmartRAID V controller.

For DEC Fault Bus subsystems: this can be caused by another SCSI device or non-DPT cabinet connected to the external SCSI cable along with the RAIDstation cabinet. Other devices will typically ground these signals.

For SAF-TE or SES: this can result from a failed enclosure monitoring module in the subsystem cabinet.

-
- Problem:** After updating the SmartRAID V controller firmware or BIOS and rebooting, the adapter does not respond.

- Solution:** The update may have been unsuccessful. The controller is now in a state in which it hangs the system during boot. If this happens, the parameters in the NVRAM can be restored to their default settings using the following procedure:

1. Turn off power to the system.
2. Place a shorting jumper across pins 1 and 2 of P4 on the controller.
3. Power on the system and wait until the LEDs 3, 5, 7 and 8 on the controller begin flashing.
4. Turn off power to the system and remove the jumper.

You can now reconfigure the controller using SMOR or Storage Manager.

Problem: After updating the SmartRAID V controller firmware or BIOS and rebooting, LEDs 1 and 5 or 2 and 5 flash once per second.

Solution: These patterns indicate that the adapter startup code detected a firmware checksum error or a flash error. Attempt the firmware update procedure again by using the procedure in the following Problem description to recover from this condition.

Problem: A flash ROM upgrade is unsuccessful, causing the controller to hang.

Solution: The new firmware can be temporarily disabled and the upgrade attempted again by following the steps below:

1. Power-off the system.
2. **PM1554, PM2554 and PM2654 controllers** – remove any RA4050 or SX405x expansion modules from the controller.
3. **PM1554, PM2554 and PM2654 controllers** – place shorting jumpers across pins 1 and 2 and pins 3 and 4 of P9 on the controller.
PM375x controllers – move the shorting jumper from pins 3 and 4 of P9 to pins 1 and 2 (from RUN to LOAD) as shown in Appendix A, “Assembly Drawings”.

NOTE *You do not need to remove an SX405x expansion module from PM375x controllers to access the jumper pins at P9.*

4. Insert the DPT SMOR Boot diskette and power-up the system. This will start SMOR.

NOTE *The SMOR Boot diskette image is available from the DPT Technical Support ftp site. The download file contains the diskette image and instructions for use.*

5. Use SMOR to update the firmware. You must restore all three components of the flash ROM, firmware, I₂O BIOS, and SMOR.
6. Power-off the system and return the jumpers to their original positions.
7. Reattach the expansion module to the controller card and insert the card in a host system PCI slot.
8. Remove the SMOR Boot diskette from your floppy disk drive and power-up the system.

-
- Problem:** After a flash ROM upgrade of the I₂O BIOS only, pressing **Ctrl+D** at the system prompt displays the message Card not configurable.
- Solution:** Perform a flash ROM upgrade for SMOR to correct this condition.
-
- Problem:** The floppy disk drive cannot be accessed after installing a DPT controller.
- Solution:** Use SMOR to enable the EBDA Relocation option.
-
- Problem:** The controller's audible alarm is sounding during normal operation.
- Solution:** This indicates a drive has failed. Start Storage Manager or restart the host system and run SMOR to identify the failed drive. The alarm will stop when Storage Manager or SMOR finish the system scan. Replace the failed drive and start a rebuild operation for the array.
- For additional information about procedures for failed drives, refer to Chapter 4, "Storage Manager on ROM" or Chapter 6, "Storage Manager".

APPENDIX C:

Specifications

This chapter lists the electrical and environmental specifications for the SmartRAID V product line.

Specifications:

- DC Power Requirements
- Environmental Specifications
- Memory Requirements
- Battery

DC Power Requirements

Voltage: 5 V \pm 5%
Ripple and Noise: 50mv peak-to-peak max

Component	Current (typical)
PM3754U2B	1.82A
PM3755U2B	1.90A
PM3755F	1.82A
PM2654U2	1.63A (with SX4054U2) 1.60A (with SX4055F) 1.35A (with RA4050; no cache)
PM2554U2	1.15A
PM1554U2	1.15A
RA4050	0.20A
SX4054U2	0.48A
SX4055U2	0.98A
SX4055F	0.45A
BB4050	0.27A (not charging) 1.16A (charging)
SM4050-16	0.16A
SM4050-64	0.16A

Voltage: 3.3 V \pm 5%
Ripple and Noise: 50mv peak-to-peak max

Component	Current
DM4050-16 DM4060-16	0.16A typical
DM4050-64 DM4060-64	0.16A typical

Environmental Specifications

Ambient Temp (operating):	10° C to 50° C 10° C to 40° C (PM3755U2B with BB4050)
Relative Humidity (operating):	10% to 90% non-condensing
Altitude (operating):	3,000 meters (10,000 feet)

NOTE *Maximum ambient temperature is 40°C when using a BB4050 module.*

Memory

SmartRAID V controllers accept up to four memory modules. The total memory installed must not exceed the maximum cache capacity of the controller.

Capacities

Product	Max Cache	Module Type
PM1554U2 w/RA4050	64MB	SIMM
PM2554U2 w/RA4050	64MB	SIMM
PM2654U2 w/RA4050	64MB	SIMM
PM3754U2	256MB	SIMM
PM3755F	256MB	SIMM
PM3755U2B	256MB	DIMM

SIMMs

Non-DPT SIMMs to be installed in SmartRAID V controllers must conform to the following specifications:

Speed:	60ns EDO
Size:	16MB or 64MB
Width:	32-bit or 36-bit
Configuration:	Single-sided, low-profile
Voltage:	5.0V

DIMMs

DIMMs to be installed in SmartRAID V controllers must be DPT DM4050 or DM4060 memory modules only. Use of non-DPT DIMMs can result in data corruption.

Battery

The following applies to the BB4050 module only:

Type:	Nickel Metal Hydride
Capacity:	3800mAH (minimum)
Backup time:	72 hours (with one 16MB memory module installed)
Charge time:	3 hours
Operating Temp:	10° C to 40° C

Exceeding the temperature limits can shorten the battery life and reduce the battery capacity. Storage Manager displays the ambient temperature for the controller which is reported by the onboard temperature sensor.

APPENDIX D:

SNMP

Simple Network Management Protocol (SNMP) is an industry-wide standard protocol designed to allow you to remotely manage your computer network. By using the DPT SNMP subagent and an SNMP-based management console, you can get the DPT hardware configuration and information for your servers from a remote workstation.

Introduction

What's Included

System Requirements

- Hardware Support
- Management Consoles
- Operating Systems and Platforms

Installation

- DPT SNMP Support
- Microsoft Windows SNMP

Operation

Software Overview

- DPT SNMP Subagent
- DPT SNMP Trap Broadcaster

Introduction

Simple Network Management Protocol (SNMP) lets you obtain basic DPT hardware configuration and status information from an SNMP-based management console. You can also receive SNMP Traps, which are messages about changes in the hardware status. These messages alert you to important events that affect the DPT hardware and attached devices.

Simple Network Management Protocol

Simple Network Management Protocol (SNMP) is a group of network management specifications, which includes the protocol itself, the definition of the database and associated concepts. SNMP is widely used and supported on a variety of servers, workstations, bridges, routers and hubs. SNMP support also includes other computer system resources, such as SCSI, Fibre Channel and RAID controllers.

SNMP implementations vary from simple device information display and collection of statistics, to complex configuration management systems. SNMP is implemented by creating a *Management Information Base* (MIB) that describes the objects to be managed. SNMP establishes standards to access and manage various types of data regarding attached resources within a computer network.

Management Information Base

As with any network management system, the core component of SNMP is the database containing the information about the objects to be managed. For SNMP this is referred to as the Management Information Base or MIB. A MIB is written using the ASN.1 (Abstract Syntax Notation One) format as described in ISO 8825-2. This format allows the exchange of structured data, especially between application programs over networks, by describing data structures in a form that is independent of machine architecture and application software.

Every system resource to be managed is represented as an object and the MIB is a collection of these objects. In a network environment each system (workstation or server) maintains a copy of the MIB containing the current status of the objects which it defines. The MIB information is kept up-to-date by a software agent. At the operating system level, there is a Master Agent that controls the system MIB. Each vendor for a managed resource (such as DPT) also supplies a subagent that contributes its own MIB to the system MIB. This sub-agent also responds to requests from the Master Agent for information as needed.

NOTE *For additional security all of the DPT MIB data is read-only. The DPT SNMP feature is intended only for gathering inventory information and for processing status and alert information.*

Management Console

The SNMP management console is usually a client workstation running SNMP-based management software. The console software can be from any vendor who provides SNMP management console software.

DPT MIB Information

The specific hardware and configuration information in the DPT MIB includes groups for the following:

- DPT SCSI System Modules
- DPT SCSI Controllers
- DPT SCSI Busses
- DPT SCSI Devices
- DPT SCSI Arrays
- DPT SCSI Statistics
- DPT SCSI Events

Refer to the MIB itself for the exact contents of each of these groups. The following lists are the groups' contents:

DPT SCSI System Modules group identifies the versions, creation date and various capabilities of the software modules. The following specific modules are included:

- DPT SNMP Subagent
- DPT SNMP Engine
- DPT SCSI Driver
- DPT SCSI Logger
- MIB revision information

DPT SCSI Controller group is a list of all DPT controllers in the system. This group contains the following information for each Controller:

- Controller Number
- Controller Vendor
- Firmware Version
- Address
- IRQ
- IRQ Type
- Host Bus Type
- Max Transfer Rate
- Controller Modules (RAID, Caching, SIMMs/DIMMs)

DPT SCSI Bus group is a list of the SCSI Buses with a set of parameters that describe and control a SCSI Bus. These parameters include:

- SCSI bus number
- SCSI bus width
- SCSI bus type
- SCSI bus transfer rate
- DPT controller SCSI ID (on this bus)

DPT SCSI Device group is a list of SCSI Devices managed by the DPT SCSI subsystem and represents the physical configuration. For each device in the system there is:

Device SCSI Address information:

Controller

Bus

ID

LUN

Device SCSI Inquiry data

Device Capacity and Block Size

Device RAID level and status (Optimal, Failed, etc.)

DPT SCSI Array group contains all the RAID-specific information within the DPT SCSI subsystem. For each Array there are:

Configuration parameters

SCSI address information

Background task information

DPT SCSI Statistics group contains statistical information regarding the DPT SCSI controllers, SCSI devices and arrays. For each SCSI controller, there are statistics on:

Cache Pages

Commands

Transfers

For Devices and Arrays there are statistics on:

Cache hits/misses

Stripe boundary crossings

Physical I/O commands (read/write)

DPT SCSI Events group is used to send traps on Controller event log entries. These event log entries are converted to SNMP traps and are identical to those used by the DPT Logger/Broadcaster. The specific traps are listed in the MIB.

What's Included

The DPT SNMP software components are included on the diskettes in the DPT controller package. Specific components vary by operating system.

The Windows 95/98 and Windows NT components are on the DPT Windows diskette. The components are as follows:

- DPT Event Logger
- SNMP Event Logger Extensions
- DPT SNMP sub-agent
- DPT MIB

System Requirements

The DPT SNMP feature has the following system requirements:

- The TCP/IP network protocol must be enabled on your system. Refer to your operating system documentation for information about installing the TCP/IP protocol.
- The SNMP Service for your operating system must be installed.

Hardware Support

The DPT SNMP agent is designed to work with all DPT SmartRAID V controllers. The specific controller information available will vary depending on whether or not that device has RAID or cache capability.

Management Consoles

The DPT SNMP agent conforms to the SNMP Version 1 specification. DPT has developed and tested this feature to work with various operating systems that provide built-in SNMP capability.

Operating System Support

The following table lists the environments in which DPT hardware is manageable from an SNMP management console:

Operating System	Comments
Novell NetWare	Versions 4.11, 4.2 and 5.0
Windows 95/98	
Windows NT 4.0	Workstation and Server versions

Installation of DPT SNMP Software

The following topics describe how to install DPT SNMP sub-agent software components and how to install SNMP support for Microsoft Windows 95/98 and Windows NT 4.0.

NOTE *Ensure that your operating system has SNMP support enabled before installing the DPT subagent software.*

Installing DPT SNMP Support

The DPT SNMP agent can be installed during the DPT Storage Manager installation process. The setup utility displays a Select Components dialog that includes a check box for the DPT SNMP software. To install this feature, check the box labeled SNMP System Agent.

By default this check box is not checked. Continue with the installation according to the installation procedure for your operating system in Chapter 5, “Software Installation”.

If your operating system is Windows NT, refer to the Microsoft Windows NT documentation for information about installing the SNMP Service.

Installing SNMP for Microsoft Windows 95

If your operating system is Windows 95, the SNMP Service must be installed by following these steps:

1. Insert the Windows 95 Installation CD-ROM into your CD-ROM drive. If the Autostart window appears, close the window.
2. Launch the Network icon in Control Panel. Click **Add** and select Service as the type of network component to install.
3. Click Add, then click the Have Disk button. Browse to the ADMIN\NETTOOLS\SNMP directory on the CD-ROM. The file SNMP.INF will be selected. Click **OK**.
4. Click **OK** in the Install From Disk window. The Microsoft SNMP agent will be selected. Click **OK** to complete the installation.

Installing SNMP for Microsoft Windows 98

If your operating system is Windows 98, the SNMP Service must be installed by following these steps:

1. Insert the Windows 98 Installation CD-ROM into your CD-ROM drive. If the Autostart window appears, close the window.
2. Launch the Network icon in Control Panel. Click **Add** and select Service as the type of network component to install.
3. Click **Add**, then click the **Have Disk** button. Browse to the \TOOLS\RESKIT\NETADMIN directory on the CD-ROM. The file SNMP.INF will be selected. Click **OK**.
4. Click **OK** in the Install From Disk window. The Microsoft SNMP agent will be selected.
Click **OK** to complete the installation.

Operation


Before you can view information about your DPT hardware, you must install the DPT Management Information Base (MIB) into the Management Console database. During the installation of the SNMP feature, the DPT MIB is installed by default as DPTMGR\DPTSCSI.MIB. Refer to your SNMP Management Console documentation for more information about adding this MIB to your existing database.

The DPT SNMP sub-agent can be accessed from any SNMP Management Console.

SNMP Software Overview

This section describes the architecture of the DPT SNMP functions in a platform independent manner.

The DPT SNMP software architecture is an addition to the current DPT software components. The components used in the SNMP implementation are the DPT Engine, Event Logger/Broadcaster and operating system device driver. The DPT Engine is used to gather all information on the system configuration and to perform the defined management functions. An SNMP Trap broadcast module has been added to the Event Logger to handle messages that are intended specifically for the SNMP console.



DPT SNMP Sub-Agent

The DPT SNMP sub-agent attaches to the operating system-specific Master Agent to handle SNMP requests for objects defined in the DPT MIB. It also broadcasts the DPT-specific Traps to the designated management consoles.

The design and implementation of the DPT SNMP sub-agent complies with the operating system-specific implementations of the SNMP specification. This assures compatibility and functionality within each operating system environment. On the client side, all SNMP management consoles are supported.


DPT SNMP Trap Broadcaster Module

The SNMP Trap implementation uses the Broadcaster feature of the DPT Event Logger. The Event Logger has individual broadcast modules that have complete control over how events are received from the Event Logger. The modules define what events are to be sent and how they want to receive the event information. Each broadcast module has control over which events are to be broadcast, how they are broadcast and where they are sent.

An SNMP Trap Broadcast module controls all DPT SNMP Traps. The SNMP Trap Broadcast module registers with the DPT Event Logger to receive all events generated for the DPT subsystem. This module then forwards all events to the DPT SNMP sub-agent for processing and delivery to the SNMP Master Agent.

Glossary

This glossary provides brief definitions of selected terms and acronyms used throughout this manual.



Adapter

SCSI Host Bus Adapter or HBA

ANSI

American National Standards Institute.

Arbitrated Loop

See FC-AL.

Array Group

A group of disk drives that appear to the computer as a single logical drive. RAID 0, RAID 1 and RAID 5 array groups can be composed of any combination of individual disk drives.

ASIC

Application Specific Integrated Circuit. An integrated circuit chip designed for a specific task rather than a general purpose design such as a microprocessor.

ASPI

Advanced SCSI Programming Interface. A protocol used by many SCSI drivers to communicate with SCSI controllers under MS-DOS, OS/2 and NetWare.

Asynchronous

Data transfer protocol that is not synchronized to a set timing interval. Asynchronous SCSI data transmitting devices must wait after each byte for acknowledgment from the receiving device. Either device can take as long as it needs to send or acknowledge data. Asynchronous SCSI has no defined maximum transfer rate but is typically limited to between 1.5 and 3MHz.

BIOS

Basic Input Output System. A ROM-based collection of device drivers and system start-up routines which is provided as an integral part of a computer. The BIOS provides enough intelligence to enable the computer to understand some simple keyboard commands and load the operating system from disk on power-up.

Bridge Controller

A device which appears as a single device on the bus, but which bridges to multiple devices. Bridge controllers are typically used to overcome limitations on the number of devices that can be on a single bus or to control remote subsystems.

Build

The operation of initializing a redundant array by creating consistent redundant information. In the case of a RAID 1 array, data from one drive is copied to a second drive. In the case of RAID 5 arrays, parity information is generated by XORing the disk data.

Burst

A term used to describe data words which are transmitted as a single group across a bus without interruption by another device.

Bus Mastering

A method of data transfer that allows data to be moved between a peripheral controller and system memory without interaction with the host CPU or a DMA controller. This technique allows the peripheral controller to take control of the system bus and move data at the maximum speed supported by the bus.

Cache

A temporary storage area (usually RAM) for data that would normally be accessed from a slower storage device. A cache management algorithm monitors the data access patterns and selects which data from the slower device is to be kept in the cache for quick access. Caches are normally transparent to or hidden from the accessing device.

CD-ROM

Compact Disk Read-Only Memory. A read-only storage device that can retrieve data from a removable optical storage disk similar to an audio compact disk.

Command Queuing

A feature that allows multiple I/O commands to be executed by a peripheral controller in a more efficient order.

Controller

A device that controls the transfer of data between a computer and a peripheral device. For example, disk drives, video displays, keyboards, and printers all require controllers. The DPT SmartRAID V is a controller for disk drives and disk arrays. See also, HBA.

DAE

Dynamic Array Expansion. A feature that enables you to increase your storage capacity under Windows NT by adding one or more drives to your RAID 0 and RAID 5 arrays while your system remains online.

Degraded Mode

The mode of operation of a redundant array in which it can continue to be accessed after a member drive has failed. For read accesses, data is synthesized from the other drives in the array. For write accesses, data is stored on the remaining drives in such a way that it can be restored when the failed drive is replaced.

Device

SCSI devices include peripherals such as disk and tape drives, optical devices, scanners, and printers. SCSI controllers are also considered SCSI devices.

Differential

An electrical signal protocol which transmits information through a current loop rather than by changes in voltage, thereby reducing the susceptibility to electrical interference. High Voltage Differential SCSI uses RS485 transceivers to transfer data at distances up to 25 meters (82 feet). Low Voltage Differential SCSI (Ultra2) achieves a 25 meter cable length without the need for external transceivers.

Digital High Availability Fault Bus

A proprietary Compaq Corporation (formerly Digital Equipment Corp.) bus standard that provides signals to host adapters for remote system management and device fault notification.

DIMM

Dual In-line Memory Module. A standard packaging for RAM on a small circuit board with a defined edge connector. See also SIMM.

Dirty

Refers to a cache page in which data has been written or modified but which has not yet been copied to the storage device. When the data has been copied to disk, the page is said to be clean.

DMA

Direct Memory Access. A method of data transfer that allows data to be moved between a peripheral controller and system memory without interaction with the host CPU. The data may be moved by the peripheral controller itself or by a separate DMA controller.

Driver

A system level software module that receives I/O requests from higher levels within the operating system and converts those requests to the protocol required by a specific hardware device such as a peripheral adapter.

Dual Loop

A method of providing Fibre Channel controller redundancy. By forming two arbitrated loops on a dual channel controller and connecting the devices to both loops, fault tolerance is provided for cable failure. In normal operation, the controller will use both loops to communicate with the devices, which maximizes controller bandwidth and performance.

EBDA

Extended BIOS Data Area. An area of system RAM that may be used by controller devices to store and execute their BIOS code. Standard rules define the way in which devices must share this space.

ECC

Error Correcting Code. A method of generating redundant information (checksums), which can be used to detect and correct bit errors in stored or transmitted data.

EDO DRAM

Extended Data Output DRAM. A type of RAM that improves memory read performance on systems that are designed to use EDO memory.

Elevator Sorting

A method of sorting records or cache pages by physical location on disk so that the information can be written to disk with less seek and rotational latency.

Events

Messages generated by DPT controllers for detected fault conditions or subsystem status changes.

Failed

The mode of operation of a drive or array in which the drive or array, because of a malfunction, can no longer be accessed.

Fast SCSI

The SCSI-2 standard for synchronous transfers at up to 10MHz. This provides a transfer speed of 10MB/sec for an 8-bit bus and 20MB/sec for a 16-bit bus. Devices that utilize these faster timings are called Fast SCSI devices. The original SCSI standard defined a 5MHz transfer rate.

Fast-20 SCSI

See Ultra SCSI.

Fast-40 SCSI

See Ultra2 SCSI.

FC-AL

Fibre Channel Arbitrated Loop – A Fibre Channel topology where up to 126 devices are connected in a serial (loop) fashion. The devices negotiate individually for use of the bus. See also, *Fibre Channel*.

Fibre Channel

A standard set of protocols for information transfer. Fibre Channel provides for high speed transfer of information over long cable lengths. Fibre Channel controllers can transfer data at up to 100MB/sec. among up to 126 devices over 30 meters of copper or 10 km of optical cable.

Flash ROM

A nonvolatile memory device on the controller that can be reprogrammed using special software without removing it from the board.

Flush

The action of writing all dirty data in the cache to disk.

Hardware Array

A group of disk drives that are all members of the same RAID level 1 or 5 array managed by a DPT controller and which appears to the computer as one storage device.

HBA

Host Bus Adapter – Refers to a DPT or other controller card that provides host computer access to the peripheral bus.

HDM

Hardware Device Module. The part of the I₂O split device driver that resides within the firmware of the device.

Hit

A data access in which the requested data is found in the cache.

Hit Ratio

The ratio of cache hits to total disk accesses. A hit ratio of 100% means that all disk accesses were serviced from the cache.

Hot Plug

The operation of adding or removing a device from a bus while transactions involving other devices are occurring over the bus.

Hot Spare

A disk drive that is assigned to automatically replace a failed disk drive.

Hot Swap

The operation of removing a failed disk drive that is a member of a redundant array and replacing it with a good drive while transactions involving other devices are occurring over the bus. Synonymous with Hot Plug.

HSSDC

High Speed Serial Data Connector. The industry standard modular connector used on Fibre Channel controllers.

I₂O

Intelligent I/O Architecture. A proprietary specification that provides a standardized software interface between peripheral devices with built-in intelligence and a host operating system.

ID

A numeric value used by SCSI devices to address one another. (IDs can be from 0 to 7 or 0 to 15 for Wide SCSI.) Fibre Channel devices can have ID numbers from 0 to 126.

Information View

The view in SMOR that provides a display of device specific information when that device is highlighted in the Tree View. The information on this view may be further grouped into Tab Pages.

Initiator

A SCSI device, such as a SmartRAID V controller, that sends commands to SCSI Target devices such as disk drives.

IRQ

Interrupt ReQuest. A hardware interrupt on a computer. Systems that use the IBM/Intel architecture have 16 IRQ lines used to signal the CPU when a peripheral event has started or terminated. Except for PCI devices, two devices cannot use the same line. The PCI bus allows IRQs to be shared between devices.

Latency

The time required by a device to access stored data, excluding the data transfer time. Reducing disk latency results in more I/O operations per second being performed on a disk drive.

LBA

Logical Block Address. A method of addressing storage blocks on a disk drive in a linear fashion, rather than by Cylinder, Track and Sector. This technique also overcomes storage addressing limitations on some systems.

LED

Light Emitting Diode. An electronic device that gives off light when power is applied.

LRU

Least Recently Used. A cache management algorithm employed by SmartRAID V to determine the next cache page to delete and reuse when all pages have been filled with data. By deleting the page in cache that has gone the longest without an access, the algorithm ensures that the most frequently accessed data is resident in the cache.

LSU

Logical Storage Unit. A device on which the computer can store and retrieve information. This can be an individual disk drive or an array group.

LUN

Logical Unit Number. Each SCSI device can contain up to eight sub-devices or logical units. The logical units are assigned from 0 to 7. Typically, SCSI devices such as a disk or tape drive contain only one subunit (LUN 0).

LVD SCSI

Low Voltage Differential SCSI. A SCSI-3 transmission protocol that provides long cable lengths without the need for external high voltage bus transceivers. The maximum synchronous transfer rate is 40MHz. Also known as Ultra2 SCSI.

MIA

Media Interface Adapter. A device that converts electrical signals to optical fiber signals for Fibre Channel connections.

Mirroring

A popular term for RAID 1. It refers to the method of creating disk-fault tolerance by storing duplicate information on pairs of drives.

Miss

A data access in which the requested data is not found in cache.

MTBF

Mean Time Between Failure. The average time between expected failures of a device in a large sample group of devices.

Multilevel RAID

A method of combining multiple RAID 1 or RAID 5 arrays into a single array, providing increased storage and performance in multi-user environments.

Non-Redundant Array

An Array Group with no fault tolerance (RAID 0). If only one drive in a non-redundant array fails, the entire array will fail.

NVRAM

Nonvolatile Random Access Memory. Hardware memory that stores data even when system power is turned off. SmartRAID controllers store their setup information in NVRAM.

Operating System

Software that manages the resources of a computer and provides the operating environment for application programs.

Optimal

The mode of operation of a disk array in which no drive failures have occurred.

OSM

Operating System Module. A system-level software module that provides communication between the host operating system and the intelligent hardware controller. See also HDM.

Page

The smallest region of cache which can be allocated to store data. Each page stores one 512-byte sector from disk.

Parity

A method of generating redundant information which can be used to detect errors in stored or transmitted data. Parity is used in standard memory modules and over the peripheral bus to detect data errors. Parity is used in RAID 5 disk arrays to reconstruct flawed or missing data sectors.

PCI

Peripheral Component Interconnect. An intelligent computer bus specification that provides automatic configuration of peripheral cards. The bus supports 32-bit data paths at a 132 MB/sec data transfer rate or 64-bit data paths at a 264 MB/sec data transfer rate.

PIO

Programmed Input/Output. A method of data transfer where data is moved between a peripheral controller and system memory by the CPU.

Plug-and-Play

The ability to install peripheral cards or devices without requiring a user to configure interrupts or addressing for the device.

Plug-and-Play BIOS

A part of the system BIOS in PCI computers that has the ability to automatically configure PCI peripheral cards so that there are no conflicts with other installed devices.

Predictive Caching

A method of analyzing disk I/O requests to improve system performance by predicting which data is likely to be needed in the near future. The data is then read into the physical cache.

RAID

Redundant Array of Independent Disks. A method of combining disk drives into one logical storage unit that provides disk-fault tolerance and can operate at higher throughput levels than a single disk drive.

Rebuild

The operation of restoring data belonging to a failed member of a redundant disk array by reconstructing the data from the other disks and writing that data to a replacement disk drive.

Redundant Array

A fault-tolerant disk array (for example, RAID 1 or RAID 5).

SAF-TE

SCSI Accessed Fault-Tolerant Enclosure. A specification (co-developed by nStor Corporation, Inc. and Intel Corp.) which provides a standardized method for monitoring and reporting on the condition of disk drives, power supplies and cooling systems used in high availability LAN servers and storage subsystems. The specification is independent of hardware I/O cabling, operating systems, server platforms, and RAID implementation because the enclosure itself is treated as a device on the SCSI bus.

Scatter/Gather

A feature that allows data to be transferred to or from multiple noncontiguous areas of host computer memory with a single I/O command.

SCSI

Small Computer Systems Interface. An ANSI standard parallel interface for communication with intelligent peripheral devices. The original SCSI definition is defined in ANSI document number X3.131-1986. The standard is now in its third major revision.

SES

SCSI Enclosure Services. A SCSI-3 command set that provides a method to manage and sense the state of the power supplies, cooling devices, displays, indicators, individual drives, and other non-SCSI components installed in an enclosure. See also SAF-TE.

SIMM

Single In-line Memory Module. A standard packaging for RAM on a small circuit board with a defined edge connector. See also DIMM.

Single-ended

An electrical signal protocol which transmits information through changes in voltage. Single-ended SCSI uses standard TTL signal-and-ground pairs to transmit information over the SCSI bus. Single-ended SCSI cables can be up to 3 meters in length.

S.M.A.R.T.

Self-Monitoring, Analysis and Reporting Technology. A standard for disk drives that monitor their own condition and report potential problems. It is part of the ATA-3 specification for IDE drives and is also used on some SCSI drives.

SPX

Sequenced Packet Exchange. The transport layer protocol used by Novell NetWare networks.

Stripe

A contiguous region of disk space. Stripes can be as small as one sector or can be composed of many contiguous sectors.

Striping

A method of distributing data evenly across all drives in an array by concatenating interleaved stripes from each drive.

Synchronous

A data transmission protocol which is synchronized to a defined time interval. Synchronous SCSI can transmit data faster than asynchronous SCSI because the transmitting device does not wait for acknowledgment of each byte from the receiving device.

Tagged Command Queuing

A feature of SCSI-2 and SCSI-3 protocols that allows SCSI commands to be executed out of order.

Target

A SCSI device, such as a disk drive, that receives and executes commands from a SCSI Initiator device such as a DPT SmartRAID V controller.

TCP/IP

Transmission Control Protocol/Internet Protocol. A widely used network communication protocol that is the standard for transmitting data through the Internet.

Termination

A method of matching the transmission impedance of an electrical bus so that signal reflections are minimized or eliminated.

TERMPWR

A signal line on the SCSI bus that supplies electric power for SCSI bus terminators.

Throughput

A term used to describe the amount of data that can be processed or transmitted by a system in a given amount of time.

Tree View

The view in SMOR that provides a graphic display of all controllers and devices on the system in a hierarchical format. When a device is highlighted in the Tree View, a corresponding Information View is displayed that provides specific information about that device.

Ultra SCSI

The SCSI-3 specification that defines synchronous data transmission rates of up to 20MHz. This transfer rate provides data transfer of up to 20MB/sec on an 8-bit bus and 40MB/sec on a 16-bit bus. Ultra SCSI is also called Fast-20 SCSI.

Ultra2 SCSI

The SPI-2 specification that defines synchronous data transmission rates of up to 40MHz. This transfer rate provides data transfers of up to 40MB/sec on an 8-bit bus and 80MB/sec on a 16-bit SCSI bus. Ultra2 SCSI is also called Fast-40 SCSI.

VHDCI

Very High Density Cable Interconnect. The small industry standard 68-pin external connector used on DPT SmartRAID V SCSI controllers.

Wide SCSI

A SCSI protocol and signal definition that provides a data path more than 8-bits wide. Wide SCSI buses can support both 8- and 16-bit data transfers. All SmartRAID V controllers use a 16-bit SCSI interface.

WORM

Write Once Read Multiple – An optical storage device similar to a CD-ROM that can write data one time only to any location on a removable optical disk. WORM drives are primarily used as data archive devices because once written, the data can never be erased.

Write-Back

A method postponing an actual data write operation to a slower device, such as a disk drive, by saving the data in a cache. The data can then be written at a time when the device would otherwise be idle.

Write-Through

Data is written to directly to the final destination before a write operation is reported as complete.

XOR

Exclusive OR. A logical operation performed on two binary operands which yields a 0 for every bit position where the operands are both 1 or both 0, and a 1 in every bit position when the operands are dissimilar.

Index

A

address

- controller 3-16, 4-13
- I2O BIOS 7-36
- logical device 6-7

alarm

- audible 2-13, 6-39
- disable 2-13, 6-39
- testing 6-15

architecture, SmartRAID V 7-22

array group

- building with SMOR 4-21
- building with Storage Manager 6-23
- caching configuration 6-18
- copying data 6-23
- creating 4-20, 6-22
- deleting 4-23, 6-28
- expanding 6-26
- hot spare rebuild 6-41
- information (SMOR) 4-17
- modifying 6-24
- naming 6-24
- number of drives 6-19
- rebuilding 6-21, 6-40
- starting a build 6-28
- task priority 6-43

ASPI protocol 7-22

asynchronous SCSI 7-29

AUTOEXEC.BAT

- Windows 95/98 5-8, 5-10
- Windows NT 5-7

B

background task priority 6-43

battery backup

- auto write-through 6-11
- initial calibration 6-12
- maintenance 6-13
- predictive failure warning 6-11
- status messages 6-12
- status window 6-11

battery module

- features 2-10
- installing 3-14
- warning 2-10

battery specifications C-4

BB4050

- configuration 6-11
- features 2-10
- installing 3-14
- status 6-12

bootable devices 4-10

booting controller 3-16

bridge controller 7-27

Broadcaster 6-31, 6-34

- NetWare 6-34
- pager event messages 6-33
- SCO Unix 6-35
- SCO UnixWare 6-35
- Windows NT 6-36

BSD/OS 5-1

building arrays

- SMOR 4-2, 4-20
- Storage Manager 6-23, 6-28

bus expansion module

- compatibility 3-9
- features 2-8
- installation 3-9
- types 2-8, 3-9

bus mastering

- byte/word alignment 7-24
- PCI 7-25

C

cable

- adapters 1-5
- disk activity 3-15
- external cable detect 7-29
- Fibre Channel 3-3
- guidelines 7-30, 7-32
- included with product 1-5
- LVD 7-32
- SCSI cable installation 3-3
- single-ended 7-30
- Ultra2 7-32

- cache
 - caching host reads 7-12
 - configuring 6-18, 7-6
 - DIMM, installing 3-13
 - DOS/Windows 3.1 setting 4-10
 - flushing 7-7, 7-10
 - operating system 7-7
 - operating system, size of 7-12
 - optimizing size 7-12
 - predictive 2-4, 6-19, 7-10
 - requirements 3-11, 3-13
 - SIMM, installing 3-11
 - virtual 7-6, 7-10
 - write-back vs. write-through 7-9
- Century
 - expansion modules 2-8
 - features 2-7
 - SIMM installation 3-11
 - system requirements 1-5
 - types 2-7
- cluster server
 - cables 3-20
 - enable/disable, support for 4-14
 - overview 3-18
 - requirements 3-19
 - SmartRAID V 3-20
- command
 - overlapping 7-23
 - queuing 7-24
- configuration, setting 4-19
- controller
 - booting 3-16
 - ID 3-6
 - installing 3-15
 - intelligent 7-3
 - IRQ 3-16
 - NVRAM reset 3-17
 - SCSI ID, changing 4-14, 6-15
- creating data redundancy 7-19

D

- DAE. *See* Dynamic Array Expansion
- data verification 6-42
- Decade
 - cache 2-7
 - features 2-2, 2-7
 - SIMM installation 3-11
 - system requirements 1-5

- degraded mode 7-21
- deleting arrays 6-28
- device
 - caching configuration 6-18
 - capabilities 4-16
 - configuring IDs 3-6
 - formatting 4-24
 - SCSI capabilities 6-17
 - status info 4-16
- differential SCSI 7-28
- Digital Fault Bus G-3
- DIMM
 - installing 3-13
 - restrictions 3-13
 - types 2-6
- DM4050, installing 3-13
- documentation
 - chapter summaries 1-2
 - overview 1-2
- DOS/Windows 3.1 cache setting 4-10
- drivers
 - BSD/OS 4.1 5-1
 - FreeBSD 5-1
 - Linux 5-24, 5-25
 - Novell NetWare 5-17
 - SCO Unix 5-14
 - Windows NT 5-2, 5-7
- Dynamic Array Expansion. *See* DAE
 - overview 6-24
 - performance 6-25
 - system requirements 6-25
 - using 6-26

E

- EBDA. *See* extended BIOS data area
- ECC
 - enabled LED 2-12
 - error LED 2-12
- enable extended int13 4-10
- environmental specifications C-3
- event
 - levels 6-29
 - logging 6-30
 - send message to pager 6-33
 - SNMP D-11
 - viewing 6-34, 6-36

- event notification
 - broadcasters 6-34
 - configuring 6-31
 - NetWare 6-34
 - pager messages 6-33
 - SCO Unix 6-35
 - SCO UnixWare 6-35
 - SNMP D-11
 - Windows NT 6-36
- expanding arrays 6-26
- extended BIOS data area
 - definition of G-3
 - relocation, enabling 4-10
 - SMOR parameter 4-10
 - troubleshooting B-2, B-7
- extended Int 13 4-10

F

- Fibre Channel
 - cable 3-3
 - configuration 3-3, 3-6
 - connector 3-3, 7-35
 - controller 2-5, A-2
 - description of 7-35
 - device ID 3-6
 - expansion module 2-6, 2-8
- firmware
 - file name 4-27
 - restoring from disk 4-28
 - saving to disk 4-27
 - upgrading 4-25, 6-15
- flash
 - SMOR 4-25
 - Storage Manager 6-15
 - unsuccessful, recovering from B-6
- flushing, cache
 - operating system 7-7
 - strategy 7-10
- formatting disks
 - SMOR 4-24
 - Storage Manager 6-38
- FreeBSD 5-1
- full stripe write 7-19

H

- hardware device module (HDM) 7-22, 7-23
- Hot Spare 2-4, 6-41
 - assigning 4-23
 - icon 6-4
 - removing 4-23

I

- I/O statistics 6-44
- I2O
 - command processing 7-23
 - features 7-22
 - intelligent controllers 7-4
 - split driver model 7-22
- I2O BIOS
 - configuration 7-36
 - flash upgrading 4-25
 - powerup message 7-36
- icons
 - SMOR 4-4
 - Storage Manager 6-4
- installation
 - battery module 3-14
 - bus expansion module 3-7, 3-10
 - configuring 3-3
 - controller 3-15
 - drivers
 - BSD/OS 4.1 5-1
 - FreeBSD 5-1
 - Linux 5-25
 - NetWare 5-17
 - SCO Unix 5-14
 - Windows 95/98 5-7
 - Windows NT 5-2, 5-7
 - memory modules 3-11, 3-13
 - overview 3-2
 - procedure 3-2
 - RA4050 3-8
 - RAID Accelerator 3-8
 - roadmap 1-3
 - SIMMs 3-11
 - SNMP D-7
 - Storage Manager
 - Linux 5-26
 - SCO UNIX 5-14
 - Windows 5-13

I-4

Int 13, extended 4-10

IRQ 3-16

K

keys, SMOR navigation 4-3

L

LED

battery module 2-13, A-12

cache status 2-12

Century/Decade, location of A-5

controller active 2-12

controller idle 2-11

disk activity 3-15

ECC enabled 3-11, 3-13

PM375x, location of A-3

power up sequence 2-11

RA4050, location of A-11

Linux

driver installation 5-25

Storage Manager 5-26

locality of reference 7-10

logical block addressing 4-10

logical device address 6-7

logical storage unit (LSU) 6-19

logical unit number (LUN) 7-27

LVD SCSI 7-28

M

management console, SNMP D-3

management information base D-2

memory capacities C-3

memory modules

Century/Decade 2-9

Millennium 2-6

memory specifications C-3

microprocessor 7-26

Microsoft Cluster Server

cables 3-20

enable/disable, support for 4-14

overview 3-18

SmartRAID V 3-20

system requirements 3-19

Index

Millennium

connectors 2-6

DIMM installation 3-13

expansion modules 2-6

features 2-5

memory modules 2-6

SIMM installation 3-11

mirroring 7-15

module installation 3-7

MSCS. *See* Microsoft Cluster Server (MSCS)

multi-mode SCSI 7-29

N

naming arrays 6-24

Novell NetWare

boot controller, 4.11 5-18

boot controller, 4.2 5-20

boot controller, 5.0 5-22

driver installation 5-17

remote communication 5-24

secondary controller, 4.11 5-19

secondary controller, 4.2 5-21

secondary controller, 5.0 5-23

NT. *See* Windows NT

NVRAM

clearing 3-17

resetting 6-28

restoring defaults 3-17

O

operating system

NetWare remote communication 5-24

operating system drivers

BSD/OS 4.1 5-1

FreeBSD 5-1

Linux 5-24, 5-25

NetWare 4.11 - booting 5-18

NetWare 4.11 - secondary 5-19

NetWare 4.2 - booting 5-20

NetWare 4.2 - secondary 5-21

NetWare 5 - booting 5-22

NetWare 5 - secondary 5-23

SCO

OpenServer 5 5-14

UNIX 3.2v4.2 5-14

UnixWare 7 5-15

- Windows 95/98 5-7
- Windows NT 5-2
- operating system services module (OSM)
 - description of 7-22
 - dynamic array expansion 6-25
 - Microsoft Windows 5-2, 5-6

P

- pager event notification 6-33
- parity group 7-18
- partial stripe write 7-19
- password, remote communication
 - changing 6-51
 - default 6-51
 - SCO servers 6-52
 - Windows 95/98 6-51
 - Windows NT 6-51
- PCI bus 2-5, 7-25
- performance
 - caching 7-6
 - intelligent I/O 7-3
 - pipelined parallel processing 7-5
- physical configuration view 6-4
- pipelined parallel processing 7-5
- powerup
 - booting controller 3-16
 - I2O BIOS message 7-36
- predictive caching 2-4, 6-19, 7-10
- prefetch algorithm 7-11

R

- RA4050
 - features 2-9
 - installation 3-8
 - SIMM installation 3-11
 - SIMMs 2-9
- RAID
 - array groups 4-17
 - bad data list 7-20
 - bad parity list 7-20
 - degraded mode 7-21
 - dual-level 7-18
 - I/O errors 7-20
 - intelligent controller 7-3
 - parity 7-19

- RAID 0 7-14
- RAID 1 7-15
- RAID 2 7-15
- RAID 3 7-16
- RAID 4 7-16
- RAID 5 7-17
- RAID Accelerator
 - features 2-9
 - installation 3-8
 - SIMM installation 3-11
- read-ahead algorithm 7-10
- read-modify-write 7-19
- rebuilding arrays
 - button 6-21
 - hot spare 6-41
 - task priority 6-43
 - using SMOR 4-24
 - using Storage Manager 6-40
- remote communication
 - command line parameter 6-53
 - configuration file, editing 6-50
 - configuring 6-49
 - default password 6-51
 - NetWare support 5-24
 - network attached 6-49
 - phonebook 6-55
 - servers 6-51
 - TCP/IP 6-50, 6-52
- reset NVRAM 3-17

S

- SAFTE G-7
- scan delay 4-10
- SCSI
 - ANSI specification 7-26
 - asynchronous 7-29
 - cable installation 3-3
 - commands and messages 7-27
 - Common Command Set (CCS) 7-26
 - configurable parameters
 - controller termination 4-14
 - SCSI ID 6-15
 - termination 3-4
 - TERMPWR 4-13, 4-14
 - controller ID 3-6, 6-14
 - device capabilities 6-17
 - device IDs 3-6

- devices, number of 3-6
- differential 7-28
- LUNs 7-27
- LVD 7-28
- LVD cabling 7-32
- mixing LVD and non-LVD devices 7-29
- multi-mode 7-29
- residue reporting 7-28
- single-ended cabling 7-30
- singled-ended 7-28
- synchronous 7-29
- termination 3-4, 7-33
- TERMPWR 4-13, 4-14, 7-34
- transfer padding 7-28
- transfer rate 7-30
- Ultra2 cabling 7-32
- wide 3-3, 3-6, 7-29
- SES (SCSI Enclosure Services) G-7
- SIMM
 - installing 3-11
 - restrictions 3-11
- single-ended SCSI 7-28
- SM4050, installing 3-11
- SmartRAID V
 - architecture 7-22
 - configuration 6-13
 - controller ID 3-6
 - features 2-4
 - installation 3-15
 - modules, installing 3-7
 - product overview 2-2
 - products 2-3
- SMOR
 - array information 4-18
 - controller configuration 4-13
 - controller information 4-11
 - device capabilities 4-16
 - device information 4-15
 - device status 4-16
 - icons 4-4
 - information view 4-6, 4-11
 - keyboard reference 4-3
 - menu reference 4-4
 - navigation 4-5, 4-6
 - overview 4-2
- parameters
 - bootable devices 4-10
 - DOS/Windows 3.1 cache 4-10
 - EBDA relocation 4-10
 - enable extended int13 4-10
 - scan delay 4-10
 - termination 3-4, 4-14
 - TERMPWR 4-14
- running 4-8
- screen layout 4-5
- tree view 4-6
- upgrading 4-25
- SNMP
 - components D-6, D-10
 - description of D-2
 - installing D-7
 - management console D-3
 - MIB D-2
 - MIB, DPT specific D-3
 - operating system support D-7
 - operation D-9
 - software overview D-9
 - sub-agent D-10
 - system requirements D-6
 - trap broadcaster D-11
- status
 - array 6-8
 - device 4-16
 - drive 6-8, 6-17
 - failed drive 6-39, 6-41
- Storage Manager
 - array group
 - creating 6-22
 - deleting 6-28
 - modifying 6-24
 - naming 6-24
 - background task priority 6-43
 - Broadcaster 6-31, 6-34
 - NetWare 6-34
 - SCO Unix 6-35
 - SCO UnixWare 6-35
 - Windows NT 6-36
 - configuration files 6-28
 - controller information 6-10
 - device information 6-17
 - event logging 6-30

- event notification 6-31, 6-34
 - NetWare 6-34
 - SCO Unix 6-35
 - SCO UnixWare 6-35
 - Windows NT 6-36
- I/O statistics 6-44
- Linux installation 5-26
- modem operation 6-48
- network operation 6-3, 6-48
- overview 6-2
- physical configuration view 6-4
- platforms supported 5-1
- remote operation 6-3, 6-48
- running 6-3
- SCO UNIX installation 5-14
- system requirements 6-2
- Windows installation 5-13

striping 7-13

sub-agent, SNMP D-10

SX405x

- connectors 2-9
- features 2-8
- installation 3-9
- types 2-8

synchronous SCSI 7-29

system requirements 1-5

T

temperature 6-10, C-3

termination 7-33

- configuration 3-4
- enabling 4-14
- power 4-14, 7-34

TERMPWR 4-13, 4-14, 7-34

transfer padding and residue reporting 7-28

U

Ultra2 SCSI 7-28, 7-32

upgrading firmware 4-25, 6-15

V

Verify 6-42

virtual cache 7-10

W

wide SCSI

- IDs 3-6
- termination 3-4
- with Narrow (8-bit) devices 3-3

Windows 95/98 5-7

Windows NT 5-2

X

XOR 7-19

