



# Intel<sup>®</sup> System Event Log Viewer Utility

## User Guide

This User Guide serves as a reference document providing instruction on the use of Intel's *System Event Log (SEL) Viewer Utility*.

**< This page is intentionally left blank.>**

## Document Revision History

Date Published	Revision	Revision Change Description
Nov 2016	1.00	First version
Nov 2016	1.01	Remove version 13.1, update to version 14.0 Modify linux intallation note

## Disclaimers

No license (express or implied, by estoppel or otherwise) to any intellectual property rights is granted by this document.

Intel disclaims all express and implied warranties, including without limitation, the implied warranties of merchantability, fitness for a particular purpose, and non-infringement, as well as any warranty arising from course of performance, course of dealing, or usage in trade.

This document contains information on products, services and/or processes in development. All information provided here is subject to change without notice. Contact your Intel representative to obtain the User Guide.

The products and services described may contain defects or errors known as errata which may cause deviations from published specifications. Current characterized errata are available on request. Intel, the Intel logo, are trademarks of Intel Corporation in the U.S. and/or other countries.

\*Other names and brands may be claimed as the property of others

© 2016 Intel Corporation

# Table of Contents

<b>1</b>	<b>Introduction.....</b>	<b>1</b>
1.1	<i>Operating System Supported .....</i>	<i>2</i>
1.2	<i>Target Audience .....</i>	<i>2</i>
1.3	<i>Glossary of Terms .....</i>	<i>2</i>
1.4	<i>Support Information .....</i>	<i>3</i>
<b>2</b>	<b>Using the Intel® SEL Viewer .....</b>	<b>4</b>
2.1	<i>Installing the Intel® SEL Viewer.....</i>	<i>4</i>
2.2	<i>Launching the Intel® SEL Viewer.....</i>	<i>5</i>
2.3	<i>Viewing SEL Records in Interpreted Text Format.....</i>	<i>6</i>
2.4	<i>Viewing SEL Records in Hex Format.....</i>	<i>7</i>
2.5	<i>Viewing the Intel® SEL Viewer Information Window.....</i>	<i>9</i>
2.6	<i>Navigating the Intel® SEL Viewer Window.....</i>	<i>9</i>
2.7	<i>Saving the Intel® SEL to a File.....</i>	<i>10</i>
2.8	<i>Viewing the Intel® SEL from a File.....</i>	<i>10</i>
2.9	<i>Checking the Intel® SEL Properties .....</i>	<i>10</i>
2.10	<i>Clearing the Intel® SEL .....</i>	<i>11</i>
2.11	<i>Sorting the Intel® SEL Entries in the UI .....</i>	<i>11</i>
2.12	<i>Go to Option (Linux*-only Feature).....</i>	<i>11</i>
2.13	<i>Getting Additional Help .....</i>	<i>11</i>
2.14	<i>Uninstalling the Intel® SEL Viewer.....</i>	<i>11</i>
	<b>Appendix Exit Error Codes.....</b>	<b>13</b>

## List of Tables

Table 1. Operating Systems Supported .....	2
Table 2. Glossary of Terms .....	2
Table 2. Accronym Used in the Raw Hex Display .....	8
Table 3. Exit Error Codes.....	13

## List of Figures

Figure 1: SEL Viewer Text View .....	6
Figure 2: SEL Viewer Main Window (Windows* & Linux* OSes).....	6
Figure 3: SEL Log in Hex Format (EFI) .....	7
Figure 4: SEL Records in Hex Format (Linux*) .....	8
Figure 5: Status Box.....	10
Figure 6: SEL Properties Dialog.....	10

**< This page is intentionally left blank.>**



# 1 Introduction

---

Thank you for purchasing and using the Intel® Server Boards. The System Event Log (SEL) Viewer can be used to display, clear, or save the SEL log on your server.

The SEL Viewer utility provides the ability to view system event records stored on the server management storage device of a server. The Baseboard Management Controller (BMC) records the details about the system events in a log in flash memory. Each SEL entry is a single system event.

- Displays the SEL records in either a text or a hexadecimal format.
- Allows you to save SEL entries to a file.
- Allows you to load SEL entries from a server and displays their properties.

The *Intel® System Event Log (SEL) Viewer Utility* is only supported on the following Intel Server products:

- Intel® Server Board based on Intel® Xeon® processor E5-1600/2600/4600 v2 product family
- Intel® Server Board based on Intel® Xeon® processor E5-2400 v2 product family
- Intel® Server Board based on Intel® Xeon® processor E5-2600 v3/v4 product family
- Intel® Server Board based on Intel® Xeon® processor E3-1200 v2/v3/v4 product family
- Intel® Server Board based on Intel® Xeon® processor E3-1200 v5 product family
- Intel® Server Board based on Intel® Xeon® Phi™ product family

For the latest information on your server, refer to <http://support.intel.com/support/motherboards/server/>.

## 1.1 Operating System Supported

This version of the SEL Viewer utility runs on the following OSes.

**Table 1. Operating Systems Supported**

Platforms	SELViewer utility version	Operating Systems/Preboot environment supported
<ul style="list-style-type: none"> <li>Intel® Server Board based on Intel® Xeon® processor E5-1600/2600/4600 v2 product family</li> <li>Intel® Server Board based on Intel® Xeon® processor E5-2400 v2 product family</li> <li>Intel® Server Board based on Intel® Xeon® processor E5-2600 v3/v4 product family</li> <li>Intel® Server Board based on Intel® Xeon® processor E3-1200 v2/v3/v4 product family</li> <li>Intel® Server Board based on Intel® Xeon® processor E3-1200 v5 product family</li> <li>Intel® Server Board based on Intel® Xeon® Phi™ product family</li> </ul>	14.0	EFI shell Windows 2016 (EM64T) Windows* Server 2012 Enterprise (32bit & EM64T) Windows Server 2012 R2 EM64T Windows Server 2008 Enterprise (32bit & EM64T) Windows Server 2008 R2 SP1 EM64T Windows Server 2003 Enterprise (32 bit SP2 & EM64T SP2) Windows 7 (32bit & EM64T) for Work Station SKU's Windows PE 2.0 – built from Windows Vista, 32 bit Windows PE 2.1 – built from Windows Vista SP1 or Windows Server 2008, EM64T) Windows PE 3.x (32bit & EM64T) Windows PE 4.x (32bit & EM64T) RHEL*6.x and 7.x (32 bit & EM64T) CentOS* 6.x (32 bit & EM64T) SuSE* 11 SP1/SP2/SP3 and 12.x ( 32 bit & EM64T)

**Note:** SELViewer version may be different across different platforms. Download the supported SELViewer version and build for your platform from Intel Support website. Also refer to the release notes for known issues.

## 1.2 Target Audience

This User Guide is intended for Original Equipment Manufacturers and those who are responsible for configuring the system BIOS and Management Firmware settings on a Intel Server system.

## 1.3 Glossary of Terms

The following table lists the terminology used in this document and the description.

**Table 2. Glossary of Terms**

Term	Definition
BIOS	Basic Input Output System
BMC	Baseboard management controller
EPS	External Product Specification
IPMI	Intelligent Platform Management Interface
JRE	Java* Runtime Environment
LAN	Local area network
RAM	Random Access Memory
SEL	System event log

## 1.4 Support Information

### World Wide Web

<http://support.intel.com/support/>

For an updated support contact list, see <http://www.intel.com/support/9089.htm/>.

## 2 Using the Intel® SEL Viewer

### 2.1 Installing the Intel® SEL Viewer

To install the SEL Viewer Utility **in EFI**, do the following:

1. Copy all the files in the SEL Viewer release directory for EFI to a USB flash drive, or create an EFI-bootable CD.
2. Insert the removable media into the server.
3. Boot the server and press the <F2> key when prompted to enter BIOS setup.
4. Go to the Boot Manager menu and select the option to boot to EFI shell.
5. At the EFI shell prompt, type `fsn:` , where n is the file system number corresponding to the device that contains the SEL Viewer utility files.

To install the SEL Viewer Utility **in Windows\*** with the standalone installation, do the following:

- **Prerequisites:** Java\* Runtime Environment (JRE) must be installed.
1. Install JRE X32 version for supporting WinPE\* 2.0 (32 bit) OS and JRE X64 version for supporting WinPE 2.1 (EM64T) OS. Installation of JRE in a USB pen drive should be performed on the same version of the operating system; for example, for JRE x32 version use windows 32-bit OS and for JRE x64 version use Windows\* 64-bit OS.
  2. In Windows\*/WINPE\* set the JRE path using `PATH=%PATH%;<>:\bin` (where <> is the USB directory shown on the cmd prompt such as D: or E: or the path where java is installed (for example, c:\Program Files\Java).
  3. While installing JRE on USB pen drive to support WinPE\* 2.0 and WinPE\* 2.1, change the installation directory USB pen drive (for example, g:\).
  4. Copy all files and subdirectories from the utility released location into a folder on the hard drive (for example, c:\Selview).
  5. Open a command prompt and change to that directory:
    - a. For 32-bit Windows\*/WINPE\*, go to folder c:\Selview\Windows\x86\imbdriver.
    - b. For 64-bit Windows\*/WINPE\*, go to folder c:\Selview\Windows\x64\imbdriver.
  6. Execute `install.cmd` as administrator.

This installation script will install the Intel IPMI driver. If Microsoft IPMI driver is present, the Intel IPMI driver will not be installed on the system.
  7. To run the SEL Viewer Utility, open a command prompt, and change directory to the folder where the `selview.exe` file resides (for example, `cd c:\Selview\windows\x86`).

You can now run the utility.

To install the SEL Viewer Utility **in Linux\***

- **Prerequisites**
1. Java\* Runtime Environment (JRE) must be installed.
  2. XServer must be running for the Intel® SEL Viewer GUI to work.
  3. In Red Hat\* 6 OSes:
    - a. If the utility fails with the error message:  
"Error while loading shared libraries: libncurses.so.5: cannot open shared object file: No such file or directory"  
then install `libstdc++-4.4.4-13.el6.i686.rpm` and `ncurses-libs-5.7-3.20090208.el6.i686.rpm` from the OS CD itself using the following commands:  
`#rpm -ivh libstdc++-4.4.4-13.el6.i686.rpm`  
`#rpm -ivh ncurses-libs-5.7-3.20090208.el6.i686.rpm`

Example:

```
rpm -ivh media\Packages\libstdc++-4.4.4-13.el6.i686.rpm
```

- b. If the utility fails with error message:

"Error: /lib/ld-linux.so.2: Bad ELF interpreter: No such file or directory".

It indicates the development and optional packages are not installed. Install the necessary packages accordingly.

4. On RHEL\* 6.4 (or above), CentOS\* 6.x, UEFI aware Linux\* or other Linux\*:

There might be a driver confliction between internal driver and kernel. You need to start up OpenIPMI driver and make sure "/dev/ipmi0" device is existed.

For example, you can use the below command to start up OpenIPMI driver on RHEL\* 6.4.

```
#modprobe ipmi_devintf
```

- A. Regular Installation:

- i. Boot into Linux and unzip the SELViewer utility zip file into a folder on your hard drive.
- ii. Copy all files and subdirectories from the utility released location into a folder on the hard drive (for example, /home/Selview/Linux).
- iii. Open a command prompt and change to that directory (for example, cd /home/Selview/Linux).
- iv. Unzip selview.zip to get the executable. Use "chmod 755" to change executable and script. Type

**./selview" to run selviewer.**

- B. RPM Installation:

- i. Boot into Linux\* and unzip the SELViewer utility zip file into a folder on your hard drive.
- ii. Copy rpm from Linux/RPM folder to a local folder.
- iii. If there is another version already has been installed previously, uninstall that version first before installing the new version.
- iv. Install selviewer utility by using `rpm -ivh selviewer-xxx.rpm`. This will install the utility in /usr/bin/selview/ folder.
- v. In RHEL\*/SLES\* after installing the rpm, close the terminal from which rpm was installed and then execute the utility from a new terminal (for example, `# selview`).
- vi. Type selview to run selviewer.

## 2.2 Launching the Intel® SEL Viewer

To launch the SEL Viewer, do the following:

1. Boot to the target OS.
2. From the directory containing the SEL viewer files, launch the SEL viewer from the EFI shell using the following syntax:

```
selview [/clear | {/save [filename] [/hex]} | /h | /?]
```

---

**Note:** A hyphen (-) may be substituted for the forward slash (/).

---

Examples:

```
selview
```

(This launches the graphical version of the SEL viewer.)

```
selview /clear
```

```
selview /save MyFileName /hex
```

```
selview /h
```

## 2.3 Viewing SEL Records in Interpreted Text Format


1. Launch the SEL Viewer.
2. The graphical display will display all the SEL entries. The following example shows the text view.



**Figure 1: SEL Viewer Text View**

The EFI-based SEL Viewer's main window is based on a multi-column display pane as shown in Figure 1. It displays all the SEL records and a pull-down menu used for selecting the main functions available in the utility.

See Figure 2 for SEL Viewer Main Utility Window (Windows\* & Linux\* OSES). The default format in which information is displayed in interactive mode is the interpreted text format.



**Figure 2: SEL Viewer Main Window (Windows\* & Linux\* OSES)**

The interpreted data is displayed in several columns as follows:

- Serial No.: Serial number of the system events are displayed starting with 1, and increasing by one for each event.
- Time Stamp.
- Sensor Type and Number.
- Event Description<sup>1</sup>
- Generator ID.


The bottom information pane shows the details on the highlighted SEL entry. Use the arrow keys to move up and down, or the Tab key to highlight a menu. In Linux\*, the bottom information pane contains a statistics panel which holds a statistical table of events based on their Event Type (Critical, Warning, Informational, or Others).

For information on using the menu items see section *Viewing the Intel® SEL Viewer Information Window*.

## 2.4 Viewing SEL Records in Hex Format

Highlight the **View** tab to choose how the SEL entries are displayed (raw hexadecimal format or plain text). Select the raw-hexadecimal format to view the SEL records in HEX format.

The following screen shows an example of the SEL log in Hex format.



RID: [01] [00]	RT: [02]	TS: [13] [CD] [2D] [4C]	GID: [20] [00]	ER: [04]	ST: [10]
RID: [02] [00]	RT: [02]	TS: [86] [CE] [2D] [4C]	GID: [20] [00]	ER: [04]	ST: [04]
RID: [03] [00]	RT: [02]	TS: [87] [CE] [2D] [4C]	GID: [20] [00]	ER: [04]	ST: [04]
RID: [04] [00]	RT: [02]	TS: [87] [CE] [2D] [4C]	GID: [20] [00]	ER: [04]	ST: [04]
RID: [05] [00]	RT: [02]	TS: [87] [CE] [2D] [4C]	GID: [20] [00]	ER: [04]	ST: [04]
RID: [06] [00]	RT: [02]	TS: [87] [CE] [2D] [4C]	GID: [20] [00]	ER: [04]	ST: [04]
RID: [07] [00]	RT: [02]	TS: [88] [CE] [2D] [4C]	GID: [20] [00]	ER: [04]	ST: [04]
RID: [08] [00]	RT: [02]	TS: [88] [CE] [2D] [4C]	GID: [20] [00]	ER: [04]	ST: [04]
RID: [09] [00]	RT: [02]	TS: [88] [CE] [2D] [4C]	GID: [20] [00]	ER: [04]	ST: [04]
RID: [0A] [00]	RT: [02]	TS: [89] [CE] [2D] [4C]	GID: [20] [00]	ER: [04]	ST: [04]
RID: [0B] [00]	RT: [02]	TS: [89] [CE] [2D] [4C]	GID: [20] [00]	ER: [04]	ST: [04]
RID: [0C] [00]	RT: [02]	TS: [89] [CE] [2D] [4C]	GID: [20] [00]	ER: [04]	ST: [04]
RID: [0D] [00]	RT: [02]	TS: [89] [CE] [2D] [4C]	GID: [20] [00]	ER: [04]	ST: [04]
RID: [0E] [00]	RT: [02]	TS: [8A] [CE] [2D] [4C]	GID: [20] [00]	ER: [04]	ST: [04]
RID: [0F] [00]	RT: [02]	TS: [8A] [CE] [2D] [4C]	GID: [20] [00]	ER: [04]	ST: [04]
RID: [10] [00]	RT: [02]	TS: [8A] [CE] [2D] [4C]	GID: [20] [00]	ER: [04]	ST: [04]
RID: [11] [00]	RT: [02]	TS: [8A] [CE] [2D] [4C]	GID: [20] [00]	ER: [04]	ST: [04]
RID: [12] [00]	RT: [02]	TS: [6D] [D3] [2D] [4C]	GID: [01] [00]	ER: [04]	ST: [12]
RID: [13] [00]	RT: [02]	TS: [6F] [D3] [2D] [4C]	GID: [20] [00]	ER: [04]	ST: [09]
RID: [14] [00]	RT: [02]	TS: [6F] [D3] [2D] [4C]	GID: [20] [00]	ER: [04]	ST: [09]

Use arrow keys and <Enter> to select from menu.

Figure 3: SEL Log in Hex Format (EFI)

<sup>1</sup> Based on the *IPMI Specification, BIOS EPS*

The following figure shows SEL records in Hex format (Windows\* & Linux\* OSes).




Figure 4: SEL Records in Hex Format (Linux\*)

The abbreviations used in the raw Hex display are as shown in the following table.

Table 3. Acronym Used in the Raw Hex Display

Acronym	Description
RID	Record ID
RT	Record Type
TS	Time Stamp
GID	Generator ID
ER	Event Message Format Revision
ST	Sensor Type
SN	Sensor Number
EDIR	Event Dir and Event Type
ED1, ED2, ED3	Event Data
MID	Manufacturer ID
OEM	OEM Defined
ExB1...ExB8	Extended Byte1...Extended Byte8 <b>Note:</b> Supported only on: <ul style="list-style-type: none"> <li>Intel® Server Board based on Intel® Xeon® processor E5-1600/2600/4600 v2 product family</li> <li>Intel Server Board based on Intel Xeon processor E5-2400 v2 product family</li> <li>Intel Server Board based on Intel Xeon processor E3-1200 v3/v4 product family</li> </ul>



## 2.5 Viewing the Intel® SEL Viewer Information Window

This option allows you to view/hide the SEL Information window. When you run the utility, by default, the SEL Info window is visible and the sub-menu is shown as **Hide SEL Info Window**.

If you select **Hide SEL Info Window**, the SEL Info window is removed from the display area and the sub-menu text changes to **View SEL Info Window**. You can again add the SEL Info window using this sub-menu.

**Hide SEL Info Window / View SEL Info Window** option is currently disabled in Hex view of EFI-based SEL Viewer utility. The SEL Info window automatically goes off when you change from text view to hex view. In case of Linux\*, this option is available under the SEL Menu item.

## 2.6 Navigating the Intel® SEL Viewer Window

To navigate the SEL Viewer window from the pull-down menu, use the arrow keys to move around the various menu items and the <Enter> key to select a particular menu item.

A brief help message about the option selected from the menu is displayed in the tip-view window, which is displayed at the bottom of the main window for EFI-based SEL Viewer Utility. This feature is not supported by WinPE\*-based SEL Viewer Utility.

- For WinPE\*-based SEL Viewer Utility
  - Use <Alt> key to select the menu and use arrow keys to move around various menu items
  - Use <Enter> key to select a particular menu item.
  - A menu item can also be accessed by left clicking the mouse on the menu item.
  - In the display pane, use <Home> key selects the first record and <End> key selects the last record.


The following table list the shortcut keys in the SEL Viewer.

**Table 4. Shortcut Keys of the WinPE\*-based SEL Viewer Utility**

Utility Version	Shortcut Keys	Descriptions
WinPE*	<Alt>+<F>	Open File menu.
	<Alt>+<S>	Open SEL menu.
	<Alt>+<V>	Open View menu.

- For EFI-based SEL Viewer Utility
  - Use <Tab> key to move between the display pane, information window at the bottom and pull-down menu.
  - The display pane supports arrow keys, <PgDn>, <PgUp>, <Home>, and <End> keys to move across the display pane.
  - Use <Home> key selects the beginning of the selected SEL entry in the display pane, and <End> key selects the end of the selected SEL entry in the display pane.
  - Use <F5> key to move forward between columns and <F6> to move backwards.
  - Use left arrow key to scroll to the left and right arrow key to scroll to right in display pane.

When the utility is first invoked, it loads the SEL records from non-volatile storage on the server. A status box as shown in Figure 5 is displayed to indicate that the SEL Viewer is loading SEL records from the server.



Please Wait...

**Figure 5: Status Box**

- For Window\*/Linux\*-based SEL Viewer Utility
  - Serial Numbers can be color coded based on the severity of a SEL Event.
  - A small panel is provided on the bottom right corner which has a statistical view of the SEL Records. It contains the count of the SEL events segregated based on the severity type (i.e., Informational, Warning, Critical, or Others).
  - In Linux\*, the status message is displayed on the status bar of the Utility main window.

## 2.7 Saving the Intel® SEL to a File

You may want to save the SEL to a file for analysis, record keeping, or documentation of a system issue. There are two ways to save the SEL to a file (the Windows Preboot Environment\* version is shown in this example):

- To save the SEL, use the following command line syntax:  
In interpreted text format:

**`selview /save MyFileName`**

In hex format:

**`selview /save MyFileName /hex`**

- Use the **File | Save** menu option from the graphical SEL viewer window.  
To save the SEL data to a file with a .sel file name extension, either in interpreted text format or in raw hex format, depending on the mode in which records are currently displayed.


## 2.8 Viewing the Intel® SEL from a File

To view the SEL records that you previously saved to a file, use the **File | Open** menu option from the graphical SEL viewer window.

To return to viewing the SEL records from non-volatile memory, use the **SEL | Reload** menu option.

## 2.9 Checking the Intel® SEL Properties

To check the SEL properties (number of entries, add/erase time, space available, and so on) in the SEL Properties dialog, use the **SEL | Properties** menu option from the graphical SEL viewer window.



**Figure 6: SEL Properties Dialog**

**Notes:**

- The SEL viewer will display the Free Space Remaining in bytes.
  - In Linux\*, the SEL Properties dialog will not display Last Add Time and Last Erase Time.
- 

## 2.10 Clearing the Intel® SEL

The SEL has a limited capacity. Refer to the Specifications in your server board product guide for the maximum number of records for server. After the SEL is full, subsequent system events will not be recorded and you will need to manually clear the SEL. There are two ways to clear the SEL (the Windows Preboot Environment\* version is shown in this example):

- Use the command line syntax: **selview /clear**
- Use the **SEL | Clear** menu option from the graphical SEL viewer window.

## 2.11 Sorting the Intel® SEL Entries in the UI

Use the **SEL | Sort by** option in the SEL Viewer main window to sort the SEL entries by different fields.

This option, when selected, displays a list of fields by which the entries can be sorted. You can sort the records by Num, Time Stamp, Sensor Type and Number, Event Description, or Generator ID upon choosing the appropriate field.

This option is not available if the SEL entries are displayed in hexadecimal mode.

For Windows\*/Linux\* based SEL Viewer Utility, sorting can also be performed by clicking on the appropriate Column heading using a mouse (in case of text mode display).

## 2.12 Go to Option (Windows\*/Linux\*-only Feature)

Use the **SEL | Go To** option in the SEL Viewer main window to select a particular SEL entry given its Serial Number. You can enter the Serial Number of the SEL Entry in the textbox provided in the Go To dialog and the SEL Table on the Utility main window will be scrolled and that particular entry will be highlighted. **Go To** can be accessed by the shortcut <CTRL>+<G>. This feature is currently supported only on Windows\* & Linux\*.

## 2.13 Getting Additional Help

If you need help on the command line syntax or any of the graphical menu items that are not described in this User Guide, use the online help. There are two ways to get help:

- Use the command line syntax: **selview /help**
- Use the **Help** menu option from the graphical SEL Viewer window.

## 2.14 Uninstalling the Intel® SEL Viewer

To uninstall the SEL Viewer Utility in **EFI**, do the following:

1. Go to the directory in the command line prompt, where all your utility files are copied from the utility released location.

2. Run `cd ..` on a command line prompt. This will take you to a directory one level below.
3. Remove all the directories including subdirectories in the current directory where you are. This leads to the uninstallation of the utility files.

**To uninstall the SEL Viewer Utility in Windows\***, do the following:

The utility files should be manually removed, if they were installed stand alone.

1. Go to the directory in the command line prompt, where all your utility files are copied from the utility released location.
2. Run `cd ..` on a command line prompt. This will take you to a directory one level below.
3. Remove all the directories including subdirectories in the current directory where you are. This leads to the uninstallation of the utility files.

**To uninstall the SEL Viewer Utility in Linux\***, do the following:

1. Go to the directory in the command line prompt, where all your utility files are copied from the utility released location.
2. Run `cd ..` on a command line prompt. This will take you to a directory one level below.
3. Remove all the directories including subdirectories in the current directory where you are. This leads to the uninstallation of the utility files.

## Appendix Exit Error Codes

---

The command line version of the SEL Viewer may be used in a script to automate the tasks of saving the SEL, clearing the SEL, or searching the SEL. The following list of exit codes may be useful in the error handling section of the script.

**Table 5. Exit Error Codes**

<b>Integer Value</b>	<b>Interpretation</b>
0	Successful termination
1	Unable to clear SEL
2	SEL log is empty
3	Unable to read SEL entries
4	Unable to create SEL file
5	Invalid invocation
6	IPMI Driver initialization failed
7	Unable to initialize SEL Viewer
8	Unknown error