

Acer eSettings Management

Acer eSettings Management allows you to view your system information and configuration, set passwords to improve security, and set boot options.

Using Acer eSettings Management

To launch Acer eSettings Management:

- Click on the Acer eSettings Management icon in the **Empowering Technology** toolbar shown on your desktop.
- From the Start menu, go to **(All) Programs > Acer Empowering Technology > Acer eSettings Management**.



This will open the Acer eSettings Management main page.

The screenshot displays the Acer eSettings Management application window. At the top, there's a title bar with the text "Empowering Technology" and the Acer logo. Below the title bar is a navigation bar with tabs: "Summary" (selected), "Processor", "Memory", and "MB and BIOS". A status indicator "1 / 2" is also present. The main content area is a table showing system specifications. The table has two columns: "Item" and "Value".

Item	Value
Manufacturer	Acer
Product Name	Veriton
Operating System	Microsoft Windows XP Professional
Processor	Genuine Intel(R) CPU 3.20GHz
Chipset	Intel 955x/945P/945G Express
Ethernet Card	Marvell Yukon 88E8053 PCI
System Memory	512 MB
Video Memory	128 MB
Hard Drive 1	SAMSUNG SP1614C,149.05 GB
CD/DVD Drive 1	COMBO BC05232IM
Video	Intel(R) 82945G Express Chipset Family
Audio	Realtek High Definition Audio
UUID	FFFFFFFF-FFFF-FFFF-FFFF-FFFFFFFF
Serial Number	

At the bottom of the window, there are three buttons: "System Information" (selected), "Boot Options", and "Monitoring". The Acer logo is located in the bottom right corner.

Acer eSettings Management Main Page

From the main page, you can view different types of **System Information**:

- Summary
- Processor
- Memory
- MB and BIOS
- Video
- Audio
- Network

Click the left and right arrows near the top-right side of the page to view all the system information tabs. Click the  icon to save and the  icon to print information for the selected tab.

By clicking the icons at the bottom of the page, you can also:

- Set your **Boot Options**.
- **Monitor** important system components.

Boot Options

Select this page to change your computer's boot sequence.



Monitoring

Use this page to monitor important system components:

- Summary
- Temperature
- Fan speed
- Voltage
- Network
- Memory usage
- Hard drive



Note: Monitoring may not be available for all desktop systems.