

## Acer LCD monitor Quick Start Guide (QSG)


## Important Safety Instructions

Please read the following instructions carefully. This manual should be retained for future use.



- 1. To clean LCD Monitor screen:
  - -- Power off LCD Monitor and unplug the AC Cord.
  - -- Spray a non-solvent cleaning solution onto a rag and clean the screen gently.
- Do not place the LCD Monitor near a window.
  Exposing the monitor to rain water,
  moisture or sunlight can severely damage it.
- Do not apply pressure to the LCD screen.
  Excess pressure may cause permanent damage to the display.
- Do not remove the cover or attempt to service this unit by yourself. Servicing of any nature should be performed by an authorized technician.
- 5. Store LCD Monitor in a room with a room temperature of  $-20 \, \bot \sim 60 \, \bot$  (or  $-4 \, \bot \sim 140 \, \bot$ ). Storing the LCD Monitor outside this range could result in permanent damage.
- If any of the following occurs, immediately unplug your monitor and call an authorized technician.
  - \* Monitor to PC signal cable is frayed or damaged.
  - \* Liquid spilled into LCD Monitor or the monitor has been exposed to rain.
  - \* LCD Monitor or the case is damaged.

## Operating Your Monitor If OSD is active, press to exit. If OSD is Auto Auto configuration press and themonitor will automatically optimize the display position, clock and phase of your display. If OSD is active, press to select or 2 Minus adjust OSD options. If OSD is active, press to select or 3 Plus adjust OSD options. 4 OSD manual Menu Press to view OSD. Press again to exit. Power on/off 5 (1)power Green: power on Orange: in sleep mode



on a stable and level workspace.

Make sure you heard click sound

Take out your monitor and assembly with the base.

