

Extensa 5630 Series

Quick Guide

Copyright © 2008. Acer Incorporated.
All Rights Reserved.

Extensa 5630 Series Quick Guide
Original Issue: 06/2008

This company makes no representations or warranties, either express or implied, with respect to the contents hereof and specifically disclaims the implied warranties of merchantability or fitness for a particular purpose. Although care has been taken to ensure accuracy, this company shall not be liable for any errors (including, but not limited to, typos, factual errors, etc.) contained in this publication.

Changes may be made periodically to the information in this publication without obligation to notify any person of such revisions or changes. Such changes will be incorporated in new editions of this manual or supplementary documents and publications. This company makes no representations or warranties, either expressed or implied, with respect to the contents hereof and specifically disclaims the implied warranties of merchantability or fitness for a particular purpose.

Record the model number, serial number, purchase date and place of purchase information in the space provided below. The serial number and model number are recorded on the label affixed to your computer. All correspondence concerning your unit should include the serial number, model number and purchase information.

No part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form or by any means, electronically, mechanically, by photocopy, recording or otherwise, without the prior written permission of Acer Incorporated.

Extensa 5630 Series Notebook PC

Model number: _____

Serial number: _____

Date of purchase: _____

Place of purchase: _____

Acer and the Acer logo are registered trademarks of Acer Incorporated. Other companies' product names or trademarks are used herein for identification purposes only and belong to their respective companies.

CE Declaration of Conformity



We,

Acer Computer (Shanghai) Limited
3F, No. 168 Xizang Medium Road, Huangpu District,
Shanghai, China

Contact person: Mr. Easy Lai

Tel: 886-2-8691-3089, Fax: 886-2-8691-3120

Email: easy_lai@acer.com.tw

Hereby declare that:

Product: Notebook Computer

Trade name: Acer

Model number: MS2231

Machine type: Extensa 5630

SKU number: Extensa 5630-xxxxx ("x" = 0-9, a-z, or A-Z)

Is compliant with the essential requirements and other relevant provisions of the following EC directives, and that all the necessary steps have been taken and are in force to assure that production units of the same product will continue comply with the requirements.

EMC Directive 2004/108/EC as attested by conformity with the following harmonized standards:

- EN55022:1998 + A1:2000 + A2:2003, AS/NZS CISPR22:2002, Class B
- EN55024:1998 + A1:2001 + A2:2003
- EN55013:2001 + A1:2003 + A2:2006 (For AV products)
- EN55020:2007 (For AV products)
- EN61000-3-2:2006, Class D
- EN61000-3-3:1995 + A1:2001 + A2:2005

Low Voltage Directive 2006/95/EC as attested by conformity with the following harmonized standard:

- EN60950-1:2001 + A11:2004
- EN60065:2002 (For AV products)

Council Decision 98/482/EC (CTR21) for pan-European single terminal connection to the Public Switched Telephone Network (PSTN).

RoHS Directive 2002/95/EC on the Restriction of the Use of certain Hazardous Substances in Electrical and Electronic Equipment.

R&TTE Directive 1999/5/EC as attested by conformity with the following harmonized standards:

- **Article 3.1(a) Health and Safety**
 - EN60950-1:2001 + A11:2004
 - EN50371:2002 (SAR, general RF devices)
 - EN50360:2001 (SAR, for mobile phones)
- **Article 3.1(b) EMC**
 - EN301 489-1 V1.6.1 (Common technical requirements)
 - EN301 489-3 V1.4.1 (For short-range devices)
 - EN301 489-7 V1.3.1 (For GSM and DCS)
 - EN301 489-17 V1.2.1 (For wide band data and HIPERLAN equipment)
 - EN301 489-24 V1.2.1 (For UMTS band)
- **Article 3.2 Spectrum Usages**
 - EN300 220-3 V1.1.1 (For short range devices, 25 - 1000MHz, part 3).
 - EN300 440-2 V1.1.2 (For short range devices, 1G - 20GHz, part 2).
 - EN300 328 V1.7.1

(For Data transmission equipment operating in the 2.4 GHz ISM band).

-EN301 511 V9.0.2 (For GSM and DCS)

-EN301 893 V1.2.3 (5 GHz high performance RLAN)

-EN301 908-1 V2.2.1 (For UMTS band, introduction and common requirements)

-EN301 908-2 V2.2.1

(Harmonized EN for IMT-2000, CDMA Direct Spread (UTRA FDD))

CE marking affixed starting from 2008

Easy Lai

Easy Lai / Director

Acer Computer (Shanghai) Limited

29 Feb 2008

Date

Federal Communications Commission Declaration of Conformity

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

The following local manufacturer/importer is responsible for this declaration:

Product name:	Notebook PC
Model number:	MS2231
Machine type:	Extensa 5630
SKU number:	Extensa 5630-xxxxx ("x" = 0 - 9, a - z, or A - Z)
Name of responsible party:	Acer America Corporation
Address of responsible party:	333 West San Carlos St., San Jose, CA 95110 USA
Contact person:	Acer Representative
Tel:	1-254-298-4000
Fax:	1-254-298-4147

First things first

We would like to thank you for making an Acer notebook your choice for meeting your mobile computing needs.

Your guides

To help you use your Acer notebook, we have designed a set of guides*:

First off, the **Just for Starters...** helps you get started with setting up your computer.

For more on how your computer can help you to be more productive, please refer to the AcerSystem User Guide. This guide contains detailed information on such subjects as system utilities, data recovery, expansion options and troubleshooting. In addition it contains warranty information and the general regulations and safety notices for your notebook. It is available in Portable Document Format (PDF) and comes preloaded on your notebook. Information for your safety and comfort.



Note: Viewing the file requires Adobe Reader. If Adobe Reader is not installed on your computer, clicking on AcerSystem User Guide will run the Adobe Reader setup program first. Follow the instructions on the screen to complete the installation. For instructions on how to use Adobe Reader, access the Help and Support menu.

Please understand that due to its nature, the Quick Guide as well as the Application Manual will occasionally refer to functions or features which are only contained in certain models of the series, but not necessarily in the model you purchased. Such instances are marked in the text with language such as "only for certain models".



*** IMPORTANT NOTICE:** Please note that the guides mentioned herein, whether in printed or electronic form, are for your reference only and except as provided in the specific warranty information contained in the AcerSystem User Guide nothing contained in these guides shall constitute a representation or warranty by Acer with regard to the product you purchased. Acer expressly disclaims any liability for errors contained in the guides.

Your Acer notebook tour

After setting up your computer as illustrated in the **Just for Starters...** poster, let us show you around your new Acer notebook.


Top view



#	Item	Description
1	Acer Crystal Eye	Web camera for video communication (only for certain models).


#	Item	Description
2	Acer PureZone	Two internal stereo microphones for sound recording.
3	Display screen	Also called Liquid-Crystal Display (LCD), displays computer output.
4	Speakers	Left and right speakers deliver stereo audio output.
5	Empowering key	Launch Acer Empowering Technology
6	Productivity keys	Three productivity keys give users one-touch access to protection and manageability features for a more secure, smarter and easier way to work. Please refer to "Generic User Guide" for more details.
7	Easy-launch buttons	Buttons for launching frequently used programs. Please refer to "Generic User Guide" for more details.
8	Palmrest	Comfortable support area for your hands when you use the computer.
9	Touchpad	Touch-sensitive pointing device which functions like a computer mouse.
10	Click buttons (left, center* and right)	The left and right buttons function like the left and right mouse buttons. *The center button serves as Acer BioProtect fingerprint reader supporting Acer FingerNav 4-way control function (manufacturing option).
11	Acer Bio-Protection fingerprint reader	The center button serves as Acer Bio-Protection fingerprint reader supporting Acer FingerNav 4-way control function (only for certain models).
12/15	Status indicators	Light-Emitting Diodes (LEDs) that light up to show the status of the computer's functions and components. Please refer to "Generic User Guide" for more details.
13	Keyboard	For entering data into your computer.
14	Power button	Turns the computer on and off.

Closed front view



#	Icon	Item	Description
1		Latch	Locks and releases the lid.
2		5-in-1 card reader	Accepts Secure Digital (SD), MultiMediaCard (MMC), Memory Stick (MS), Memory Stick Pro (MS PRO), and xD-Picture Card. Note: Only one card can operate at any given time.
3		Line-in jack	Accepts audio line-in devices (e.g., audio CD player, stereo walkman, mp3 player)
4		Microphone jack	Accepts inputs from external microphones.
5		Headphones/speaker/line-out jack.	Connects to audio line-out devices (e.g., speakers, headphones).
6		Bluetooth communication switch	Enable/disable the Bluetooth function.
7		Wireless communication switch	Enable/disable the wireless function.

Left view



#	Icon	Item	Description
1		Kensington lock slot	Connects to a Kensington-compatible computer security lock.
2		Acer EasyPort IV connector	Connects to Acer EasyPort IV.
3		External display (VGA) port	Connects to a display device (e.g., external monitor, LCD projector).
4		Ethernet (RJ-45) port	Connects to an Ethernet 10/100/1000-based network.
5	HDMI	HDMI port	Supports high definition digital video connections.
6		Two USB 2.0 ports	Connect to USB 2.0 devices (e.g., USB mouse, USB camera).
7		PC Card slot	Accepts one Type II PC Card.
8	ExpressCard / 54	ExpressCard/54 slot	Accepts one ExpressCard/54 module.
9		PC Card slot eject button	Ejects the PC Card from the slot.

Right view




#	Item	Description
1	Optical drive	Internal optical drive; accepts CDs or DVDs.
2	Optical disk access indicator	Lights up when the optical drive is active.
3	Optical drive eject button	Ejects the optical disk from the drive.
4	Emergency eject hole	Ejects the optical drive tray when the computer is turned off. Note: Insert a paper clip to the emergency eject hole to eject the optical drive tray when the computer is off.

Rear view



#	Icon	Item	Description
1		USB 2.0 port	Connects to USB 2.0 devices (e.g., USB mouse, USB camera).
2	 / e SATA	USB 2.0/ e SATA port	Connects to USB 2.0 or eSATA devices. Note: If you plug an eSATA device you will have three USB ports available in the mean time.
3		Modem (RJ-11) port	Connects to a phone line.
4		DC-in jack	Connects to an AC adapter.
5		Ventilation slots	Enable the computer to stay cool, even after prolonged use.

Base view



#	Icon	Item	Description
1		Hard disk bay	Houses the computer's hard disk (secured with screws)
2		Acer DASP (Disk Anti-Shock Protection)	Protects the hard disk drive from shocks and bumps.
3		Ventilation slots and cooling fan	Enable the computer to stay cool, even after prolonged use. Note: Do not cover or obstruct the opening of the fan.
4		Memory compartment	Houses the computer's main memory.
5		Battery lock	Locks the battery in position.
6		Battery release latch	Releases the battery to remove the battery pack.
7		Battery bay	Houses the computer's battery pack.

Specifications

Operating system	Windows Vista™
Platform	- Intel® Centrino® 2 processor technology, featuring: - Intel® Core™ 2 Duo mobile processor - Mobile Intel® GM45/PM45 Express Chipset* - Intel® Wireless WiFi Link 5100/5300
System memory	- Dual-Channel DDR2 support - Up to 2 GB of DDR2 667 MHz memory, upgradeable to 4 GB using two soDIMM modules*
Display	15.4" WXGA 1280 x 800
Graphics	- Mobile Intel® GM45 Express Chipset* - ATI Mobility Radeon™ HD 3470* - NVIDIA® GeForce® 9300M GS*
Storage subsystem	2.5" hard disk drive - Optical drive options: - Blu-ray Disc™/DVD-Super Multi double-layer drive - DVD-Super Multi double-layer drive - DVD/CD-RW combo drive 5-in-1 card reader
Audio	- Two built-in Acer 3DSonic stereo speakers - High-definition audio support - MS-Sound compatible - Acer PureZone technology with two built-in stereo microphones - Built-in microphone
Communication	- Acer Video Conference, featuring: - Integrated Acer Crystal Eye webcam* - Optional Acer Xpress VoIP phone - WLAN: Intel® Wireless WiFi Link 5100/5300 - WPAN: Bluetooth® 2.0+EDR - LAN: Gigabit Ethernet, Wake-on-LAN ready - Modem: 56K ITU V.92
Privacy control	- Enhanced Acer DASP (Disk Anti-Shock Protection) - Acer Bio-Protection fingerprint solution* - BIOS user, supervisor, HDD passwords - Kensington lock slot
Dimensions	360 (W) x 267 (D) x 30.3/43 (H) mm (14.17 x 10.51 x 1.09/1.69 inches) 3.02 kg (6.64 lbs)* 2.88 kg (6.34 lbs)*

Power subsystem	• ACPI 3.0 • 71 W 4800 mAh • 44.4W 4000 mAh • 3-pin 65/90 W AC adapter • Energy Strat 4.0
Input devices	• 88-/89-key keyboard
I/O interface	• Acer EasyPort IV connector • ExpressCard™/54 slot • PC Card slot (Type II) • Acer Bio-Protection fingerprint reader* • 5-in-1 card reader (SD™, MMC, MS, MS PRO, xD) • HDMI™ port with HDCP support • Three USB 2.0 ports • USB 2.0/ eSATA port
	 Note: If you plug an eSATA device you will have three USB ports available in the mean time. • External display (VGA) port • Headphone/speaker/line-out jack • Microphone-in jack • Line-in jack • Ethernet (RJ-45) port • Modem (RJ-11) port • DC-in jack for AC adapter
Environment	• Temperature: • Operating: 5 °C to 35 °C • Non-operating: -20 °C to 65 °C • Humidity (non-condensing): • Operating: 20% to 80% • Non-operating: 20% to 80%



Note: "*" "only for certain models".



Note: The specifications listed above are for reference only. The exact configuration of your PC depends on the model purchased.